Electrical Safety Tester

GPT-9000 / GPT-9000A Series

USER MANUAL

GW INSTEK PART NO. 82PT-90000EH1





This manual contains proprietary information, which is protected by copyright. All rights are reserved. No part of this manual may be photocopied, reproduced or translated to another language without prior written consent of Good Will company.

The information in this manual was correct at the time of printing. However, Good Will continues to improve products and reserves the rights to change specification, equipment, and maintenance

Good Will Instrument Co., Ltd.
No. 7-1, Jhongsing Rd., Tucheng Dist., New Taipei City 236, Taiwan.

procedures at any time without notice.



Table of Contents

SAFETY INSTE	RUCTIONS	5
GETTING STA	RTED	9
	GPT-9000/9000A Series Overview	10
	Appearance	15
	Set Up	23
OPERATION		30
	Menu Tree	32
	Test Lead Connection	36
	ACW, DCW, IR and GB Manual Testing	. 38
	Special MANU Test Mode (000)	77
	Automatic Tests	82
	Common Utility Settings	99
EXTERNAL CO	ONTROL	108
	External Control Overview	109
REMOTE CON	ITROL	115
	Interface Configuration	116
	Command Syntax	120
	Command List	123
FAQ		165
APPENDIX		167
	Fuse Replacement	167
	Error Messages	168
	GPT-9000/9000A Specifications	170
	GPT-9801/9802/9803 Dimensions	177
	GPT-9804 Dimensions	178



	GPT-9903 Dimensions 1	79
	GPT-9904 Dimensions 1	80
	GPT-9901A/9902A/9903A Dimensions 1	81
	Certificate Of Compliance	82
INDEV		7.00
INDEX	•••••	183



SAFETY INSTRUCTIONS

This chapter contains important safety instructions that you must follow during operation and storage. Read the following before any operation to ensure your safety and to keep the instrument in the best possible condition.

Safety Symbols

These safety symbols may appear in this manual or on the instrument.

! WARNING	Warning: Identifies conditions or practices that could result in injury or loss of life.
! CAUTION	Caution: Identifies conditions or practices that could result in damage to the instrument or to other properties.
<u> </u>	DANGER High Voltage
<u></u>	Attention Refer to the Manual
	Protective Conductor Terminal
\rightarrow	Frame or Chassis Terminal

Earth (ground) Terminal





Do not dispose electronic equipment as unsorted municipal waste. Please use a separate collection facility or contact the supplier from which this instrument was purchased.

Safety Guidelines

General Guideline



- Do not place any heavy object on the instrument.
- Avoid severe impact or rough handling that leads to damaging the instrument.
- Do not discharge static electricity to the instrument.
- Use only mating connectors, not bare wires, for the terminals.
- · Do not block the cooling fan opening.
- Do not disassemble the GPT-9000/GPT-9000A unless you are qualified.

(Measurement categories) EN 61010-1:2010 specifies the measurement categories and their requirements as follows. The GPT-9000/GPT-9000A does not fall under category II, III or IV.

- Measurement category IV is for measurement performed at the source of low-voltage installation.
- Measurement category III is for measurement performed in the building installation.
- Measurement category II is for measurement performed on the circuits directly connected to the low voltage installation.

Power Supply



- AC Input voltage range: 100/120/220/230VAC ±10%
- Frequency: 50Hz/60Hz
- To avoid electrical shock connect the protective grounding conductor of the AC power cord to an earth ground.



Cleaning the GPT-9000/

- Disconnect the power cord before cleaning.
- Use a soft cloth dampened in a solution of mild detergent and water. Do not spray any liquid.
- Do not use chemicals containing harsh material such as benzene, toluene, xylene, and acetone.

Operation Environment

- Location: Indoor, no direct sunlight, dust free, almost non-conductive pollution (Note below)
- Relative Humidity: ≤ 70% (no condensation)
- Altitude: < 2000m
- Temperature: 0°C~40°C

(Pollution Degree) EN 61010-1:2010 specifies the pollution degrees and their requirements as follows. The GPT-9000/GPT-9000A falls under degree 2.

Pollution refers to "addition of foreign matter, solid, liquid, or gaseous (ionized gases), that may produce a reduction of dielectric strength or surface resistivity".

- Pollution degree 1: No pollution or only dry, non-conductive pollution occurs. The pollution has no influence.
- Pollution degree 2: Normally only non-conductive pollution occurs. Occasionally, however, a temporary conductivity caused by condensation must be expected.
- Pollution degree 3: Conductive pollution occurs, or dry, nonconductive pollution occurs which becomes conductive due to condensation which is expected. In such conditions, equipment is normally protected against exposure to direct sunlight, precipitation, and full wind pressure, but neither temperature nor humidity is controlled.

Storage environment

- Location: Indoor
- Temperature: -10°C to 70°C
- Relative Humidity: ≤ 85% (no condensation)

Disposal



Do not dispose this instrument as unsorted municipal waste. Please use a separate collection facility or contact the supplier from which this instrument was purchased. Please make sure discarded electrical waste is properly recycled to reduce environmental impact.



Power cord for the United Kingdom

When using the safety tester in the United Kingdom, make sure the power cord meets the following safety instructions.

NOTE: This lead/appliance must only be wired by competent persons

VI WARNING: THIS APPLIANCE MUST BE EARTHED

IMPORTANT: The wires in this lead are coloured in accordance with the

following code:

Green/ Yellow: Earth
Blue: Neutral
Brown: Live (Phase)



As the colours of the wires in main leads may not correspond with the coloured marking identified in your plug/appliance, proceed as follows:

The wire which is coloured Green & Yellow must be connected to the Earth terminal marked with either the letter E, the earth symbol \oplus or coloured Green/Green & Yellow.

The wire which is coloured Blue must be connected to the terminal which is marked with the letter N or coloured Blue or Black.

The wire which is coloured Brown must be connected to the terminal marked with the letter L or P or coloured Brown or Red.


If in doubt, consult the instructions provided with the equipment or contact the supplier.

This cable/appliance should be protected by a suitably rated and approved HBC mains fuse: refer to the rating information on the equipment and/or user instructions for details. As a guide, a cable of 0.75mm² should be protected by a 3A or 5A fuse. Larger conductors would normally require 13A types, depending on the connection method used.

Any exposed wiring from a cable, plug or connection that is engaged in a live socket is extremely hazardous. If a cable or plug is deemed hazardous, turn off the mains power and remove the cable, any fuses and fuse assemblies. All hazardous wiring must be immediately destroyed and replaced in accordance to the above standard.

GETTING STARTED

This chapter describes the safety tester in a nutshell, including its main features and front / rear panel introduction. After going through the overview, please read the safety considerations in the Set Up chapter.



GPT-9000/9000A Series Overview	10
Series lineup10	
Model Overview11	
Main Features11	
Accessories12	
Package Contents14	
Appearance	15
GPT-9801/9802/9803/9901A/9902A/9903/9903A Front Panel 1	15
GPT-9804/9904 Front Panel15	
GPT-9801/9802/9803/9804 Rear Panels19	
GPT-9901A/9902A/9903/9903A Rear Panel19	
GPT-9904 Rear Panel	
Set Up	23
ine Voltage Connection and Power Up23	
nstalling the Optional GPIB Card25	
Vorkplace Precautions26	
Operating Precautions27	
Basic Safety Checks29	



GPT-9000/9000A Series Overview

Series lineup

The GPT-9000/9000A Series Safety Testers are AC/DC withstanding voltage, insulation resistance and ground bond safety testers.

The GPT-9801/9901A are AC withstanding voltage testers, the GPT-9802/9902A are AC/DC withstanding voltage testers and the GPT-9803/9903/9903A are AC/DC withstanding voltage and insulation resistance testers. The GPT-9804 & GPT-9904 include all the test functions of the other models as well as ground bond testing. All models can operate at up to 5kVAC for AC withstanding voltage testing and at up to 6kVDC for DC withstanding voltage testing (excluding the GPT-9801/9901A).

For the GPT-99XX/99XXA models, the testing terminals are also mirrored on the rear panel for added safety and for more permanent safety testing environments. They also include an innovative sweep function to view test results as a graph.

The GPT-9000/9000A Series can store up to 100 manual tests, as well as run up to 16 manual tests sequentially as an automatic test, allowing the safety testers to accommodate any number of safety standards, including IEC, EN, UL, CSA, GB, JIS and others.

Note: Throughout this user manual, the terms ACW, DCW, IR and GB refer to AC Withstanding, DC Withstanding, Insulation Resistance and Ground Bond testing, respectively. GPT-9000 refers to any of the GPT-98XX or GPT-99XX models, GPT-9000A refers to any of the GPT-99XXA models.



Model Overview

Model name	ACW	DCW	IR	GB	Sweep
GPT-9801	✓				
GPT-9802	✓	\checkmark			
GPT-9803	✓	✓	✓		
GPT-9804	✓	✓	✓	✓	
GPT-9901A	✓				✓
GPT-9902A	✓	✓			✓
GPT-9903	✓	✓	✓		✓
GPT-9903A	✓	✓	✓		✓
GPT-9904	✓	✓	✓	✓	✓

Main Features

Performance

ACW: 5kVAC

• DCW: 6kVDC

• IR: 50V~1000V (50V steps)*

• GB: 3A~30A (GPT-98XX); 3A~32A (GPT-99XX)

* The GPT-99XX/99XXA also includes an extra +125V test point



Features •	Ramp up time control				
•	Safety discharge100 test conditions (MANU mode)				
•					
•	100 automatic tests (AUTO mode)				
•	Over temperature, voltage and current protection				
•	Pass, Fail, Test, High Voltage and Ready indicators				
•	PWM output (90% efficiency, increased reliability)				
•	Interlock (configurable)				
•	Sweep Function				
	Rear panel output (GPT-9000 series only)				
Interface •	Remote control start/stop interface terminal RS232/USB interface for programming				
•	Optional GPIB interface for programming				
•	Signal I/O port for pass/fail/test monitoring and start/stop control/interlock				

Accessories

Standard Accessories	Part number	Description
	GHT-114 x1	Test lead
	Region dependent	Power cord
	GTL-115 x1 or GTL-215 x1	GB Test leads (A random type will be shipped. GPT-9804/9904 only)
	N/A	Remote terminal male plug
	N/A	Interlock key




Optional Accessories	Part number	Description
	GHT-205	High Voltage Test Probe
	GHT-113	High Voltage Test Pistol
	GTL-232	RS232C cable
	GTL-248	GPIB cable
	GTL-247	USB cable
	GRA-417	Rack Adapter Panel (19", 4U) (GPT-9801/9802/9803/ 9804/9901A/9902A/9903A only)
	GRA-433	Rack Adapter Panel (19", 4U) (GPT-9903A/9904A only)
Options	Part number	Description
GPT-9KG1	Opt.01 GPIB Interface	GPIB module



Package Contents

Check the contents before using the GPT-9000/GPT-9000A.

Opening the box



Contents (single unit)

- GPT-9000/9000A unit GHT-114 test leads x1
- Quick Start guide
- User manual CD
- CTC (Calibration Traceable Certificate)
- GTL-115 test leads x1 (GPT-9804/9904)
- Remote terminal male plug
- Interlock key • Power cord x1 (region dependent)




Keep the packaging, including the box, polystyrene foam and plastic envelopes should the need arise to return the unit to GW Instek.




Appearance

GPT-9801/9802/9803/9901A/9902A/9903/9903A Front Panel



GPT-9804/9904 Front Panel





Display 240 X 64 dot matrix display (LCD) Function keys The function keys correspond to the soft-keys directly above on the main display. PASS FAIL The PASS and FAIL indicators Pass/Fail indicators light up upon a PASS or FAIL test result at the end of a manual test or automatic test. The ESC key is used to exit out of ESC key a menu or cancel a setting. PAGE key The PAGE key is used to view automatic test information and test results. Directional arrow The directional arrow keys are used to navigate menus and keys parameter settings. **READY** indicator READY The READY indicator is lit when the tester is ready to begin testing. The STOP button is used to put the tester into READY status. **TEST** indicator The TEST indicator is lit when a test is on. The START button is used to put the tester into TEST status. CALITION HIGH VOLTAGE The HIGH VOLTAGE indicator indicator will light up when an output terminal is active. Only after the test has finished or stopped will the indicator turn off.

HIGH VOLTAGE output terminal



The HIGH VOLTAGE terminal output is used for outputting the testing voltage. The terminal is recessed for safety. This terminal is used in conjunction with the RETURN terminal.



WARNING

USE EXTREME CAUTION.

Do not touch the HIGH VOLTAGE terminal during testing.

RETURN terminal All models except GPT-9804/9904


RETURN



The RETURN terminal is used for IR, DCW and ACW tests.

RETURN, SENSE GPT-9804/9904

and SOURCE terminals



The RETURN terminal is used for IR, DCW and ACW tests.

The SOURCE H, SOURCE L, SENSE H and SENSE L terminals are used for GB tests.

Scroll wheel



The scroll wheel is used to edit parameter values.

UTILITY key




Used to enter the MANU Utility or Common Utility menu.


EDIT/SAVE key	EDIT/SAVE	Used to start editing MANU/AUTO tests as well as save settings and parameters.
MANU/AUTO key	MANU/AUTO	The MANU/AUTO key is used to select manual tests (MANU) or automatic tests (AUTO).
REMOTE terminal	REMOTE	The REMOTE terminal is used to connect to a remote controller.
STOP button	STOP	The STOP button is used to stop/cancel tests. The STOP button will also put the safety tester in the READY status to begin testing.
START button	START	The START button is used to start tests. The START button can be used to start tests when the tester is in the READY status. Pressing the START button will put the tester in the TEST status.
POWER switch	POWER	Turns the power on. The safety tester will always start up with the setting which was performed and executed from the last test.



GPT-9801/9802/9803/9804 Rear Panels




GPT-9901A/9902A/9903/9903A Rear Panel





GPT-9904 Rear Panel



SIGNAL I/O port



The SIGNAL I/O port is used to monitor the tester status (PASS, FAIL, TEST) and input (START/STOP signals). It is also used with the Interlock key.

USB A port



Used for remote control.

RS232 interface port



Used for remote control and firmware updates.

Fan/Fan Vents

Exhaust fan. Allow enough room for the fan to vent. Do not block the fan openings.

GND



Connect the GND (ground) terminal to the earth ground.

Line voltage input



Line voltage input: 100/120/220/230VAC ±10%

Line voltage fuse



Line voltage selector and fuse:

GPT-98XX:

100V/120V T5A 250V 220V/230V T2.5A 250V

GPT-99XX/99XXA:

100V/120V T10A 250V 220V/230V T6.3A 250V

Optional GPIB port



Optional GPIB interface for remote control.

HIGH VOLTAGE output terminal



The HIGH VOLTAGE terminal output is used for outputting the testing voltage.



USE EXTREME CAUTION.

Do not touch the HIGH VOLTAGE terminal during testing.

RETURN terminal GPT-9901A/9902A/ 9903/9903A

RETURN


The RETURN terminal is used for IR, DCW and ACW tests.





RETURN/ SENSE and SOURCE terminals

GPT-9904



The RETURN terminal is used for IR, DCW and ACW tests.

The SOURCE L/H and SENSE L/H terminals are for GB tests only.

Set Up

Line Voltage Connection and Power Up


Background

Before powering up the GPT-9000/9900A ensure the correct voltage has been selected on the rear panel. The GPT-9000/9000A supports line voltages of 100V/120V/220V and 230V.


Steps

1. Check the line voltage and the fuse Page 167 in the fuse holder.

The desired line voltage should line up with the arrow on the fuse holder.



Connect the power cord to the AC voltage input.



 If the power cord does not have an earth ground, ensure the ground terminal is connected to an earth ground.



!Warning

Ensure the power cord is connected to an earth ground. Failure could be harmful to the operator and instrument.

4. Press the Power button.






- When the unit is powering up, all the LED indicators will light. Check to make sure all 5 LED indicators are working.
- 6. Check to make sure the System Self Test passes without errors.



After the System Self Test completes, the tester will go into VIEW status and be ready to operate.






Installing the Optional GPIB Card


Background	The optional GPIB is a user-installable option. Follow the instructions below to install the GPIB card.
• WARNING	Before installing the optional GPIB card ensure the GPT-9000/9000A is turned off and disconnected from power.

Steps

1. Remove the screws from the rear panel cover plate.



2. Insert the GPIB card into the two slots on either side of the opening. Push the card gently until it is fully inserted.





Workplace Precautions

Background

The GPT-9000/9900A is a high voltage instrument that outputs dangerous voltages. The following section describes precautions and procedures that must be followed to ensure a safe work environment.

WARNING

The GPT-9000/9000A generates voltages in excess of 5kVAC or 6kVDC. Follow all safety precautions, warnings and directions given in the following section when using the instrument.

- 1. Only technically qualified personnel should be allowed to operate the safety tester.
- The operating workplace must be fully isolated, especially when the instrument is in operation. The instrument should be clearly labeled with appropriate warning signage.
- The operator should not wear any conductive materials, jewelry, badges, or other items, such wrist watches.
- 4. The operator should wear insulation gloves for high voltage protection.
- 5. Ensure the earth ground of the line voltage is properly grounded.
- Ensure any devices that are adversely affected by magnetic fields are not placed near the tester.



Operating Precautions

Background The GPT-9000/9000A is a high voltage instrument that outputs dangerous voltages. The following section describes precautions and procedures that must be followed to ensure that the tester is operated in a safe manner.

WARNING

The GPT-9000/9000A generates voltages of up to 5kVAC or 6kVDC. Follow all safety precautions, warnings and directions given in the following section when using the instrument.

- Never touch the safety tester, lead wires, terminals, probes and other connected equipment when the tester is testing.
- 2. Do not turn the safety tester on and off quickly or repeatedly. When turning the power off, please allow a few moments before turning the power back on. This will allow the protection circuits to properly initialize.
 - Do not turn the power off when a test is running, unless in an emergency.
- Only use those test leads supplied with the instrument. Leads with inappropriate gauges can be dangerous to both the operator and the instrument.
 - For GB testing, never use the Sense leads on the SOURCE terminals.
- Do not short the HIGH VOLTAGE terminal with ground. Doing so could charge the chassis to dangerously high voltages.

- 5. Ensure the earth ground of the line voltage is properly grounded.
- Only connect the test leads to the HIGH VOLTAGE/SOURCE H/SENSE H terminals before the start of a test. Keep the test leads disconnected at all other times.
- 7. Always press the STOP button when pausing testing.
- 8. Do not leave the safety tester unattended. Always turn the power off when leaving the testing area.
- 9. When remotely controlling the safety tester, ensure adequate safety measures are in place to prevent:
- Inadvertent output of the test voltage.
- Accidental contact with the instrument during testing. Ensure that the instrument and DUT are fully isolated when the instrument is remotely controlled.
- Ensure an adequate discharge time for the DUT.

When DCW or IR tests are performed, the DUT, test leads and probes become highly charged. The GPT-9000/9000A has discharge circuitry to discharge the DUT after each test. The time required for a DUT to discharge depends on the DUT and test voltage.

Never disconnect the safety tester before a discharge is completed.



Basic Safety Checks

Background	The GPT-9000/9000A is a high voltage device and as such, daily safety checks should be made to ensure safe operation.

- 1. Ensure all test leads are not broken and are free from defects such as cracks or splitting.
- 2. Ensure the safety tester is always connected to an earth ground.
- 3. Test the safety tester operation with a low voltage/current output:

Ensure the safety tester generates a FAIL judgment when the HIGH VOLTAGE and RETURN terminals are shorted (using the lowest voltage/current as the testing parameters).



Do not use high voltages/currents when the HIGH VOLTAGE and RETURN terminals are shorted. It may result in damage to the instrument.



OPERATION

Menu Tree		32
Menu Tree Overview	33	
Test Lead Connection	•••••	36
ACW, DCW, IR Connection	36	
GB Connection	37	
ACW, DCW, IR and GB Manual Testing	•••••	38
Choose/Recall a Manual Test Number		
Edit Manual Test Settings	40	
Setting the Test Function	41	
Setting the Test Voltage or Test Current	42	
Setting the Test Frequency	43	
Setting the Upper and Lower Limits	44	
Setting a Reference Value	46	
Setting the Test Time (Timer)	47	
Setting the Ramp Up Time	50	
Creating a MANU Test File Name	51	
Setting the ARC Mode	52	
Setting PASS HOLD	55	
Setting FAIL MODE		
Setting MAX HOLD	57	
Setting the Grounding Mode	58	
Saving and Exiting EDIT Status		
Running a MANU Test	64	
PASS / FAIL MANU Test		
Zeroing of the Test Leads (GB only)	74	
Special MANU Test Mode (000)		77
Automatic Tests		82

OPERATION




Choose/Recall an Automatic Test	82
Edit Automatic Test Settings	84
Adding a Step to the Automatic Test	85
Creating an AUTO Test File Name	86
Saving and Exiting EDIT Status	87
Automatic Test Page View	88
Running an Automatic Test	91
Automatic Test Results	



Menu Tree

This section describes the overall structure of the operation statuses and modes for the GPT-9000/9000A safety testers. The testers have two main testing modes (MANU, AUTO) and 5 main operation statuses (VIEW, EDIT, READY, TEST and STOP).



- 1 Press EDIT/SAVE to save settings, or ESC to cancel and return to the previous screen.
- 2 Press the STOP key twice for a FAIL result.
- 3 When in MANU mode, selecting MANU number 000 will enter the special manual mode.
- 4 The Sweep mode function is only accessible in the special manual mode.

Menu Tree Overview


VIEW status

VIEW status is used to view the parameters of the selected manual test/automatic test. The VIEW status is also used to put the tester into MANU or AUTO mode.




EDIT status

EDIT status is used to edit the manual test or automatic test parameters. Pressing the EDIT/SAVE key will save any changes. Pressing the ESC key will cancel any changes.



READY status

When the tester is in READY status, it is ready to begin testing. Pressing the START button will begin testing and put the tester into TEST status. Pressing the MANU/AUTO key will return the tester to VIEW status.





TEST status

TEST status is active when a MANU test or AUTO test is running. Pressing STOP will cancel the MANU test or the remaining steps in an AUTO test.



STOP status

STOP status is shown when a manual test or automatic test did not finish running and has been stopped by the operator. Pressing STOP will return the tester to READY status.




Page View

Up to 16 tests can be used to create an automatic test. Page View is used to see which manual tests (steps) an automatic test is composed of. The steps can be re-arranged and deleted in Page View.


AUTO mode

AUTO indicates that the tester is in AUTO mode. AUTO mode is for creating/running a sequence of up to 16 MANU tests.



MANU mode

MANU mode is used to create and/or execute a single test. MANU indicates that the manual test mode is active.



Common Utility Settings

This utility controls the LCD, buzzer, interface and control settings. These settings are system wide.



MANU Utility Settings

The Manu Utility settings are configured for each MANU test separately. The settings include: ARC MODE, PASS HOLD, FAIL MODE, MAX HOLD and GROUND MODE.

```
MANU=***-002 MANU UTILITY
ARC MODE:OFF
PASS HODE:OFF
FAIL MODE:STOP
MAX HOLD:OFF
GROUND MODE:ON
```



Test Lead Connection


This section describes how to connect the GPT-9000/GPT-9000A to a DUT for withstanding, insulation resistance or ground bond testing.

ACW, DCW, IR Connection

Background


ACW, DCW and IR tests use the HIGH VOLTAGE terminal and RETURN terminal with the GHT-114 test leads.

ACW, DCW, IR Connection



Steps

- 1. Turn the power off on the safety tester.
- 2. Connect the high voltage test lead(red) to the HIGH VOLTAGE terminal and screw firmly into place.
- Connect the return test lead(white) into the RETURN terminal and screw the protector bar into place, as shown below.






GB Connection

Background


GB tests use the SENSE H/L and SOURCE H/L terminals with the GTL-115 test leads.

GB Connection



Steps

- 1. Turn the power off on the safety tester.
- 2. Connect the Sense H lead to the SENSE H terminal.
- 3. Connect the Sense L lead to the SENSE L terminal.
- 4. Connect the Source H lead to the SOURCE H terminal.
- 5. Connect the Source L lead to the SOURCE L terminal.





ACW, DCW, IR and GB Manual Testing

This section describes how to create, edit and run a *single* ACW, DCW, IR or GB safety test. Each Manual setting described in this chapter *only applies to the selected* manual test – *no other manual tests are affected*.

Each manual test can be stored/recalled to/from one of 100 memory locations. Each stored manual test can be used as a test step when creating an AUTO test (page 82).

- Choose/Recall a Manual Test number → from page 39.
- Edit Manual Test Settings → from page 40.
- Setting the Test Function→ from page 41.
- Setting the Test Voltage or Test Current→ from page 42.
- Setting the Test Frequency → from page 43.
- Setting the Upper and Lower Limits → from page 44.
- Setting a Reference Value → from page 46.
- Setting the Test Time (Timer) → from page 47.
- Setting the Ramp Up Time → from page 50.
- Creating a MANU Test File Name→ from page 51.
- Setting the ARC Mode → from page 52.
- Setting PASS HOLD→ from page 55.
- Setting FAIL MODE→ from page 56.
- Setting MAX HOLD→ from page 57.
- Setting the Grounding Mode → from page 58.
- Saving and Exiting EDIT Status→ from page 63.
- Running a MANU Test → from page 64.
- PASS / FAIL MANU Test → from page 69.
- Zeroing of the Test Leads (GB only) → from page 74
- Special MANU Test Mode (000) → from page 77

Before operating the GPT-9000/9000A please read the safety precautions as outlined in the Set Up chapter on page 23.

Choose/Recall a Manual Test Number

Background

ACW, DCW, IR and GB tests can only be created in the MANU (manual) mode. MANU number 001 to 100 can be saved and thus be loaded when editing/creating a MANU test or AUTO test. MANU number 000 is a special mode. See page 74 for details on the special mode.

Steps

 If the tester is in AUTO mode, press and hold the MANU/AUTO key for three seconds to switch to MANU mode.



The tester can only switch between AUTO and MANU mode when in the VIEW status.



Use the scroll wheel to choose the MANU number.



MANU # 001~100 (MANU# 000 is a special mode)

MANU number







The MANU number can only be chosen in VIEW status. If in the EDIT status, switch to the VIEW status by pressing the EDIT/SAVE or ESC key.

Edit Manual Test Settings


Background

To edit any of the manual test settings, the tester must be in EDIT status.

Any settings or parameters that are edited only apply to the currently selected MANU number.

Steps

1. Press the EDIT/SAVE key when in VIEW status to enter the EDIT status. This will enter the EDIT status for the chosen test number.



2. The Status changes from VIEW to EDIT.



Pressing the EDIT/SAVE key again will save the settings for the current test and return back to VIEW status.



Setting the Test Function

Background

After a MANU number has been chosen and the tester is in EDIT status, a test function can be set.

There are four test functions, AC Withstand, DC Withstand, Insulation Resistance and Ground Bond.

Steps

1. To choose the test function, press the ACW, DCW, IR or GB soft-keys.



2. The test function soft-key is highlighted.





The chosen test function only applies to the current test.



Setting the Test Voltage or Test Current

Background

The test voltage can be set from 0.050kV to 5kV for ACW, 0.050kV to 6kV for DCW and 0.050 to 1kV for IR (50V steps*). For GB tests the test current can be set from 3A to 30A (GPT-98XX) or 3A to 32A (GPT-99XX).
*GPT-99XX/GPT-99XXA includes a 125V test point.

Steps

1. Press the UP / DOWN arrow keys to bring the cursor to the voltage setting.





2. Use the scroll wheel to set the voltage level.

ACW



 $\begin{array}{ll} \mbox{DCW} & 0.050 \mbox{kV} \sim 6 \mbox{kV}^2 \\ \mbox{IR} & 0.05 \mbox{kV} \sim 1 \mbox{kV} \ (50 \mbox{V steps})^3 \\ \mbox{GB} & 3.00 \mbox{A} \sim 33.00 \mbox{A} \ (\mbox{GPT-98XX}) \end{array}$

0.050kV ~ 5kV 1

3.00A~ 33.00A (GPT-99XX)

- ¹ At least 0.5 seconds is needed to reach a set voltage of 50V/10mA.
- ² At least 0.5 seconds is needed to reach a set voltage of 50V/2mA.
- ³ GPT-99XX/99XXA includes a 125V test point.





When setting the voltage, be aware that a maximum of 200VA can be set for ACW and 50W for DCW (GPT-98XX) or 500VA and 100W, respectively for GPT-99XX/99XXA.

The ground bond voltage (GBV) is calculated as the HI SET limit x Test Current.

Setting the Test Frequency

Background

A test frequency of 60Hz or 50Hz can be set, regardless of the input line voltage. The test frequency setting only applies to ACW and GB tests.

Steps

1. Press the UP / DOWN arrow keys to bring the cursor to the FREQ setting.





2. Use the scroll wheel to set the test frequency.



ACW, GB 50Hz, 60Hz



The test frequency can only be set for ACW or GB tests.



Setting the Upper and Lower Limits


Background

There is both a LO and HI judgment setting. When the measured value is below the LO SET setting, the test will be judged as FAIL. When the value exceeds the HI SET setting the test will be judged as FAIL. Any measurement between the LO SET and HI SET setting is judged as PASS. The LO SET limit cannot be made greater than the HI SET limit.

Steps

1. Press the HI/LO soft-key or use the UP / DOWN arrow keys to bring the cursor to the HI SET (ACW/DCW/GB) setting or the LO SET(IR) setting.






2. Use the scroll wheel to set the HI SET/LO SET limit*.



- ACW (HI) 0.001mA~042.0mA (GPT-98XX) 0.001mA~110.0mA (GPT-99XX/ 99XXA)
- DCW (HI) 0.001mA~011.0mA (GPT-98XX) 0.001mA~021.0mA (GPT-99XX/ 99XXA)
- IR (LO) $0001 \text{M}\Omega \sim 9999 \text{M}\Omega \text{ (GPT-98XX)} \\ 0.001 \text{G}\Omega \sim 50.00 \text{G}\Omega \text{ (GPT-99XX/} \\ 99XXA)$
- GB (HI) $000.1\text{m}\Omega \sim 650.0\text{m}\Omega$

 Press the HI/LO soft-key again or press the DOWN arrow key to switch between HI SET and LO SET.





4. Use the scroll wheel to set the HI SET/LO SET limit*.



 $\begin{array}{lll} \mbox{ACW (LO)} & 0.000 \mbox{mA} {\sim} 041.9 \mbox{mA (GPT-98XX)} \\ & 0.000 \mbox{mA} {\sim} 109.9 \mbox{mA (GPT-99XX/} \\ & 99XXA) \\ \mbox{DCW (LO)} & 0.000 \mbox{mA} {\sim} 010.9 \mbox{mA (GPT-98XX)} \\ & 0.000 \mbox{mA} {\sim} 020.9 \mbox{mA (GPT-99XX/} \\ & 99XXA) \\ \mbox{IR (HI)} & 0001 \mbox{M} \mbox{Ω} {\sim} 99999 \mbox{M} \mbox{Ω}, \, \infty \mbox{(GPT-98XX)} \\ & 0.001 \mbox{G} \mbox{Ω} {\sim} 50.00 \mbox{G} \mbox{Ω}, \, \infty \mbox{(GPT-99XX/} \\ & 99XXA) \\ \mbox{GB (LO)} & 000.0 \mbox{m} \mbox{Ω} {\sim} 649.9 \mbox{m} \mbox{Ω} \end{array}$



*Please note that the resolution of the measured value depends on the resolution of HI SET setting.



The LO SET setting is limited by the HI SET setting. The LO SET limit cannot be greater than the HI SET limit.

When setting the current, be aware that a maximum of 200VA can be set for ACW and 50W for DCW (GPT-98XX) or 500VA and 100W, respectively for GPT-99XX/99XXA.



Setting a Reference Value

Background

The REF# acts as an offset. The REF# value is subtracted from the measured current (ACW, DCW) or measured resistance (IR, GB).

Steps

 Press the UP / DOWN arrow keys to bring the cursor to the REF# setting.





2. Use the scroll wheel to set the REF# value.



 $\begin{array}{lll} \mbox{ACW} & 0.000\mbox{mA}{\sim}\mbox{HI SET current-}0.1\mbox{mA} \\ \mbox{DCW} & 0.000\mbox{mA}{\sim}\mbox{HI SET current-}0.1\mbox{mA} \\ \mbox{IR} & 0000\mbox{M}\Omega{\sim}\mbox{HI SET}\Omega{-}1\mbox{M}\Omega \\ \mbox{GB} & 000.0\mbox{m}\Omega{\sim}\mbox{HI SET}\Omega{-}0.1\mbox{m}\Omega \end{array}$




For GB tests, a reference offset can be automatically created using the zeroing function. See page 74 for details.

Setting the Test Time (Timer)

Background

The TIMER setting is used to set the test time for the current test. The test time determines how long the test voltage or current is applied to the DUT. This test time does not include Ramp /, initial start time or discharge time (note: GB does not have Ramp / or discharge times). The test time can be set from 0.5 seconds to 999.9 seconds for ACW, DCW and GB and 1.0 second to 999.9 seconds for IR, with a resolution of 0.1 seconds for all modes. The timer can be turned off when in the special MANU test mode when using the ACW or DCW test functions.

Each test has an initial test time of approximately 150ms and a discharge time (except GB). The total discharge time depends on the DUT and test voltage.



Steps

 Press the TIMER soft-key or use the UP/DOWN arrow keys to bring the cursor to the TIMER setting.







cursor

2. Use the scroll wheel to set the TIMER value.



ACW	000.5s~999.9s
DCW	000.5s~999.9s
IR	001.0s~999.9s
GB	000.5s~999.9s



With the ACW test function, when the test current is between 30mA and 40mA (GPT-98XX) or 80mA and 100mA (GPT-99XX/99XXA), the ramp time + test time cannot exceed 240 seconds. At this current level, the tester also needs to pause after a test for a time equal to or greater than the output time. See the specifications on page 170 for details.

Special Manual Mode

When in special MANU test mode (page 74) the Timer can be turned off when using the DCW or ACW test function.

Hold the TIMER soft-key for 3 seconds to turn the timer off.





The timer can only be turned off under special MANU test mode, however there is a limitation: The timer cannot be turned off (limited to 240s) if the test current is between 30mA and 40mA (GPT-98XX) or 80mA and 100mA (GPT-99XX/99XXA) in ACW mode.


The discharge time and initial test time cannot be edited.



Setting the Ramp Up Time

Background

The Ramp Up time is the total time taken for the tester to reach the test voltage level. The Ramp Up time starts after the initial time (approximately 150ms) with a start voltage of 50 volts. The Ramp Up time can be set from 000.1 to 999.9 seconds. The Ramp Up time is only applicable for ACW, DCW and IR tests.



Steps

 Use the UP/DOWN arrow keys to bring the cursor to the RAMP / setting.





2. Use the scroll wheel to set the RAMP / value.



ACW	000.1s~999.9s
DCW	000.1s~999.9s
IR	000.1s~999.9s



The discharge time and initial test time cannot be edited.

Creating a MANU Test File Name

Background

Each manual test can have a user-defined test file name (default: MANU_NAME) up to 10 characters long. See the character list below for the allowed characters.

Character List

0								-																	
Α	В	С	D	Ε	F	G	Н	Ι	J	K	L	M	Ν	0	Р	Q	R	S	Т	U	٧	W	Х	Υ	Z
а																q	r	s	t	u	٧	w	х	У	z
+	-	*	/		=	:	Ω	?	()	<	>	[]											

Steps

1. Use the UP/DOWN arrow keys to bring the cursor to the MANU test file name at the top of the screen. The test file name is initially set as MANU_NAME.





2. Use the scroll wheel to scroll through the available characters.



- 3. Press the Left/Right arrow keys to go the next character.
- 4. The MANU test file name is set when the current test setting is saved or when the cursor is moved to another setting.



Setting the ARC Mode

Background

ARC detection, otherwise known as flashover detection, detects fast voltage or current transients that are not normally detected. Arcing is usually an indicator of poor withstanding insulation, electrode gaps or other insulating problems that cause temporary spikes in current or voltage during ACW and DCW testing.

There are three ARC detection settings: OFF, ON AND CONTINUE, ON AND STOP.
The ON AND CONTINUE setting will detect arcs over the ARC current level and continue the test, the ON AND STOP setting will stop the test when an arc is detected.

ARC mode settings only apply to ACW and DCW tests.

Steps

1. Press the UTILITY key on the front panel when the tester is in EDIT status. The tester will go to the MANU Utility for the *current test*.



MANU='''-002 MANU UTILITY

ARC MODE: OFF

FAIL MODE: STOP

MAX HOLD: OFF

GROUND MODE: ON



The MANU UTILITY settings only apply to the selected MANU test.

Use the UP/DOWN arrow keys to move to the ARC MODE setting.



3. Use the scroll wheel to set the ARC mode.



ARC MODES: OFF, ON AND CONTINUE, ON AND STOP

4. Press the EDIT/SAVE key to save and exit the MANU Utility and go back to EDIT status.







The ESC key can be pressed at any time in the Utility menu to cancel and exit.

- 5. If the ARC MODE was set to either ON AND CONTINUE, or ON AND STOP, the ARC current level can be edited.
- 6. Use the UP/DOWN arrow keys to move the cursor to the ARC setting.



7. Use the scroll wheel to edit the ARC level.



GPT-98XX:

ACW	1.000mA~080.0mA
DCW	1.000mA~020.0mA

GPT-99XX/99XXA:

ACW	2.000mA~200.0mA
DCW	2.000mA~040.0mA





The ARC setting range is directly related to the HI SET current limit.

ACW: GPT-98XX

HI SET Limit	ARC Range
0.001mA~1.100mA	1.000mA ~2.000mA
01.11mA~11.00mA	01.00mA ~20.00mA
011.1mA~042.0mA	001.0mA ~080.0mA

ACW: GPT-99XX/99XXA

HI SET Limit	ARC Range
0.001mA~1.100mA	2.000mA
01.11mA~11.00mA	02.00mA ~20.00mA
011.1mA~110.0mA	002.0mA ~200.0mA

DCW: GPT-98XX

HI SET Limit	ARC Range
0.001mA~1.100mA	1.000mA ~2.000mA
01.11mA~11.00mA	01.00mA ~20.00mA

DCW: GPT-99XX/99XXA

HI SET Limit	ARC Range
0.001mA~1.100mA	2.000mA
01.11mA~11.00mA	02.00mA ~20.00mA
011.1mA~021.0mA	002.0mA ~040.0mA

Setting PASS HOLD

Background	The PASS HOLD settings only apply to the selected test in an AUTO test. When the PASS HOLD setting is set to ON, a PASS judgment is held until the START button is pressed.
Note	The PASS HOLD setting only applies to AUTC tests. This setting is ignored when running <i>a single</i> MANU test.
Steps	1. Press the UTILITY key on the front panel when the tester is in EDIT status. The display will go from the normal EDIT status to the MANU Utility menu for <i>the current test</i> .
	MANU=***-002 MANU UTILITY ARC MODE:OFF PASS HOLD:OFF FAIL MODE:STOP MAX HOLD:OFF GROUND MODE:ON
Note	The MANU UTILITY settings only apply to the selected MANU test.
	2. Use the UP/DOWN arrow keys to move to the PASS HOLD setting. ▼
	3. Use the scroll wheel to set PASS HOLD.
	PASS HOLD OFF, ON
	4. Press the EDIT/SAVE key to save and exit the MANU Utility menu.





The ESC key can be pressed at any time in the MANU Utility menu to cancel and exit.

Setting FAIL MODE

Background

The FAIL MODE settings only apply to the selected test in AUTO tests.

FAIL MODE has three options, CONTINUE, HOLD and STOP.

When FAIL MODE is set to CONTINUE the tester will continue testing after a FAIL judgment.

When set to HOLD, the tester will hold the test on a FAIL judgment, and then continue testing after the START key is pressed.

The STOP mode will completely stop the test after a FAIL judgment.



The FAIL MODE setting only applies to AUTO tests. This setting is ignored when running MANU tests.

UTILITY

Steps

 Press the UTILITY key on the front panel when the tester is in MANU/EDIT status. The display will go from the normal EDIT status to the MANU Utility menu for the current test.

MANU=***-002 MANU UTILITY
ARC MODE:OFF
PASS HOLD:OFF
FAIL MODE:STOP
MAX HOLD:OFF
GROUND MODE:ON

2. Use the UP/DOWN arrow keys to move to the FAIL MODE setting.



3. Use the scroll wheel to set FAIL MODE.



FAIL MODE CONTINUE, HOLD, STOP

4. Press the EDIT/SAVE key to save and exit the MANU Utility menu.





The ESC key can be pressed at any time in the MANU Utility menu to cancel and exit.

Setting MAX HOLD

Background

The MAX HOLD setting will hold the maximum current measured in the ACW and DCW tests or the maximum resistance measured in IR and GB tests.

Steps

1. Press the UTILITY key on the front panel when the tester is in EDIT status. The display will go from the normal EDIT status to the MANU Utility menu for *the current test*.



MANU=***-002 MANU UTILITY
ARC MODE:OFF
PASS HOLD:OFF
FAIL MODE:STOP
MAX HOLD:OFF
GROUND MODE:ON



The MANU UTILITY settings only apply to the selected MANU test.



2. Use the UP/DOWN arrow keys to move to the MAX HOLD setting.



3. Use the scroll wheel to set MAX HOLD.



MAX HOLD OFF, ON

4. Press the EDIT/SAVE key to save and exit the MANU Utility menu.





The ESC key can be pressed at any time in the MANU Utility menu to cancel and exit.

Setting the Grounding Mode

Background

When GROUND MODE is set to ON, the GPT-9000/9000A grounds the return terminal to the ground. This mode is best for DUTs that are grounded to an earth ground by their chassis, fixtures or operation environment. This mode measures the potential of the HIGH VOLTAGE terminal with respect to earth ground. This means that any stray capacitance/resistance that leaks to earth ground will also be measured. This is the safest testing mode, though potentially not as accurate.

When GROUND MODE is set to OFF, the return terminal is floating with respect to the earth ground. This mode is for DUTs that are floating and not directly connected to an earth ground. This is more accurate than when GROUND MODE is set to ON as any stray capacitance/resistance that leaks to the earth




ground from the DUT side of the testing circuit will not be measured. For this reason, this testing mode is able to measure to a higher resolution.

The GROUND MODE is always set to OFF for IR and GB tests.


GROUND MODE = ON, DUT grounded

GPT-9000/9000A



GROUND MODE = ON, DUT floating


GPT-9000/9000A






GROUND MODE = OFF, DUT floating

GPT-9000/9000A




GPT-9804/9904 (GB testing)




GROUND MODE = OFF, DUT grounded

GPT-9000/9000A



GPT-9804/9904 (GB testing)





When GROUND MODE is set to OFF, the DUT, fixtures or connected instrumentation cannot be grounded. This will short circuit the internal circuitry during a test.

For ACW and DCW tests, if it is not known whether the DUT test setup is grounded or not, always set GROUND MODE to ON.

Only set GROUND MODE to OFF when the DUT is floating electrically.

Steps

1. Press the UTILITY key on the front panel when the tester is in EDIT status. The display will go from the normal EDIT status to the MANU Utility menu for *the current test*.



MANU=***-002 MANU UTILITY
ARC MODE:OFF
PASS HOLD:OFF
FAIL MODE:STOP
MAX HOLD:OFF
GROUND MODE:ON



The MANU UTILITY settings only apply to the selected MANU test.

2. Use the UP/DOWN arrow keys to move the cursor to the GROUND MODE setting.



▼

3. Use the scroll wheel to set the GROUND MODE.



GROUND MODE OFF, ON

4. Press the EDIT/SAVE key to save and exit the MANU Utility menu.





5. The GROUND MODE icon on the display changes accordingly.





The ESC key can be pressed at any time in the MANU Utility menu to cancel and exit.

IR and GB tests can only have GROUND MODE set to OFF.




Saving and Exiting EDIT Status

Background	After all test parameters have been set, the test
· ·	can be saved. After a test is saved it can be used
	when creating an AUTO test.

The special MANU number, 000, can be saved, however it cannot be used for AUTO tests. See page 74 for details.

1. When in EDIT status, press the EDIT/SAVE key to save the current test. This will enter the VIEW status for the chosen test number.





2. The Status changes from EDIT to VIEW.



Steps

Pressing the EDIT/SAVE key again will return the tester back to EDIT status for the current test.



Running a MANU Test

Background A test can be run when the tester is in READY status. The tester cannot start to run a test under the following conditions: • A protection setting has been tripped; when a protection setting has been tripped the corresponding error message is displayed on the screen. See page Error! Bookmark not **defined.** for a comprehensive list of the all the setting errors. The INTERLOCK function is ON and the Interlock key is not inserted in the signal I/O port (page 103). The STOP signal has been received remotely. If Double Action is ON, ensure the START button is pressed immediately after the STOP button (<0.5s). When a test is running the voltage output cannot be changed, unless the test is under the

Steps


1. Ensure the tester is in VIEW status Page 63 for the current test. Save the current test if necessary.

special manual mode. See page 74 for details.



2. Press the STOP button to put the tester into the READY status.





3. The READY indicator will be lit blue when in the READY status.



 Press the START button when the tester is in the READY status. The manual test starts automatically and the tester goes into the TEST status.




5. The TEST indicator will be lit orange when in the TEST status.









The test will start by showing the remaining ramp up time, followed by the remaining test time. The test will continue until the test is finished or the test is stopped.




ACW Example



DCW Example




IR Example





GB Example



Stop the Test

 To stop the test at any time when it is running, press the STOP button. The test will stop immediately. When the STOP button is pressed, a judgment is not made on the test.



All panel keys except the STOP button are locked when the tester is in STOP status.



To put the tester back into READY status, press the STOP button again.



Exit TEST Status

To exit testing, press the MANU/AUTO key when the tester is in the READY status. The tester will revert to the VIEW status for the current test.









Do not touch any terminals, test leads or any other connections when the test is on.

PASS / FAIL MANU Test

Background

If the test is allowed to run to completion (the test is not stopped or a protection setting is not tripped) then the tester will judge the test as either PASS or FAIL.



The test will be judged PASS when:

• The HI SET and LO SET limits have not been tripped during the test time.

The test will be judged FAIL when:

- Either the HI SET or LO SET limit has been tripped during the test time.
- A protection setting has been tripped during the test time. See page Error! Bookmark not defined. for a list of error messages.

PASS Judgment

 When the test is judged as PASS, PASS will be displayed, the buzzer will sound and the PASS indicator will be lit green.





2. The PASS judgment will be held on the display until the STOP or START button is pressed.

Pressing the STOP button will return the tester to the READY status.





Pressing the START button will restart the test.






The buzzer will only sound if the Pass Sound is set to ON. See page 100 for details.

The START button is disabled when the buzzer is beeping.


PASS Timing Diagrams

The timing diagrams below show the ACW, DCW, IR and GB timing for the START status, TEST status and PASS judgment.

ACW PASS Timing




DCW PASS Timing






IR PASS Timing



GB PASS Timing



FAIL Judgment

1. When the test is judged as FAIL, FAIL will be displayed, the buzzer will sound and the FAIL indicator will be lit red.



As soon as a test is judged FAIL, power is cut from the terminals.



2. The FAIL judgment will be held on the display until the STOP button is pressed. Pressing the STOP button twice will return the tester to the READY status.





3. The READY indicator will be lit blue in the READY status.






Note

The buzzer will only sound if Fail Sound is set to ON. See page 100 for details.


FAIL Timing Diagrams

The timing diagrams below show the ACW, DCW, IR and GB timing for the START status, TEST status and FAIL judgment.

ACW FAIL Timing




DCW FAIL Timing






IR FAIL Timing



GB FAIL Timing





Zeroing of the Test Leads (GB only)

Background

The Zeroing function is used to determine the resistance of the test leads for GB tests. When a zero check is performed, the reference is automatically set to the measured resistance of the test leads.


This function is only available for GB testing.

Steps

1. Ensure the tester is in VIEW status Page 63 for the current GB test. Save the current test if necessary.



2. Short the positive and negative alligator clips as shown below.



3. Press the STOP button to put the tester into the READY status.




4. The ZERO function can be activated by pressing the corresponding soft-key in the READY status. The ZERO soft-key will be highlighted.




5. Press the START button to perform the zero check. The tester will go into the ZERO status.





6. When the zero check has finished, the tester will return back to the VIEW status. The resistance of the test leads will be automatically set as the Reference value.






Remember to replace the test leads to the proper position on the DUT before testing.




I<SET

If SOURCE H/L terminals are open or poorly connected, then an I<SET error will appear on the screen. Stop the test and re-check the connection again and try again.



R = 0 Stop the test and perform the zero check again.



Special MANU Test Mode (000)

Special Test Mode Overview

When MANU number 000 is selected, the special test mode is activated. Under the special test mode, the voltage can be changed during a test, in real time (ACW, DCW only). The test function can also be changed when in READY or VIEW status, unlike under normal operation.


Separate settings can be saved under the special test mode for each of the testing functions: ACW, DCW, IR and GB. This means a different ACW, DCW, IR and GB test setup can be saved for MANU number 000.

Sweep Function Overview

The GPT-9901A/9902A/9903/9903A and 9904 have access to the sweep mode function. The sweep function creates a graph of one of the ACW, DCW, IR or GB tests in the special manual mode. The graph will plot the output voltage, current or resistance versus time. After the test has been completed, the test current, voltage or resistance at any point in time can be viewed in the graph.

Below is an example of the resultant sweep plot of a DCW test where a DC voltage is ramped up to a user-defined level until the HI SET current level has been tripped or the test time runs out.





The test items that are plotted on the sweep graph depend on the type of test that is performed.

TEST Graph Test Items

ACW: Test voltage, measured current (V, I)

DCW: Test voltage, measured current (V, I)

IR: Test voltage, measured resistance (V, R)

GB: Test current, measured resistance (I, R)

Page 39

Steps

- 1. Choose MANU number 000 to enter the special test mode.
- 2. The settings of a previous test can be loaded by pressing the corresponding soft-key in the VIEW or READY status.

 ACW

 Example:

 ACW

For example, if you are currently in DCW mode, pressing the ACW key will load the ACW settings that were previously used in the special manual mode.



3. Set all the necessary parameters for Pages 40~63 a test and save.

Note: A different test setup can be saved for each test function (ACW, DCW, IR and GB).



GPT-99XX/99XXA shown.



The TIMER settings can be set OFF when in the special test mode for ACW and DCW tests.

If the TIMER settings are set to OFF, the sweep function will not produce a graph.

Start Time

Setting the Sweep 1. When in the VIEW status, press the STALL STA.t key and set the starting time for the sweep graph. Make sure that the sweep start time is significantly less than the test time. This setting is only applicable for the GPT-9901A/9902A/9903/ 9903A/9904.



2. Press the EDIT/SAVE key to save the Start time.





- Running the Test 1. In special test mode (000), tests are Page 64 started and stopped in the same way as for the normal manual test mode. See page 64 for details.
 - 2. If required, the scroll wheel can be used to set the voltage level in realtime as the test is running (this does not apply to IR or GB tests).



ACW	$0.050 \text{kV} \sim 5 \text{kV}$
DCW	0.050kV ~ 6kV

Results

Test judgments are the same as Page 69 those for the normal manual tests. Please see the PASS/FAIL MANU Test section for details.

View Sweep Graph

Unlike normal manual tests, the special test mode also has an option to view the resultant test as a sweep graph.


This option is only available for the GPT-9901A/9902A/9903/9903A/9904.

Steps

SWEEP 1. When the test has finished, press the SWEEP key to view the results of the sweep in a graph.

	Graph Test Items:	
TEST	Primary	Secondary
ACW	Test voltage	test current
DCW	Test voltage	test current
IR	Test voltage	test resistance
GB	Test current	test resistance

DCW Example




2. Use the scroll wheel to move the cursor on the time axis (x-axis). The measured values for the primary and secondary items at that particular point in time are shown on the left-hand side.



Remove Lines from the Graph

- 1. Pressing the F5 key will toggle the primary test item on/off.
- 2. Pressing the F6 key will toggle the secondary test item on/off.



Exit the Results Graph

To exit the graph, press the ESC key. You will be returned back to MANU mode/VIEW status.





Automatic Tests

This section describes how to create, edit and run automatic tests. Automatic tests allow you to link together up to 16 different MANU tests and run them sequentially. Each stored MANU test is used as a test step when creating an AUTO test.

- Choose/Recall an Automatic Test→ from page 82
- Edit Automatic Test Settings → from page 84
- Adding a Step to the Automatic Test → from page 85
- Creating an AUTO Test File Name → from page 86
- Saving and Exiting EDIT Status → from page 87
- Automatic Test Page View → from page 88
- Running an Automatic Test → from page 91
- Automatic Test Results → from page 95

Before operating the GPT-9000/9000A please read the safety precautions as outlined in the Set Up chapter on page 23.

Choose/Recall an Automatic Test

Background	The tester must first be put into AUTO mode to create or run automatic tests. Up to 100 automatic tests can saved/recalled.					
Steps	. If the tester is in MANU mode, press and hold the MANU/AUTO key for three seconds. This will put the tester into Auto mode.					
	The tester can only switch between AUTO and MANU mode when in the VIEW status.					







If the chosen automatic test has not yet been setup, then the screen will be blank except for the status and mode.



2. Use the scroll wheel to choose the AUTO number.



AUTO # 001~100







The AUTO number can only be chosen in VIEW status. If in the EDIT status, switch to the VIEW status by pressing the EDIT/SAVE or ESC key.



Edit Automatic Test Settings

Background

To edit an automatic test, the tester must be in EDIT status.

Any settings or parameters that are edited only apply to the currently selected AUTO number.

Steps

1. Press the EDIT/SAVE key when in VIEW status to enter the EDIT status. This will enter the EDIT status for the chosen AUTO number.





2. The Status changes from VIEW to EDIT. The tester is now ready to edit the current AUTO test.



Pressing the EDIT/SAVE key again will save the settings or pressing the ESC will cancel the settings for the current AUTO test and return back to VIEW status.

Adding a Step to the Automatic Test


Background

Up to 16 MANU tests (steps) can be added to an automatic (AUTO) test. Each step is added in a sequential order.

Steps

 Press the DOWN arrow keys to bring the cursor to the MANU number.





Use the scroll wheel to choose a MANU number to add to the automatic test.



MANU number 001~100

Press the ADD soft-key to add the selected manual test to the automatic test as another step.



4. Repeat steps 2 and 3 for any other tests that you wish to add to the automatic test.



After 16 steps have been added to an AUTO test, FULL will be shown on the display when you attempt to add another step to the AUTO test.







The test order can be edited in the Page View menu after the AUTO test is saved. See page 88 for details.

Creating an AUTO Test File Name

Background

Each automatic test can have a user-defined test file name (Default: AUTO_NAME) up to 10 characters long. See the character list below for the allowed characters.


Character List

0	1	2	3	4	5	6	7	8	9																
Α	В	С	D	Е	F	G	Н	I	J	K	L	M	Ν	0	Р	Q	R	S	Т	U	٧	W	Χ	Υ	Z
а	b	С	d	е	f	g	h	i	j	k	T	m	n	o	р	q	r	s	t	u	v	w	х	У	z
+	-	*	/		=	:	Ω	?	()	<	>	[]											_

Steps

1. Use the UP/DOWN arrow keys to bring the cursor to the AUTO number. A small cursor will also appear under the first character of the AUTO test file name. This is initially set as AUTO_NAME





2. Use the scroll wheel to scroll through the available characters.



3. Press the LEFT/RIGHT arrow keys
to go to the next character.



4. The AUTO test file name is set when the current AUTO test is saved or when the cursor is moved to another setting.



To cancel the name changes, press the ESC key before the cursor is moved to another setting or the name is saved.

Saving and Exiting EDIT Status

Background

After all test steps have been added to an automatic test, the automatic test can be saved.

Steps

1. When in EDIT status, press the EDIT/SAVE key to save the automatic test. After the test is saved the tester will revert back to VIEW status.





2. The status changes from EDIT to VIEW.



Pressing the EDIT/SAVE key again will return the tester back to EDIT status for the selected AUTO test.




Automatic Test Page View

Background

Pressing the PAGE key will show an overview of the tests for the currently selected automatic test when in the VIEW status. The Page View will show the order of the AUTO test steps as well as the manual file name, function, test voltage/current and HI/LO SET limits.

Steps


 Ensure the tester has had an automatic test saved and the tester is in AUTO mode/VIEW status.



2. Press the PAGE key to bring up the (Page view of the AUTO test.



All the test steps are shown on the bottom of the screen along with the corresponding MANU numbers. The top of the screen shows the selected MANU test file name and the settings (test function, test voltage, HI/LO SET).



Editing

When in the Page View, the automatic test steps can be edited. Steps can be deleted, skipped, moved or swapped.

Moving a Step

- 1. Use the UP/DOWN and LEFT/RIGHT arrow keys to move the cursor to the test step you wish to move.
- 2. Press the MOVE soft-key.



- Use the UP/DOWN and LEFT/RIGHT arrow keys to move the cursor to the destination step.
- 4. Press the MOVE soft-key again.

 The manual test will be moved to the destination step. The remaining steps will move up/down to fill the empty step.





Swapping Two Steps

 Use the UP/DOWN and LEFT/RIGHT arrow keys to move the cursor to the test step you wish to swap.



2. Press the SWAP soft-key.



3. Use the UP/DOWN and LEFT/RIGHT arrow keys to move the cursor to the second step.



4. Press the SWAP soft-key again. The tests will be swapped with each other.





Skip a Test Step

 Use the UP/DOWN and LEFT/RIGHT arrow keys to move the cursor to the test step you wish to skip.




2. Press the SKIP soft-key.



3. The step will have an asterisk beside the MANU number.







The next time the automatic test is run, the steps with asterisks will be skipped.



	_
Delete a Test Ste	1. Use the UP/DOWN and LEFT/RIGHT arrow keys to move the cursor to the test step you wish to delete.
	2. Press the DEL soft-key.
	3. The step will be deleted.
Save Changes and Exit	To save the changes made in Page View, press the EDIT/SAVE key. You will be returned back to AUTO mode/VIEW status.
Cancel and Exit Page View	To cancel any changes and to exit the Page View, press the ESC key. You will be returned back to AUTO mode/VIEW status.
Running an Au	utomatic Test
Background	An automatic test can be run when the tester is in READY status.
Note	The tester cannot start to run an AUTO test under the following conditions:
	Any protection modes have been tripped.
	The INTERLOCK function is ON and the Interlock key is not inserted in the signal I/O port (page 113).
	The STOP signal has been received remotely.
	If Double Action is ON, ensure the START




button is pressed immediately after the STOP button (<0.5s).



Do not touch any terminals, test leads or the DUT when a test is running.

Steps

1. Ensure the tester is in VIEW status. Page 82 Save the automatic test if necessary.



2. Press the STOP button to put the tester into the READY status.





- 3. The READY indicator will be lit blue when in the READY status.
- 4. Press the START button when the tester is in the READY status. The AUTO test starts automatically and the display changes to TEST status.



READY

5. The TEST indicator will be lit orange when in the TEST status.



Each test will start by showing the remaining ramp up time, followed by the remaining test time. Each test will be tested in sequence until the last test has finished or the test is stopped.



PASS/FAIL HOLD 1. If Pass Hold is set to ON or Fail Mode is set to HOLD for a manual test, then the tester will "hold" the testing after a Pass/Fail result for that particular test. See page 54, 56 for details.



The PASS or FAIL indicator will also be lit. The buzzer will NOT sound.



To continue to the next test after HOLD is displayed on-screen, press the START button.





To stop the test when HOLD is displayed on-screen, press the STOP button.





When in HOLD status, only the START and STOP buttons can be pressed, all other keys are disabled.

Stop a Running Test To stop the AUTO test at any time when it is running, press the STOP button. The AUTO test will stop immediately. When the STOP button is pressed, a judgment is not made on the current test and any remaining tests are aborted.



All panel keys except the STOP and START buttons are locked when the tester has been stopped. All the results up until when the AUTO test was stopped are shown on-screen. See page 95 for more details on automatic test results.

```
AUTO=001-*** AUTO_NAME
#01:FAIL #02:PASS #03:STOP #04:---
#05:--- #06:--- #07:--- #08:---
#09: #10: #11: #12:
#13: #14: #15: #16:
```

Example of an automatic test that has been stopped. Dashes (-) indicate aborted test steps.

To put the tester back into READY status, press the STOP button again.





Exit Testing

To exit testing, press the MANU/AUTO key when the tester is in the READY status. The tester will revert to the VIEW status for the current automatic test.






Automatic Test Results

Background

If all the test steps are allowed to run to completion (the AUTO test is not stopped or a protection setting is not tripped) then the tester will judge each step as either PASS or FAIL. This is shown as a table after the automatic test has finished running. If the test has been stopped, then any remaining tests will not be run and thus the AUTO test will not finish running.

Overview





The PASS/FAIL judgment for an automatic test as a whole depends on the results of all the steps (manual tests) that compose the automatic test:

· Each step must be passed for a PASS judgment



(excluding skipped tests).

- A FAIL result for a single step will result in FAIL for the whole automatic test.
- A STOP. No step can be stopped for a PASS/FAIL judgment to be made. In other words, if a test is stopped, it is judged as neither PASS nor FAIL.
- No step can contain an ERROR or ILOCK message.



ERROR: Indicates that V, I or R is not correct. This usually occurs if the testing leads are not properly connected.

ILOCK: Indicates that the interlock key is disconnected (if configured to be used).

PASS Judgment

When all the tests have been judged as PASS, the PASS indicator will be lit green and the buzzer will sound.



```
AUTO=001-*** AUTO_NAME
#01:PASS #02:PASS #03:PASS #04:PASS
#05:PASS #06:PASS #07:PASS #08:PASS
#09: #10: #11: #12:
#13: #14: #15: #16:
```



The Pass Sound setting must to set to ON for the buzzer to sound (page 100).

FAIL Judgment

When any of the tests have been judged as FAIL, the FAIL indicator will be lit red and the buzzer will sound.





AUTO = 001 -	* * * AUTO	NAME	
#01:PASS	#02:PASS	#03:PASS	#04:PASS
#05:PASS	#06:FAIL	#07:FAIL	#08:PASS
#09:	#10:	#11:	#12:
#13:	#14:	#15:	#16:




The Fail Sound setting must to set to ON for the buzzer to sound (page 100).

View Results

1. When the PASS or FAIL overview table is shown on the screen, turn the scroll wheel right to scroll through each test step.





2. Turn the scroll wheel left to return back to the overview table.



Return to Ready Status

- 1. The PASS/FAIL results will be held on the screen until the STOP button is pressed.
- 2. To put the tester back into READY status, press the STOP button (twice for a fail result).



3. The READY indicator will be lit blue in the READY status.








Exit Testing

To exit testing, press the MANU/AUTO key when the tester is in the READY status. The tester will revert to the VIEW status.






PASS Timing Diagram



FAIL Timing Diagram



Common Utility Settings

The Common Utility settings are system-wide settings that apply to both MANU tests and AUTO tests.

The Common Utility menu includes the following settings:


- LCD settings → from page 99.
- Buzzer Settings \rightarrow from page 100.
- Interface Settings → from page 102.
- Control settings → from page 103.
- Control1 settings → from page 106.

LCD Settings

Description	The LCD settings include contrast and
	brightness controls.

Steps

1. Ensure the tester is in VIEW status. Page 63 Save the current test if necessary.



2. Press the UTILITY key.



3. Press the LCD soft-key to bring up the LCD Common Utility menu.







4. Use the UP/DOWN arrow keys to choose a menu item: LCD Contrast, LCD Brightness.



5. Use the scroll wheel to select a parameter for the chosen menu item.



LCD Contrast $1(low) \sim 8(high)$ LCD Brightness BRIGHT, DARK

6. Press EDIT/SAVE to save the settings and exit to VIEW status.





The ESC key can be pressed at any time to cancel and exit back to VIEW status.


Buzzer Settings

Description

The Buzzer settings allow you to set whether the buzzer will sound for PASS/FAIL judgments. The buzzer time can also be set for the PASS/FAIL judgments. The buzzer settings are system-wide.

Steps

1. Ensure the tester is in VIEW status. Page 63 Save the current test if necessary.



2. Press the UTILITY key.



3. Press the BUZZ soft-key to bring up the Buzzer Common Utility menu.





4. Use the UP/DOWN arrow keys to choose a menu item: Pass Sound or Fail Sound.





Use the scroll wheel to select a parameter for the chosen menu item.



Pass Sound ON (000.2s~999.9s), OFF Fail Sound ON (000.2s~999.9s), OFF

Press EDIT/SAVE to save the settings and exit to the VIEW status.





When in automatic tests, the Pass Sound and Fail Sound settings only apply to the overall PASS/FAIL of the *overall automatic test*, not each test step that make up the automatic tests.





The ESC key can be pressed at any time to cancel and exit back to VIEW status.


Interface Settings

Description

The interface settings choose the remote interface configuration. USB, RS232 and GPIB (optional) can be selected.

Steps

1. Ensure the tester is in VIEW status. Page 63 Save the current test if necessary.



2. Press the UTILITY key.



Press the INTER soft-key to bring up the Interface Common Utility menu.





4. Use the scroll wheel to select USB, RS232 or GPIB.



5. For RS232 or GPIB, use the UP/DOWN arrow keys to choose Baud or Address.





6. Use the scroll wheel to select the baud rate or GPIB address.



Baud 9600, 19200, 38400, 57600,

115200

GPIB address $0\sim30$

7. Press EDIT/SAVE to save the settings and exit to VIEW status.



!\ Note

Ensure the baud rate settings or GPIB address matches the host machine.



Note

The ESC key can be pressed at any time to cancel and exit back to VIEW status.

Control Settings

Description

The Control settings are accessed in the COMMON UTILITY menu. The Control settings include: Start Control, Double Action, Key Lock and Interlock.

Start Control is used to determine how a test is started. Tests can be started via the front panel (START/STOP buttons), from a remote controller or via the SIGNAL I/O port.

The Double Action function is a safety feature used to prevent accidentally starting a test. Normally to start a test, the START button is pressed when the tester is in the READY status. To start a test when Double Action is ON, the STOP button must first be pressed, followed by the START button within 500ms.



Key Lock disables the front panel keys from changing the test number, mode or testing parameters. Only the Utility menu and any keys required for testing are not disabled.

The Interlock function is a safety feature. The interlock function prevents a test from running, unless the interlock pins on the signal I/O port connector are shorted. The included interlock key can be used for this purpose. See page 113 for details.

Steps

1. Ensure the tester is in VIEW status. Page 63 Save the current test if necessary.



2. Press the UTILITY key.



Press the CTRL soft-key to bring up the Control Common Utility menu.





 Use the UP/DOWN arrow keys to choose a menu item: Start Ctrl, Double Action, Key Lock or INTERLOCK.



5. Use the scroll wheel to select setting for the chosen menu item.



Start Ctrl FRONT PANEL, REMOTE

CONNECT, SIGNAL IO

Double Action ON, OFF
Key Lock ON, OFF
INTERLOCK ON, OFF

Press EDIT/SAVE to save the settings and exit to VIEW status.






The Double Action setting is ignored when the GPT-9000/9000A is being controlled remotely using the USB, RS232 or GPIB interfaces.



If a test is started with INTERLOCK ON, but the interlock signal I/O pins are not shorted (either with the included interlock key or manually), the INTERLOCK OPEN message will be displayed, preventing the test from starting.







Control 1 Settings


Description

The Control1 setting, which is accessed in the COMMON UTILITY menu, currently includes the IR UNIT display function only.

The function toggles the IR unit between the default M/G ohm and the fixed G ohm display, which is suitable for applications of high ohm value measurement.

Steps

1. Ensure the tester is in VIEW status. Page 63 Save the current test if necessary.



2. Press the UTILITY key.



Press the CTRL1 soft-key to bring up the IR UNIT menu in the upper-left corner.





4. Use the scroll wheel to select setting for the IR UNIT.



IR UNIT

ON, OFF



5. Press EDIT/SAVE to save the settings and exit to VIEW status.





When setting ON, IR unit display is fixed in G ohm only, whilst OFF indicates IR unit display is shown in both M and G ohm in accord with measured value.



EXTERNAL CONTROL

The External Control chapter covers the REMOTE terminal and the SIGNAL I/O port.

External Control Overview		109
Remote Terminal Overview	109	
Remote Controller Operation	110	
SIGNAL I/O Overview	111	
Using the SIGNAL I/O to Start/Stop Tests	113	
Using the Interlock Key	114	




External Control Overview

The External Control section describes the front panel REMOTE terminal connection and the rear panel SIGNAL I/O port.

Remote Terminal Overview

Overview	The REMOTE terminal connector is a standard 5-pin DIN terminal suitable for a remote controller.		
(warning	Keep any cables that are connected to the REMOTE terminal away from the HIGH VOLTAGE and RETURN terminals.		

Pin Assignment and Connection



Pin	Pin name	Description	
1	RMT_STOP	Remote Stop signal	
2	COM	Common line	
3	Not used		
4	RMT_START	Remote Start signal	
5	Not used		
Signa	al Properties		
High	level input voltage	2.4V~3.3V	
Low level input voltage		0~0.8V	
Input period		minimum of 1ms	



Remote Controller Operation

Description

The GPT-9000/9000A accepts external remote controllers with a START and STOP button. To use the REMOTE terminal, the

GPT-9000/9000A must first be configured to accept a remote controller.

Operating a remote controller is the same as operating the START and STOP buttons on the front panel.

Steps

 Insert the lead of remote controller into the REMOTE terminal.



 Configure the Start Ctrl option to REMOTE CONNECT in the Common Utility menu.

The tester will now only be able to start a test using a remote controller.



Even if the GPT-9000/9000A is configured to use the REMOTE CONNECT option, the STOP button on the front panel can still be used to stop a test.

4. To return the operation control to Page 103 the front panel, configure the Start Ctrl option to FRONT PANEL.



SIGNAL I/O Overview


Overview

The SIGNAL I/O port can be used to remotely start/stop tests and monitor the test status of the instrument. The SIGNAL I/O port is also used for the interlock function (page 103).

The SIGNAL I/O port uses a DB-9 pin female connector.

Pin Assignment

Pin name




Description

Pin

Pin name	PIII	Description		
INTERLOCK1	1	When INTERLOCK is ON, a test is only allowed		
INTERLOCK2	2	to start when both INTERLOCK pins are shorted.		
INPUT_COM	3	Common input line		
INPUT_START	4	Start signal input		
INPUT_STOP	5	Stop signal input		
OUTPUT_TEST	6	Indicates that a test is in progress		
OUTPUT_FAIL	7	Indicates that a test has failed		
OUTPUT_PASS	8	Indicates that a test has passed		
OUTPUT_COM	9	Common output line		
Interlock connection		PIN 1 INTERLOCK1 PIN 2 INTERLOCK2		
Input Connection	ı	PIN 3 INPUT_COM PIN 4 INPUT_START PIN 5 INPUT_STOP		
		<u> </u>		







Using the SIGNAL I/O to Start/Stop Tests

		_
Background	To use the SIGNAL I/O port the Start Ctrl settings have to be set to SIGNAL I/O in the Common Utility menu.	
Panel operation	 Set the Start Ctrl option to SIGNAL Page 103 I/O. 	
	Connect the Input/Output signals to the SIGNAL I/O port.	
	3. To start the testing, short the INPUT_STOP and INPUT_COM line for a minimum of 1ms to put the tester into READY status.	
	4. To start the testing, short the INPUT_START and INPUT_COM lines for a minimum of 1ms.	
	5. To stop the testing, temporarily short the INPUT_STOP and INPUT_COM line again.	
⚠ NOTE	Even if the GPT-9000/9000A is configured to use the SIGNAL I/O interface, the STOP button on th front panel can still be used to stop a test.	e



Using the Interlock Key

Background

When the INTERLOCK function is set to ON, tests are only allowed to start when both Interlock pins on the signal I/O port are shorted. Using the Interlock key will short the INTERLOCK1 and INTERLOCK2 pins on the signal I/O port.

See page 111 for the Signal I/O pin assignment.

Panel operation

 Insert the Interlock key into the SIGNAL I/O port on the rear panel.



2. Set the INTERLOCK option to ON Page 103 in the Common Utility.

Note

With INTERLOCK set to ON, the tester can now only start a test when the Interlock key is connected. Do not remove the interlock after starting a test. It must be connected after a test has started or is running.

Set INTERLOCK to OFF to disable this feature.



REMOTE CONTROL

This chapter describes basic configuration of IEEE488.2 based remote control. The remote interface supports USB, RS232 and GPIB.

Interface Configuration	116
Command Syntax	120
Command List	123



Interface Configuration

USB Remote Interface

USB PC side Type A, host
Configuration Connector

GPT-9XXX side Rear panel Type A
connector

USB Class CDC (communications device class) (VCP, Virtual Com Port)

Panel operation 1. Connect the USB cable to the rear panel USB A port.



2. Set the interface to USB from the Page 102 Common Utility menu.

Note

When USB is used for remote control, an RS232 port is simulated. Check the Windows Device Manager for the baud rate and other RS232 settings. Check the RS232 configuration below for more details.

Note the baud rate is fixed to 115200 baud when using the USB interface.

RS232 Remote Interface

 RS232
 Connection
 Null modem cable

 Configuration
 Baud rate
 9600, 19200, 38400, 57600, 115200

 Parity
 None

 Data bits
 8



	Stop bit	1		
	Flow control	None		
Pin Assignment	12345	1: No c	onnection	
	$\bigcirc \bigcirc $	② 2: RxD	(Receive Data	1)
	6789	3: TxD	(Transmit Dat	ta)
		4: No c	onnection	
		5: GNE)	
		6-9: No	connection	
Connection	PC	:	Te	ster
Connection	DB9 Pin	Signal	Signal	DB9Pin
	2	RxD	TxD	3
	3	TxD	RxD	2
	5	GND	GND	5
Panel operation	1. Connect the	Null mode	em cable to	RS232

the rear panel RS232 port.

2. Set the interface to RS232 from the Page 102 Common Utility menu.

GPIB Remote Interface

GPIB Configuration	Address 0-30
Panel operation	1. Connect the GPIB cable to the rear panel GPIB port.
	 Set the interface to GPIB and set the GPIB address from the Common Utility menu.



USB/RS232 Remote Control Function Check

Functionality check

Invoke a terminal application such as Hyper Terminal

To check the COM port number and other settings, see the Device Manager in the PC. For WinXP; Control panel \rightarrow System \rightarrow Hardware tab.

Run this query command via the terminal after the instrument has been configured for USB or RS232 remote control (page 116, 116).

*idn?

This should return the Model number, Serial number, and Firmware version in the following format:

GPT-9803, XXXXXXXXXXXXX, V1.00

Model number: GPT-9803

Serial number:12 character serial number

Firmware version: V1.00

 ^j can be used as the terminal character when entering the queries/commands from a terminal application.

Display

GW INSTEK

When the panel is being remotely controlled via the USB, RS232 or GPIB interfaces, RMT will be displayed on the screen.



Return to Panel Control

Background

When the instrument is remotely controlled all panel keys except the STOP button are disabled.

Steps

1. When RMT is on the display, press the STOP button. The panel goes to the READY status.



- From the READY status the tester can go into one of two states: TEST or VIEW.
- To put the tester into VIEW status, press the MANU/AUTO key.



 To put the tester in TEST status, press the START button. This will start the manual test/automatic test. For more details on running a manual test or automatic test, see pages 64 and 91, respectively.





To put the tester back to RMT, simply issue another remote control command.

A single or compound

parameter

MANU:STEP 1

command with/without a



Command Syntax

Compatible	IEEE488.2	Partia	al compatibility
Standard	SCPI, 1999	Partia	al compatibility
Command Structure	SCPI commands follow a tree-like structure, organized into nodes. Each level of the command tree is a node. Each keyword in an SCPI command represents each node in the command tree. Each keyword (node) of an SCPI command is separated by a colon (:). For example, the diagram below shows an SCPI sub-structure and a command example.		
	1	MANU ACW	MANU:ACW:VOLTage
	VOLTage (CHISet	CLOSet
Command types	There are a number of different instrument commands and queries. A command sends instructions or data to the unit and a query receives data or status information from the unit.		
	uiiit.		

Setting

Example



	Query	A query is a simple or compound command followed by a question mark (?). A parameter (data) is returned.		
	Example	MANU:ACW:VOLTage?		
Command Forms	Commands and queries have two different forms, long and short. The command syntax is written with the short form of the command in capitals and the remainder (long form) in lower case.			
	The commands can be written in capitals or lower-case, just so long as the short or long forms are complete. An incomplete command will not be recognized.			
	Below are excommands.	amples of correctly written		
-	Long form	SYSTem:BUZZer:KEYSound SYSTEM:BUZZER:KEYSOUND system:buzzer:keysound		
	Short form	SYST:BUZZ:KEYS syst:buzz:keys		
Command Format	MANU:ST	EP 100 1. Command header 2. Space 3. Parameter		
Parameters	Туре	Description Example		
	<boolean></boolean>	Boolean logic 0, 1		
	<nr1></nr1>	integers 0, 1, 2, 3		
	<nr2></nr2>	decimal 0.1, 3.14, 8.5 numbers		

GPT-9000/9000A Series User Manual

	<nr3> <nrf></nrf></nr3>	floating point 4.5e-1, 8.25e+1
	<string></string>	any of NR1, 2, 3 1, 1.5, 4.5e-1 ASCII text TEST_NAME string
Message Terminator	CR, LF	Carriage Return, Line feed code



Command List

System	SYSTem:LCD:CONTrast	
Commands	SYSTem:LCD:BRIGhtness	
	SYSTem:BUZZer:PSOUND	
	SYSTem:BUZZer:FSOUND	127
	SYSTem:BUZZer:PTIMe	
	SYSTem:BUZZer:FTIMe	128
	SYSTem:ERRor	128
	SYSTem:GPIB:VERSion	129
	SYSTem:CONTrol:IRUNit	130
	SYSTem:CONTrol:INTerlock	130
Function	FUNCtion:TEST	101
Commands	MEASure <x></x>	
Commanus	MAIN:FUNCtion	
	MAIN:FUNCtion	133
Manual	MANU:STEP	135
Commands	MANU:NAME	135
	MANU:INITial	135
	MANU:RTIMe	136
	MANU:EDIT:MODE	136
	MANU:ACW:VOLTage	
	MANU:ACW:CHISet	
	MANU:ACW:CLOSet	
	MANU:ACW:TTIMe	
	MANU:ACW:FREQuency	
	MANU:ACW:REF	
	MANU:ACW:ARCCurrent	
	MANU:DCW:VOLTage	
	MANU:DCW:CHISet	
	MANU:DCW:CLOSet	
	MANU:DCW:TTIMe	
	MANU:DCW:REF	
	MANU:DCW:ARCCurrent	
	MANU:IR:VOLTage	
	0-	==



	MANU:IR:RHISet	145
	MANU:IR:RLOSet	146
	MANU:IR:TTIMe	146
	MANU:IR:REF	147
	MANU:GB:CURRent	147
	MANU:GB:RHISet	148
	MANU:GB:RLOSet	148
	MANU:GB:TTIMe	148
	MANU:GB:FREQuency	149
	MANU:GB:REF	
	MANU:GB:ZEROCHECK	150
	MANU:UTILity:ARCMode	150
	MANU:UTILity:PASShold	151
	MANU:UTILity:FAILmode	151
	MANU:UTILity:MAXHold	151
	MANU:UTILity:GROUNDMODE	
	MANU <x>:EDIT:SHOW</x>	152
Sweep	SWEEP:DATA:STATus	
Commands	SWEEP <x>:DATA:SHOW</x>	
	SWEEP:GRAPh:SHOW	
	SWEEP:GRAPh:LINE	
	SWEEP:STARt:TIME	156
	AUTO:STEP	157
Auto Commands	AUTO <x>:PAGE:SHOW</x>	158
	AUTO:PAGE:MOVE	
	AUTO:PAGE:SWAP	
	AUTO:PAGE:SKIP	
	AUTO:PAGE:DEL	
	AUTO:NAME	
	AUTO:EDIT:ADD	
	TESTok:RETurn	
	*SRE	
_		
Common	*CI C	4.0
Commands	*CLS	
	*IDN	163





Remote	*RMTOFF	164
Commands		
Special Functions	INTerlock:PIN	164



System Commands

SYSTem:LCD:CC	NTrast		126
SYSTem:LCD:BRIGhtness			
SYSTem:BUZZer	:PSOUNE)	127
)	
SYSTem:CONTro	ol:INTerlo	ck	130
			Set →
SYSTem:LCD:C	ONTrast		→ Query
Description	Sets the c	ontrast of the LCD disp	olay from 1 (low)
	to 8 (brig	ht).	
Syntax	SYSTem:LCD:CONTrast <nr1></nr1>		
Query Syntax	SYSTem:LCD:CONTrast?		
Parameter/ Return parameter	<nr1></nr1>	1~8	
Example	SYST:LCD	:CONT 5	
	Sets the d	isplay contrast to 5.	
			Set →
SYSTem:LCD:B	RIGhtne	SS	—Query
Description	Cata tha h	wightness of the LCD d	ianlar fram
	Sets the brightness of the LCD display from 1(dark) to 2(bright).		
Syntax	SYSTem:LCD:BRIGhtness <nr1></nr1>		
Query Syntax	SYSTem:L	CD:BRIGhtness?	
Parameter/	<nr1></nr1>	1 (dark), 2 (bright)	
Return parameter			



Example SYST:LCD:BRIG 2

Sets the display brightness to bright.

SYSTem:BUZZer:PSOUND



Turns the buzzer sound on or off for a PASS Description

judgment.

SYSTem:BUZZer:PSOUND{ON|OFF} Syntax

SYSTem:BUZZer:PSOUND? **Query Syntax** Parameter/ ON PASS Sound on. Return parameter OFF PASS Sound off.

SYST:BUZZ:PSOUND ON Example

Turns the buzzer sound on for PASS judgments.



SYSTem:BUZZer:FSOUND

Description Turns the buzzer sound on or off for a FAIL judgment.

Syntax

SYSTem:BUZZer:FSOUND{ON|OFF} SYSTem:BUZZer:FSOUND?

Query Syntax FAIL Sound on. Parameter/ ON Return parameter OFF FAIL Sound off.

Example SYST:BUZZ:FSOUND ON

Turns the buzzer sound on for FAIL judgments.



SYSTem:BU77er:PTIMe

Description Sets the PASS sound duration in seconds.

Syntax SYSTem:BUZZer:PTIMe < NR2>

Query Syntax SYSTem:BUZZer:PTIMe? Parameter/ <NR2> 0.2~999.9

Return parameter



Example SYST:BUZZ:PTIM 1

Sets the buzzer to 1 second for a PASS judgment.

(Query

SYSTem:BUZZer:FTIMe

Description	Sets the F	AIL Sound duration in seconds.
Syntax	SYSTem:B	UZZer:FTIMe <nr2></nr2>
Query Syntax	SYSTem:B	UZZer:FTIMe?
Parameter/	<nr2></nr2>	0.2~999.9
Return parameter		
Example	SYST:BUZ	Z:FTIM 1

Sets the buzzer to 1 second for a FAIL judgment.

SYSTem:ERRor	→ Query
--------------	---------

Description	2	rors in the output buffer. See the e below for details.
Query Syntax	SYSTem:ERRor	?
Return parameter	<string></string>	Returns an error string that includes an error code and an error description.

Error Code Table

Error code, Error description

0.No Error

20.Command Error

21, Volume Error

22, String Error

23, Query Error

24, Mode Error

25.Time Error

26,DC Over 50W (GPT-98XX), DC Over 100W (GPT-

99XX/99XXA

27,GBV > 5.4V30, Voltage Setting Error

31, Current Setting Error



	32,Current HI SET Error 33,Current LOW SET Error 34,Resistance HI SET Error 35,Resistance LO SET Error 36,REF Setting Error 37,Frequency Setting Error 38,ARC Setting Error 39,RAMP Time Setting Error 40,TEST Time Setting Error 45, Buffer Error 50, Scanner Box Not Found 51, HI Channel Setting Error 52, LO Channel Setting Error 60, Get Data = 0 (GPT-9900 only gets SWEEP data)
Example	SYST:ERR?
	>0,No Error
	Returns "0, No Error" as the error message.

SYSTem:GPIB:VERSion



Description	Queries the 0	GPIB version.
Query Syntax	SYSTem:GPIB:VERSion?	
Return parameter	<string></string>	Returns: The GPIB version as a string "GPIB,V1.00" or "No GPIB connected" if there is not a GPIB device configured/connected.
Query Example	SYST:GPIB:VE >GPIB,V1.00 Returns the C	



Parameter/

Return parameter OFF

SYSTem:CONTrol:IRUNit → Query Description Toggles the IR unit between the default M/G ohm display and the fixed G ohm, which is suitable for applications of high ohm value measurement. Syntax SYSTem:CONTrol:IRUNit {ON | OFF} Query Syntax SYSTem:CONTrol:IRUNit ?

Example SYST:CONTI:IRUN ON

ON

Turns the IR unit to G ohm display.

IR unit fixed in G ohm display.

IR unit between M and G ohm displays.

SYSTem:CONTrol:INTerlock



Description	Queries the status of Interlock.	
Query Syntax	SYSTem:CONTrol:INTerlock?	
Return parameter	<string></string>	Returns: "OFF": Interlock function is off.
		or "ON" Interlock function is on.

Query Example SYST:CONT:INT?

>ON

Returns the Interlock function is on.



Function Commands

MEASure <x></x>			132
FUNCtion:TES ⁻	Γ	$\stackrel{\text{(Set)}}{\longrightarrow} \bigcirc$)→ uery)
Description	Turns the cur	rently selected test (outpu	it) on or off.
	When HOLD is displayed on the screen during AUTO tests, use the FUNCtion:TEST command to move on to the next step.		
	Setting the FUNCtion:TEST command to OFF at the end of a test will also temporarily turn the PASS/FAIL buzzer sound off.		
Syntax	FUNCtion:TEST {ON OFF}		
Query Syntax	FUNCtion:TEST?		
Parameter	ON	Turns the test on.	
	OFF	Turns the test off.	
Return parameter	TEST ON	Test is on.	
	TEST OFF	Test is off.	
Example	FUNC:TEST O	N	

Turns the output on.



MEASure<x>



Description

Returns the test parameters & results of the tester in either MANU or AUTO mode.

MANU mode: Returns the test parameters & results of a MANU test.

AUTO mode: Returns the test parameters & results of the selected step (1-16) of the AUTO test.

Return parameters: function, judgment/status, test voltage/current, measured current/resistance, test time (time of completed test) or ramp time (elapsed time of test that has not been completed.

Query Syntax	MEASure <x>?</x>	
Parameter		No parameter needed for MANU
(MANU mode)		mode.
Parameter	<x></x>	<nr1>1~16. Step number.</nr1>
(AUTO mode)		
Return parameter	<string></string>	Returns the test status of the test
		in the following format:
		function, judgment or status, test
		voltage, test current or resistance,
		test time or ramp time
	Function	ACW, DCW, IR, GB
	Judgment	PASS, FAIL
	/Status	VIEW
	Test voltage	voltage+unit
	Test current	current+unit
	/Test resistance	resistance+unit
	Test time	T=time+S

Example (in MANU mode)

MEAS?

/Ramp time

>ACW,FAIL,0.024kV,0.013 mA ,R=000.1S

Returns the test result of the current manual test.

R=time+S



Example (in MANU mode)	MEAS?
	>IR,TEST,0.250kV,Mohm,T=000.2S
	Returns as the test result when the reading is invalid.
Example (in AUTO mode)	MEAS10?
	>IR,FAIL,0.250kV,999M ohm,T=010.3S
	Returns step 10 of the current automatic result.
	<u>Set</u> →

→ Query MAIN:FUNCtion

Description	Changes the mode between AUTO and MANU.		
Syntax	MAIN:FUNCtion {MANU AUTO}		
Query Syntax	MAIN:FUNCtion?		
Parameter	MANU	Puts the tester mode to MANU.	
	AUTO	Puts the tester mode to AUTO.	
Return parameter	MANU MODE	The tester mode is set to MANU.	
	AUTO MODE	The tester mode is set to AUTO.	
Example	MAIN:FUNC MANU		
	Sate the tester to	MANILLmodo	

Sets the tester to MANU mode.



Manual Commands

MANU:STEP	135
MANU:NAME	
MANU:INITial	135
MANU:RTIMe	136
MANU:EDIT:MODE	136
MANU:ACW:VOLTage	137
MANU:ACW:CHISet	138
MANU:ACW:CLOSet	138
MANU:ACW:TTIMe	139
MANU:ACW:FREQuency	140
MANU:ACW:REF	
MANU:ACW:ARCCurrent	141
MANU:DCW:VOLTage	
MANU:DCW:CHISet	
MANU:DCW:CLOSet	
MANU:DCW:TTIMe	
MANU:DCW:REF	144
MANU:DCW:ARCCurrent	144
MANU:IR:VOLTage	145
MANU:IR:RHISet	
MANU:IR:RLOSet	
MANU:IR:TTIMe	146
MANU:IR:REF	
MANU:GB:CURRent	147
MANU:GB:RHISet	
MANU:GB:RLOSet	
MANU:GB:TTIMe	
MANU:GB:FREQuency	
MANU:GB:REF	149
MANU:GB:ZEROCHECK	150
MANU:UTILity:ARCMode	150
MANU:UTILity:PASShold	
MANU:UTILity:FAILmode	
MANU:UTILity:MAXHold	
MANU:UTILity:GROUNDMODE	152
MANU <x>:EDIT:SHOW</x>	152



MANU:STEP	Set → Query
Description	Sets the MANU test number.
Syntax	MANU:STEP <nr1></nr1>
Query Syntax	MANU:STEP?
Parameter/ Return parameter	<nr1> 0~100.</nr1>
Example	MANU:STEP 100
	Sets the manual test number to 100.
MANU:NAME	Set → —Query
Description	Sets or returns the test name for the selected manual test. The test must be in MANU mode before this command can be used. Note only alphanumeric characters (A-Z, a-z, 0-9) and the "_" underscore character can be used to set the MANU test name.
Syntax	MANU:NAME <string></string>
Query Syntax	MANU:NAME?
Parameter/ Return parameter	<string> 10 character string. (first character must be a letter)</string>
Example	MANU:NAME test1
	Sets the manual test name to "test1".
MANU:INITial	Set →
Description	Loads the initial (default) settings for the selected MANU test number. The initial settings that are loaded depend on the test function (ACW, DCW, IR or GB).
Syntax	MANU:INITial



Initial Settings			Fund	ction	
illitial Settings	Parameter	ACW	DCW	IR	GB
	REF#	0.000mA	0.000mA	0000ΜΩ	000.0m Ω
	FREQ	60Hz	X	X	60Hz
	HI SET	1.000mA	1.000mA	∞ M Ω	100.0m Ω
	LO SET	0.000mA	0.000mA	0001M Ω	000.0m Ω
	I or V	V=0.100kV	V=0.100kV	V=0.050kV	03.00A
	TIMER	001.0S	001.0S	001.0S	001.0S
	RAMP/	000.1S	000.15	000.1S	X

Example MANU:INITial

Loads the initial settings for the selected MANU

number.

MANU:RTIMe



Description Sets or returns the Ramp Time for the test in

seconds.

Note: A "TIME ERR" will result if the Ramp Time + Test Time is \geq 240 seconds when the HI SET limit is over 30mA (GPT-98XX) or over 80mA (GPT-99XX/99XXA). This applies to the ACW function only.

Syntax MANU:RTIMe <NR2>
Query Syntax MANU:RTIMe?

Parameter/ <NR2> 0.1~999.9 seconds
Return parameter

Example MANU:RTIM 0.5

Sets the ramp time to half a second.

MANU:EDIT:MODE



Description	Sets or returns the mode (ACW, DCW, IR, GB) of the selected manual test.
Syntax	MANU:EDIT:MODE {ACW DCW IR GB}
Query Syntax	MANU:EDIT:MODE?



Parameter/	ACW	AC Withstand mode
Return parameter	DCW	DC Withstand mode
	IR	Insulation Resistance mode
	GB	Ground Bond mode
Example	MANU:EI	DIT:MODE ACW
	Sets the r	node to ACW.
		Set →
MANU:ACW:V	OLTage	→ Query
Description		eturns the ACW voltage in kV. The test to be in ACW mode before this command sed.
Description Syntax	must firs	t be in ACW mode before this command
	must firs can be us	t be in ACW mode before this command sed.
Syntax	must firs can be us	t be in ACW mode before this command sed. CW:VOLTage < NR2>

Sets the ACW voltage to 1 kV.



MANU:ACW:C	HISet		Set → Query
Description	milliamp	eturns the ACW HI SE os. The test must first b iis command can be use	e in ACW mode
Syntax	MANU:A	CW:CHISet <nr2></nr2>	
Query Syntax	MANU:A	CW:CHISet?	
Parameter/ Return parameter	<nr2></nr2>	0.001 ~ 042.0 (GPT-98) 0.001 ~ 110.0 (GPT-99)	,
Example	MANU:A	CW:CHIS 10.0	·
	Sets the A	ACW HI SET current to 1	0 mA.
			Set →

MANU:ACW:CLOSet

Description

→ Query

Sets or returns the ACW LO SET current value in milliamps. The LO SET value must be less than the HI SET value. The test must first be in ACW mode before this command can be used.

The LO SET range must use the HI SET range. If all the digits in the LO SET range are outside the HI SET range, an error will be produced. All digits outside the HI SET range are ignored and will not be used.

For example:

HI SET value: 12.34

LO SET value1: $0.005 \Rightarrow$ error LO SET value2: $0.053 \Rightarrow$ no error

In the example above LO SET value1 will produce an error as all digits are outside the range of HI SET. LO SET value2 will not produce an error, but will return 0.05, not 0.053.



Syntax	MANU:ACW:C	I OSatzNP2
•		
Query Syntax Parameter/	MANU:ACW:C) ~ 041.9 (GPT-98XX)
Return parameter		7~ 041.9 (GFT-99XX/99XXA)
Example	MANU:ACW:C	, , ,
	Sets the ACW L	O SET current to 20 mA.
		(Set)→
MANU:ACW:T	ГІМе	——Query
Description	test must first command can Note: A "TIM! + Test Time is is over 30mA (99XX/99XXA) only.	s the ACW test time in seconds. The be in ACW mode before this be used. E ERR" will result if the Ramp Time ≥ 240 seconds when the HI SET limit (GPT-98XX) or over 80mA (GPT-0). This applies to the ACW function NU mode, the TIMER can be turned
Syntax		 ГІМе { <nr2> OFF}</nr2>
Query Syntax	MANU:ACW:T	• • •
Parameter	<nr2></nr2>	0.5 ~ 999.9 seconds
rameter	OFF	TIMER OFF (special MANU mode).
Return parameter	<nr2></nr2>	0.5 ~ 999.9 seconds
· 	TIME OFF	TIMER is OFF (special MANU mode).
Example	MANU:ACW:T	ГІМ 1

Sets the ACW test time to 1 second.



MANU:ACW:FI	REQuency		Set → Query
Description	test must fi	erns the ACW test fre rst be in ACW mode can be used.	
Syntax	MANU:ACW	V:FREQuency {50 60}	
Query Syntax	MANU:ACW	V:FREQuency?	
Parameter	60 60	O Hz O Hz	
Return parameter		O Hz O Hz	
Example	MANU:ACW	V:FREQ 50	
	Sets the AC	W test frequency to 50	Hz.
			Set →
MANU:ACW:RI	EF		→ Query
Description	The test mu	erns the ACW referer ust first be in ACW n can be used.	
	The ACW r SET value.	reference value must	be less than the HI
	The ACW r	reference value must ET value.	use the same range
Syntax	MANU:ACW	V:REF <nr2></nr2>	
Query Syntax	MANU:ACW	V:REF?	
Parameter/ Return parameter		.000 ~ 041.9 (GPT-98) .000 ~ 109.9 (GPT-99)	,
Example	MANU:ACW	V:REF 0.01	
	Sets the AC	W reference to 0.01 m	A.



MANU:ACW:A	RCCurrent	Set ————————————————————————————————————
Description	Sets or returns the ACW A ARC must be enabled before be set. The test must first be this command can be used.	re the ARC current can e in ACW mode before
	ARC current uses the same value. The ARC current is larger value.	
Syntax	MANU:ACW:ARCCurrent <n< td=""><td>R2></td></n<>	R2>
Query Syntax	MANU:ACW:ARCCurrent?	
Parameter/ Return parameter	<nr2> 1.000 ~ 080.0 (GP 2.000 ~ 200.0 (GP</nr2>	,
Example	MANU:ACW:ARCC 0.04	
	Sets the ACW ARC value to 0	.04 mA.
		Set →
MANU:DCW:V	OLTage	→ Query
Description	OLTage Sets or returns the DCW vomust first be in DCW mode can be used.	oltage in kV. The test
	Sets or returns the DCW vomust first be in DCW mode can be used. Note: A "DC Over 50W" en DCW Voltage X HI SET va 98XX).	oltage in kV. The test e before this command error will result if the lue is > 50 watts (GPT-
	Sets or returns the DCW vomust first be in DCW mode can be used. Note: A "DC Over 50W" en DCW Voltage X HI SET va	oltage in kV. The test e before this command error will result if the lue is > 50 watts (GPT-error will result if the
	Sets or returns the DCW vormust first be in DCW mode can be used. Note: A "DC Over 50W" en DCW Voltage X HI SET var 98XX). Note: A "DC Over 100W" en DCW Voltage X HI SET var DCW Voltage X HI SET var	oltage in kV. The test before this command error will result if the lue is > 50 watts (GPT-error will result if the lue is > 100 watts (GPT-
Description	Sets or returns the DCW vormust first be in DCW mode can be used. Note: A "DC Over 50W" en DCW Voltage X HI SET var 98XX). Note: A "DC Over 100W" en DCW Voltage X HI SET var 99XX/99XXA).	oltage in kV. The test before this command error will result if the lue is > 50 watts (GPT-error will result if the lue is > 100 watts (GPT-
Description	Sets or returns the DCW vormust first be in DCW mode can be used. Note: A "DC Over 50W" en DCW Voltage X HI SET var 98XX). Note: A "DC Over 100W" en DCW Voltage X HI SET var 99XX/99XXA). MANU:DCW:VOLTage < NR2	oltage in kV. The test before this command error will result if the lue is > 50 watts (GPT-error will result if the lue is > 100 watts (GPT-
Syntax Query Syntax Parameter/	Sets or returns the DCW vormust first be in DCW mode can be used. Note: A "DC Over 50W" end DCW Voltage X HI SET variable. Note: A "DC Over 100W" end DCW Voltage X HI SET variable. DCW Voltage X HI SET variable. MANU:DCW:VOLTage < NR2 MANU:DCW:VOLTage?	oltage in kV. The test before this command error will result if the lue is > 50 watts (GPT-error will result if the lue is > 100 watts (GPT-



Description Sets or returns the DCW HI SET current value in

milliamps. The test must first be in DCW mode

before this command can be used.

Note: A "DC Over 50W" error will result if the DCW Voltage X HI SET value is > 50 watts.

Note: A "DC Over 100W" error will result if the DCW Voltage X HI SET value is > 100 watts (GPT-

99XX/99XXA)

Syntax MANU:DCW:CHISet <NR2>
Query Syntax MANU:DCW:CHISet?

Parameter/ <NR2> 0.001 ~ 011.0 (GPT-98XX)

Return parameter $0.001 \sim 021.0 \text{ (GPT-99XX/99XXA)}$

Example MANU:DCW:CHIS 5

Sets the DCW HI SET current to 5mA.

$\begin{array}{ccc} & & & & & & \\ & & & & \\ & & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & \\ & & \\ & & \\ & & \\ & & \\ & & \\ & & \\ & & \\ & & \\ & & \\ & & \\ & & \\ & & \\ & \\ & & \\ & \\ & & \\ &$

Description

Sets or returns the DCW LO SET current value in milliamps. The LO SET value must be less than the HI SET value. The test must first be in DCW mode before this command can be used.

The LO SET range must use the HI SET range. If all the digits in the LO SET range are outside the HI SET range, an error will be produced. All digits outside the HI SET range are ignored and will not be used.

For example:

HI SET value: 12.34

LO SET value1: $0.005 \rightarrow \text{error}$ LO SET value2: $0.053 \rightarrow \text{no error}$

In the example above LO SET value1 will produce



	SET. LO SE	all digits are outside the range of HI T value2 will not produce an error, but 0.05, not 0.053.	
Syntax	MANU:DCW:CLOSet <nr2></nr2>		
Query Syntax	MANU:DCV	MANU:DCW:CLOSet?	
Parameter/ Return parameter			
Example	MANU:DCV	V:CLOS 2.00	
	Sets the DC	W LO SET current to 2mA.	
		(Set)→	
MANU:DCW:T	TIMe	—Query	
Description	test must fi	rns the DCW test time in seconds. The rst be in DCW mode before this can be used.	
Description	test must fi	rst be in DCW mode before this	
Description Syntax	test must fit command of the special Month.	rst be in DCW mode before this can be used.	
	test must fit command of the special Month.	rst be in DCW mode before this can be used. MANU mode, the TIMER can be turned V:TTIMe { <nr2> OFF}</nr2>	
Syntax	In special Noff. MANU:DCV	rst be in DCW mode before this can be used. MANU mode, the TIMER can be turned V:TTIMe { <nr2> OFF}</nr2>	



Example MANU: DCW:TTIM 1

Sets the DCW test time to 1 second.

MANU:DCW:REF

→Query)

Description Sets or returns the DCW reference value in mA.

The test must first be in DCW mode before this

command can be used.

The reference value must be less than the HI SET

value.

The reference value uses the same range as the HI

SET value.

Syntax MANU: DCW: REF < NR2>

Query Syntax MANU:DCW:REF?

Parameter/ < NR2> $0.000 \sim 010.9 \text{ (GPT-98XX)}$

Return parameter $0.000 \sim 020.9 \text{ (GPT-99XX/99XXA)}$

Example MANU: DCW: REF 0.01

Sets the DCW reference to 0.01 mA.

MANU:DCW:ARCCurrent



Description Sets or returns the DCW ARC current value in mA.

ARC must be enabled to set the ARC current. The

test must first be in DCW mode before this

command can be used.

ARC current uses the same range as the HI SET value. The ARC current is limited to 2X the HI SET

value.

Syntax MANU: DCW: ARCCurrent < NR2>

Query Syntax MANU:DCW:ARCCurrent?

Parameter/ <NR2> 1.000 ~ 20.00 (GPT-98XX)

Return parameter $2.000 \sim 040.0 \text{ (GPT-99XX/99XXA)}$



Example	MANU:DO	CW:ARCC 10
	Sets the D	OCW ARC value to 10mA.
		(Set)→
MANU:IR:VOL	Tage	—Query)
Description		turns the IR voltage in kV. The test must IR mode before this command can be
Syntax	MANU:IR	:VOLTage <nr2></nr2>
Query Syntax	MANU:IR	:VOLTage?
Parameter/ Return parameter		0.05 ~ 1 (0.05kV to 1kV: steps of .05) *GPT-99XX/99XXA also includes a 0.125kV point.
Example	MANU:IR	:VOLT 1
	Sets the IR voltage to 1 kV.	
		(Set)→
MANU:IR:RHIS	Set	—Query
Description	MΩ (GPT	turns the IR HI SET resistance value in G -98XX) or $G\Omega$. The test must first be in IR ore this command can be used.
Syntax	MANU:IR:RHISet <nr1> NULL</nr1>	
Query Syntax	MANU:IR:RHISet?	
Parameter/ Return parameter		GPT-98XX only: $2 \sim 9999$ (unit = $M\Omega$) GPT-99XX/GPT-99XXA only: Format A: $0.002 \sim 50.00$ (unit = $G\Omega$) Format B: $0.002G \sim 50.00G$ Format C: $2M \sim 50000M$ Sets the HI SET value to ∞ .
Example	MANU:IR	
(GPT-98XX)		R HI SET resistance to 10 M Ω .
	שבנש נוופ וו	VIII DET TESISTATICE TO TO INITY.



Example MANU: IR: RHIS 0.010 (GPT-99XX/ Sets the IR HI SET resistance to $10 M\Omega$. 99XXA) Set MANU:IR:RLOSet Query Sets or returns the IR LO SET resistance value in Description $M\Omega$ (GPT-98XX) or $G\Omega$. The LO SET value must be less than the HI SET value. The test must first be in IR mode before this command can be used. MANU:IR:RLOSet<NR1> Syntax Query Syntax MANU:IR:RLOSet? Parameter/ <NR1> GPT-98XX only: $1 \sim 9999 \text{ (unit = } M\Omega)$ Return parameter GPT-99XX/GPT-99XXA only: Format A: $0.001 \sim 50.00$ (unit = $G\Omega$) Format B: 0.001G ~ 50.00G Format C: 1M ~ 50000M Example MANU: IR: RLOS 10 (GPT-98XX) Sets the IR LO SET resistance to $10M\Omega$. Example MANU: IR: RLOS 0.010 (GPT-99XX/ Sets the IR LO SET resistance to $10M\Omega$. 99XXA) Set MANU:IR:TTIMe Query Description Sets or returns the IR test time in seconds. The test must first be in IR mode before this command can be used. Syntax MANU:IR:TTIMe <NR2> MANU:IR:TTIMe? Query Syntax 1.0 ~ 999.9 seconds Parameter/ <NR2> Return parameter Example MANU: IR: TTIM 1 Sets the IR test time to 1 second.



MANU:IR:REF	Set → Query		
Description	Sets or returns the IR reference value in M Ω (GPT-98XX) or G Ω . The test must first be in IR mode before this command can be used.		
	The reference value must be lower than the HI SET value.		
Syntax	MANU:IR:REF <nr1></nr1>		
Query Syntax	MANU:IR:REF?		
Parameter/ Return parameter	<nr1> GPT-98XX only: $0000 \sim 9999 \text{ (unit = M}\Omega\text{)}$ GPT-99XX/GPT-99XXA only: Format A: $0 \sim 50.00 \text{ (unit = G}\Omega\text{)}$ Format B: $0 \sim 50.00 \text{G}$ Format C: $0 \sim 5000 \text{M}$</nr1>		
Example	MANU:IR:REF 900		
(GPT-98XX)	Sets the IR reference to 900 M Ω .		
Example (GPT-99XX/ 99XXA)	MANU:IR:REF 0.900		
	Sets the IR reference to 900 $\mbox{M}\Omega.$		
	Set		
MANU:GB:CUI	RRent —Query		
Description	Sets or returns the GB current in A. The test must first be in GB mode before this command can be used.		
Syntax	MANU:GB:CURRent <nr2></nr2>		
Query Syntax	MANU:GB:CURRent?		
Parameter/ Return parameter	<nr2> 3.00~33.00 (GPT-98XX) 3.00~33.00 (GPT-99XX)</nr2>		
Example	MANU:GB:CURR 3.00		
	Sets the GB current to 3.00A.		



MANU:GB:RH	lSet		Set ————————————————————————————————————
Description	$m\Omega.$ The	turns the GB HI SET t test must first be in G d can be used.	
Syntax	MANU:G	B:RHISet <nr2></nr2>	
Query Syntax	MANU:G	B:RHISet?	
Parameter/ Return parameter	<nr2></nr2>	000.1 ~ 650.0	
Example	MANU:G	B:RHIS 100.0	
	Sets the F	HI SET value to 100 m Ω	
Note !		current x HI SET resist be generated ("GBV > 5	
MANU:GB:RLC	Set		Set → Query
Description	mΩ. The SET valu	turns the GB LO SET LO SET value must b e. The test must first is command can be us	e less than the HI be in GB mode
Syntax	MANU:G	B:RLOSet <nr2></nr2>	
Query Syntax	MANU:IR	:RLOSet?	
Parameter/ Return parameter	<nr2></nr2>	0.000 ~ 649.9	
Example	MANU:G	B:RLOS 50	
	Sets the C	GB LO SET resistance to	50mΩ.
MANU:GB:TTI	Me		Set → Query
Description		turns the GB test time t be in GB mode befor	



Syntax	MANIIIC	B:TTIMe <nr2></nr2>
•	MANU:G	
Query Syntax Parameter/	<nr2></nr2>	
Return parameter		old 77717 seconds
Example	MANU:G	B:TTIM 1
	Sets the C	GB test time to 1 second.
		Set →
MANU:GB:FRE	Quency	——Query
Description		eturns the GB test frequency in Hz. The first be in GB mode before this command sed.
Syntax	MANU:G	B:FREQuency {50 60}
Query Syntax	MANU:G	B:FREQuency?
Parameter	50	50 Hz
	60	60 Hz
Return parameter	50 Hz	50 Hz
	60 Hz	60 Hz
Example	MANU:G	B:FREQ 50
	Sets the C	GB test frequency to 50Hz.
		Set →
MANU:GB:REF	-	Query
Description		eturns the GB reference value in $m\Omega$. The first be in GB mode before this command sed.
Syntax	MANU:G	B:REF <nr2></nr2>
Query Syntax	MANU:G	B:REF?
Parameter/ Return parameter	<nr2></nr2>	0.000 ~ 649.9
Example	MANU:G	B:REF 100
	Sets the C	GB reference to 100 m Ω .



MANU:GB:ZEF	ROCHECK	Set → Query	
Description	Performs the zero check function. The test must first be in GB mode and in the Ready Status before this command can be used.		
	See page 74 for	details on the ZERO function.	
Syntax	MANU:GB:ZEROCHECK {ON OFF}		
Query Syntax	MANU:GB:ZER	OCHECK?	
Parameter/		function is active.	
Return parameter	OFF Zero	function is not active.	
Example	MANU:GB:ZER	OCHECK OFF	
	Activates the ZE	RO function.	
		(Set)→	
MANU:UTILity	:ARCMode	Query	
Description	Sets or returns the ARC mode status for the current test. The ARC mode cannot be set for the IR and GB function.		
	function.	e cannot be set for the IK and GB	
Syntax		ARCMode {OFF ON_CONT	
Syntax Query Syntax	MANU:UTILity:	ARCMode {OFF ON_CONT	
•	MANU:UTILity: ON_STOP}	ARCMode {OFF ON_CONT ARCMode? Turns ARC mode off.	
Query Syntax	MANU:UTILity: ON_STOP} MANU:UTILity:	ARCMode {OFF ON_CONT ARCMode?	
Query Syntax	MANU:UTILity: ON_STOP} MANU:UTILity:	ARCMode {OFF ON_CONT ARCMode? Turns ARC mode off. Sets ARC mode to ON and	
Query Syntax	MANU:UTILity: ON_STOP} MANU:UTILity: OFF ON_CONT ON_STOP	ARCMode {OFF ON_CONT ARCMode? Turns ARC mode off. Sets ARC mode to ON and CONTINUE.	
Query Syntax Parameter	MANU:UTILity: ON_STOP} MANU:UTILity: OFF ON_CONT ON_STOP ARC OFF	ARCMode {OFF ON_CONT ARCMode? Turns ARC mode off. Sets ARC mode to ON and CONTINUE. Sets ARC mode to ON and STOP.	
Query Syntax Parameter	MANU:UTILity: ON_STOP} MANU:UTILity: OFF ON_CONT ON_STOP ARC OFF ARC ON_CONT	ARCMode {OFF ON_CONT ARCMode? Turns ARC mode off. Sets ARC mode to ON and CONTINUE. Sets ARC mode to ON and STOP. ARC mode is set off. ARC mode is set ON and	
Query Syntax Parameter	MANU:UTILity: ON_STOP} MANU:UTILity: OFF ON_CONT ON_STOP ARC OFF ARC ON_CONT	ARCMode {OFF ON_CONT ARCMode? Turns ARC mode off. Sets ARC mode to ON and CONTINUE. Sets ARC mode to ON and STOP. ARC mode is set off. ARC mode is set ON and CONTINUE. ARC mode is set ON and CONTINUE. ARC mode is set ON and STOP.	



MANU:UTILity	:PASShold		Set → Query
Description		Sets or returns the PASS HOLD setting for the current test.	
Syntax	MANU:UTII	_ity:PASShold {ON OF	·F}
Query Syntax	MANU:UTII	MANU:UTILity:PASShold?	
Parameter/	OFF	Turns PASS HOLD	
Return parameter	ON	Turns PASS HOLD	on.
Example	MANU:UTII	_:PASS OFF	
	Turns PASS	HOLD OFF.	
			Set →
MANU:UTILity	:FAILmode	!	Query
Description	Sets or retu	rns the FAIL mode s	etting for the
Syntax	MANU:UTII	_ity:FAILmode {CONT	HOLD STOP}
Query Syntax	MANU:UTII	_ity:FAILmode?	
Parameter/	CONT	Sets/returns the fail	
Return parameter		Sets/returns the fail	
	STOP	Sets/returns the fail	l mode as stop.
Example	MANU:UTII	_:FAIL CONT	
	Sets the fail	mode to CONT (conti	nue).
			Set →
MANU:UTILity	:MAXHold		→ Query
Description	Sets or retu current test	rns the MAX HOLD	setting for the
Syntax	MANU:UTII	_ity:MAXHold {ON OF	
Query Syntax	MANU:UTII	_ity:MAXHold?	
Parameter/	OFF	Turns MAX HOLD	off.
Return parameter	ON	Turns MAX HOLD	on.



Example MANU:UTIL:MAXH ON Turns MAX HOLD on.

MANU:UTILity:GROUNDMODE



Description	Sets or retur	ens the Grounding mode of the current
		l Mode setting cannot be turned on and GB function.
Syntax	MANU:UTIL	ity:GROUNDMODE {ON OFF}
Query Syntax	MANU:UTIL	ity:GROUNDMODE?
Parameter/	OFF	Turns ground mode off.
Return parameter	ON	Turns ground mode on.
Example	MANU:UTIL	:GROUNDMODE ON

Turns GROUND MODE on.

MANU<x>:EDIT:SHOW



Description	Returns the test parameters of a manual test.		
Query Syntax	MANU <x>:EDIT:SHOW?</x>		
Parameter/	<x></x>	<nr1> 000~100. Manual test number</nr1>	
Return parameter	<string></string>	Returns a string in the following	
		format:	
		Test function, test voltage, HI SET	
		value, LO SET value, Ramp time, test	
		time.	
Example	MANU1:ED	IT:SHOW ?	
	> ACW,0.100 >T=001.0S.	0kV,H=01.00mA,L=00.00mA,R=000.1S,	
	Returns the test parameters of manual test number 1.		



Sweep Commands

SWEEP <x>:DAT SWEEP:GRAPh:S SWEEP :GRAPh:</x>	A:SHOW SHOW LINE	
SWEEP:DATA:S	STATus	→ Query
Description	Returns the sweep mode, the voltage and current settings and the number data points that are used in the last sweep. There can be a maximum of 190 data points, depending on the testing time.	
	The data format:	is returned as a string in the following
	SWEEP N	MODE,VSET,ISET,Get Data[#data points].
Query Syntax	SWEEP:D	ATA:STATus?
Return parameter	<string></string>	SWEEP MODE, VSET+unit, ISET+units, Get Data=number of data points
Example	SWEEP:D	ATA:STATus?

>ACW,V=0.108kV,HI=10.96 mA ,Get Data=011



SWEEP<X>:DATA:SHOW



Description

Returns the data associated with a sweep graph.

Data can be returned in one of two ways; either all the data can be returned or only the data at a particular point in time.

The test points are evenly distributed. There can be up to 190 data points.

If only the data from a single point is returned then the data is returned in the following format*: DATA POINT, VSET, ISET, TIME, CR+LF

If the all the data for the all the points is returned then the data is returned in the following format*:

ACW MODE, CR+LF

No.,V(kV),I(mA), T(S),CR+LF001,0.071,0.032,0000.1,CR+LF

002,0.111,0.047,0000.2,CR+LF

013,0.601,0.215,0001.3,CR+LF

END

*Where CR+LF is a carriage return and line feed code. Time is in seconds.

Query Syntax	SWEEP<>	<pre><>:DATA:SHOW?</pre>
Parameter	<x></x>	<nr1> 1~190 (single data point)</nr1>
	<x></x>	<nr1> 0 (all data points)</nr1>

Single Data Point SWEEP10:DATA:SHOW?

Example

> 010,0.106,00.00,0001.0, CR+LF

Returns the data at point 10, which is at the 1 second time for the sweep test.



All Data Points Example

SWEEP0:DATA:SHOW?

>ACW MODE,CR+LF

>No.,V(kV),I(mA), T(S),CR+LF>001,0.071,0.032,0000.1,CR+LF >002,0.111,0.047,0000.2,CR+LF

>.....

>013,0.601,0.215,0001.3,CR+LF

>END

This will return all the data from the sweep graph.

SWEEP:GRAPh:SHOW



Description	Turns the sweep graph on or off on the GPT-99XX/99XXA display.	
Syntax	SWEEP:G	RAPh:SHOW {ON OFF}
Query Syntax	SWEEP:G	RAPh:SHOW?
Parameter/	ON	Turn the sweep graph on.
Return parameter	OFF	Turn the sweep graph off.
Example	SWEEP:G	RAP:SHOW ON

Displays the sweep graph on the LCD display.

SWEEP: GRAPh: LINE



Description	Sets or returns which lines are shown on the sweep graph.
Syntax	SWEEP:GRAPh:LINE <nr1></nr1>
Query Syntax	SWEEP:GRAPh:LINE?



Parameter/	<nr1></nr1>	Description
Return parameter	0	Turn all lines off/all lines are off.
	1	Displays the graph line for the primary
		test item. See page 78 for details.
		For example: V for ACW, DCW and IR
		tests, I for GB tests.
	2	Displays the graph line for the secondary
		test items.
		For example: I for ACW and DCW tests,
		R for IR and GB tests.
	3	Turn all lines on/all lines are on.
Example	SWEEP:G	RAP:LINE 3
	Turns all t	the graph lines on.
		<u></u>
		Sot
C\Y/EED.CT	TINAE	Set →
SWEEP:STARt:	TIME	Set → Query
		Query
SWEEP:STARt:	Sets or re	eturns the start time (STA.t) of the sweep
	Sets or re	Query
	Sets or regraph in	eturns the start time (STA.t) of the sweep milliseconds.
	Sets or regraph in	eturns the start time (STA.t) of the sweep milliseconds.
	Sets or regraph in This setti the first p	eturns the start time (STA.t) of the sweep milliseconds. In a will also set what the time will be for point for the sweep data that is returned in
Description	Sets or regraph in This setti the first I the SWE	eturns the start time (STA.t) of the sweep milliseconds. In a will also set what the time will be for point for the sweep data that is returned in EP:DATA:SHOW query.
	Sets or regraph in This setti the first I the SWE	eturns the start time (STA.t) of the sweep milliseconds. In a will also set what the time will be for point for the sweep data that is returned in
Description	Sets or regraph in This setti the first p the SWEEP:S	eturns the start time (STA.t) of the sweep milliseconds. In a will also set what the time will be for point for the sweep data that is returned in EP:DATA:SHOW query.
Description Syntax	Sets or regraph in This setti the first p the SWEEP:S	eturns the start time (STA.t) of the sweep milliseconds. Ing will also set what the time will be for point for the sweep data that is returned in EP:DATA:SHOW query. TART:TIME <nr2></nr2>
Description Syntax Query Syntax	Sets or regraph in This setti the first p the SWEEP:S' SWEEP:S'	eturns the start time (STA.t) of the sweep milliseconds. Ing will also set what the time will be for point for the sweep data that is returned in EP:DATA:SHOW query. TART:TIME <nr2> TART:TIME ?</nr2>
Description Syntax Query Syntax Parameter/	Sets or regraph in This setti the first p the SWEEP:S' SWEEP:S' <nr2></nr2>	eturns the start time (STA.t) of the sweep milliseconds. Ing will also set what the time will be for point for the sweep data that is returned in EP:DATA:SHOW query. TART:TIME <nr2> TART:TIME ?</nr2>
Syntax Query Syntax Parameter/ Return parameter	Sets or regraph in This setti the first p the SWEEP:S' SWEEP:S' <nr2> SWEEP:S'</nr2>	eturns the start time (STA.t) of the sweep milliseconds. Ing will also set what the time will be for point for the sweep data that is returned in EP:DATA:SHOW query. TARt:TIME <nr2> TARt:TIME ? 0.1~1999.8 seconds</nr2>



Auto Commands

AUTO:STEP	
AUTO <x>:PAGE</x>	:SHOW158
AUTO:PAGE:MO	DVE158
AUTO:PAGE:SW	'AP159
AUTO:PAGE:SK	IP159
AUTO:PAGE:DE	L160
	O
*SRE	
	(Set)→
AUTO:STEP	Query
Description	Sets or queries the AUTO number (automatic test number).
Syntax	AUTO:STEP < NR1>
Query Syntax	AUTO:STEP?
Parameter/ Return parameter	<nr1> 1~100.</nr1>
Example	AUTO:STEP 100

Sets the current AUTO number to 100.



AUTO<x>:PAGE:SHOW



71010 \	IGE.5110 W	, (Query)	
Description	Returns the Page View of the selected automatic test in the following format:		
	step1:MANU number, step2 step3etc.	: MANU number,	
Query Syntax	AUTO <x>:PAGE:SHOW?</x>		
Parameter/	<x> <nr1>1~100</nr1></x>		
Example	AUTO1:PAGE:SHOW? >01:011 ,02:004 ,03:003 ,04: >05:015 ,06:020* ,07:012 ,08: >09: ,10: ,11: ,12:	018 ,	
	>13: ,14: ,15: ,16: Shows the Page View for AUTO	,	
	Shows the rage view for AOTO	J Hullibel 1.	

AUTO:PAGE:MOVE



Description	Moves the source step to the desired destination.
Syntax	AUTO:PAGE:MOVE <value1>,<value2></value2></value1>
Parameter/	<value1> <nr1> 1~16 (source step)</nr1></value1>
	<value2> <nr1> 1~16 (destination step)</nr1></value2>
Example	AUTO:PAGE:MOVE 1, 4
	Moves the contents of step 1 to the step 4.
	AUT 0=001-010 AUT 0 NAME MANI NAME #01:010 #02:001 #03:003 #08:005 #08:005 #108:005 #111: #12: #13: #14: #15: #16: MOVE SWAP SKIP DEL



AUTO:PAGE:SWAP



Description	Swaps the source step with destination step.	
Syntax	AUTO:PAGE:SWAP < Value1>, < Value2>	
Parameter/	<vaue1> <nr1> 1~16 (source step)</nr1></vaue1>	
	<value2> <nr1> 1~16 (destination step)</nr1></value2>	
Example	AUTO:PAGE:SWAP 1, 4	
	Swaps the contents of step 1 with step 4.	
	AUTO=001-010 AUTO_NAME	
	#01:010 #02:001 #03:003 #04:004	



AUTO:PAGE:SKIP



Description	Skips the selected step when an AUTO test is run. This is shown as an asterisk (*) when in the PAGE view.	
Syntax	AUTO:PA	AGE:SKIP <nr1>,{ON OFF}</nr1>
Parameter/	<nr1> ON OFF</nr1>	1~16 (step no.#) Skip the selected step. Un-skip the selected step.
Example		E ACW= 0 . 1 0 kV HI_SET=01.0mA #02:001 #03:003 #04:004 #06:003 #07:038 #08:005 #10: #11: #12: #14: #15: #16:



AUTO:PAGE:DEL Set Deletes the selected step from the AUTO test. The Description remaining steps move up to replace the deleted step. Syntax AUTO:PAGE:DEL <NR1> Parameter/ <NR1> 1~16 (step no.#) Example AUTO:PAGE:DEL 3 Deletes the contents of step number #3. AUTO = 0 0 1 - 0 1 0 AUTO_ MANU_NAME ACW = 0 . 1 0 #02:001 #06:003 #04:004 MOVE SWAP SKIP DEL Set **AUTO:NAME** Query Sets or returns the AUTO name for the selected Description automatic test. The test must be in AUTO mode before this command can be used. Note only alphanumeric characters (A-Z, a-z, 0-9) and the " " underscore character can be used to set the AUTO test name. Syntax AUTO:NAME <string> **Query Syntax** AUTO:NAME? <string> 10 character string. (first character must Parameter/ Return parameter be a letter) Example AUTO:NAME program1

Sets the AUTO name to "program1".



AUTO:EDIT:A	DD Set →	
Description	Add the selected MANU test to the current AUI number.	O.
Syntax	AUTO:EDIT:ADD <nr1></nr1>	
Parameter/	<nr1> 1~100</nr1>	
Example	AUTO:EDIT:ADD 7	
	Adds MANU-007 to the current AUTO number. I.e. AUTO=005-007 AUTO_NAME MANU_NAME ACW=0.100kV HI_SET=01.00mA #01:010 #02:001 #03:003 #04:004 #05:007 #06: #07: #08: #09:07 #10: #11: #12: #13 #14: #15: #16: MOV SWAP SKIP DEL	,
	MANU test added to	
	last step	
	Set →	
TESTok:RETurr	1 Query	
Description	Allows "OK" to be displayed on the remote terminal when a test has stopped (PASS/FAIL of STOP). This applies for MANU and AUTO modern and AUTO	
Description	terminal when a test has stopped (PASS/FAIL o	
Description Syntax	terminal when a test has stopped (PASS/FAIL of STOP). This applies for MANU and AUTO mod	
	terminal when a test has stopped (PASS/FAIL of STOP). This applies for MANU and AUTO mod By default, TESTok:RETurn is set to OFF.	
Syntax	terminal when a test has stopped (PASS/FAIL of STOP). This applies for MANU and AUTO mod By default, TESTok:RETurn is set to OFF. TESTok:RETurn {ON OFF}	
Syntax Query Syntax Parameter/	terminal when a test has stopped (PASS/FAIL of STOP). This applies for MANU and AUTO mode By default, TESTok:RETurn is set to OFF. TESTok:RETurn {ON OFF} TESTok:RETurn? ON Enables the "OK" message to be	
Syntax Query Syntax Parameter/	terminal when a test has stopped (PASS/FAIL of STOP). This applies for MANU and AUTO mode. By default, TESTok:RETurn is set to OFF. TESTok:RETurn {ON OFF} TESTok:RETurn? ON Enables the "OK" message to be displayed.	



*SRE	→ Query
Description	AUTO MODE only. Use this command to get measurement step number at the current point in time during AUTO MODE testing.
	Example: User send command "*SRE" to GPT-9000 during AUTO mode
Query Syntax	*SRE?
Return parameter	<nr1> 00~16</nr1>
Example	*SRE?
	>5
	The current test step is number 5. This indicates that steps 1~4 have already been completed and the results for those steps can now be retrieved.



Common Commands

*CLS		<u>Set</u> →
Description	The *CLS	command clears the internal registers.
Syntax	*CLS	
*IDN		— Query
Description		he model number, serial number, and version of the tester.
Query Syntax	*IDN5	
Query Syntax Return parameter		Returns the instrument identification as a string in the following format:
		string in the following format:

Firmware version: V1.00



Remote Comm	ands
*RMTOFF	
*RMTOFF	(Set)→
Description	This command can be used to terminate a remote session. When this command is used "RMT" will no longer be displayed on the front panel, indicating that remote mode has been terminated.
Syntax	*RMTOFF
Special Functio	ns
INTerlock:PIN	—→Query
TIVI CITOCKIT IIV	, (, , , , , , , , , , , , , , , , , ,
Description	Queries if the physical interlock pin is shorted or not.
Query Syntax	INTerlock:PIN?
Return parameter	<pre><string> Returns: "PIN OFF": Interlock pin is Not shorted. or "PIN ON" Interlock pin is shorted.</string></pre>
Query Example	INT:PIN?
	>PIN ON Returns the Interlock pin is shorted.

FAQ

- The tester will not turn on.
- The panel keys are not working.
- When I press the START button the tester will not start testing?
- The accuracy does not match the specification.

The tester will not turn on.

Ensure the power cord is connected. Ensure the line input is set to the correct line voltage. Check to make sure the fuse is not blown. See page 167.

The panel keys are not working.

Ensure the tester is not in remote mode, page 119.

Ensure the tester is not in SIGNAL I/O or Remote Connect mode, page 103.

When I press the START button the tester will not start testing?

The tester must first be in the READY status before a test can be started. Ensure the tester displays READY before pressing the START button, page 64 (manual test), 91(automatic test).

If "Double Action" is enabled, the START button must be pressed 0.5 seconds after the STOP button is pressed, otherwise the tester will not start testing.



If "Interlock" is enabled, the interlock key must be inserted into the signal I/O port on the rear before a test can be started. See page 113 for details.

Lastly, ensure that the Start Ctrl setting is correctly configured in the Common Utility menu. For example, to enable the START button to start a test, ensure that the Start Ctrl setting is set to FRONT PANEL. See page 103 for details.

The accuracy does not match the specification.

Make sure the tester is powered on for at least 30 minutes, within +15°C~+35°C. This is necessary to stabilize the unit to match the specification.

For more information, contact your local dealer or GWInstek at www.gwinstek.com / marketing@goodwill.com.tw.

APPENDIX


Fuse Replacement

Steps


1. Turn the instrument off.



2. Remove the power cord.



3. Remove the fuse socket using a flat screwdriver.




4. Replace the fuse in the fuse holder.



5. Ensure the correct line voltage is lined up with the arrow on the fuse holder. Insert the fuse socket.





Rating The fuse for the GPT-98XX and the GPT-99XX/99XXA have different ratings:

GPT-98XX:	
100V/120V	T5A 250V
220V/230V	T2.5A 250V

GPT-99XX/99XXA:	
100V/120V	T10A 250V
220V/230V	T6.3A 250V

Error Messages

The following error messages or messages may appear on the GPT screen when configuring parameters or running tests. When status is attributed to Testing, the FAIL indicator on the front pannel of unit will be lit in red.

Error Messages	Status	Description
TIME ERR	Configuring	For ACW tests. GPT-98XX: TIME ERR is displayed when HI SET ≥ 30.00mA~40.00mA and if the RAMP / time and the TEST TIME setting is > 240 seconds. GPT-99XX/99XXA: TIME ERR is displayed when HI SET ≥ 80.00mA~100.0mA and if the RAMP / time and the TEST TIME setting is > 240 seconds.



OVER 50W (GPT-98XX)	Configuring	For DCW tests. OVER 50W is displayed if the HI SET setting multiplied by the Voltage setting is greater than 50W (GPT-98XX only).
OVER 100W (GPT-99XX/99XXA)	Configuring	For DCW tests. OVER 100W is displayed if the HI SET setting multiplied by the Voltage setting is greater than 100W (GPT-99XX/99XXA only).
I ERR	Testing	For ACW, DCW tests. Shown when the current is set too high.
SHORT [Serr]	Testing	Voltage is too low or there is no High Voltage output. Indicates that the DUT could be shorted.
V ERR	Testing	For ACW, DCW and IR tests. Indicates that an abnormal voltage has been detected.
V = 0	Testing	For GB tests. Voltage is equal to 0. Check to see that the SENSE H is not open.
R ERR	Testing	For IR tests. The voltage is too high or resistance= 0Ω . Check to see whether the DUT or test lead is shorting.
		For GB tests. The resistance is too high.
I <set< td=""><td>Testing</td><td>For GB tests. Current too low. Indicates that the SOURCE L or SOURCE H test lead is open or poorly connected. Test the test lead connection with the DUT to confirm.</td></set<>	Testing	For GB tests. Current too low. Indicates that the SOURCE L or SOURCE H test lead is open or poorly connected. Test the test lead connection with the DUT to confirm.
I>SET	Testing	For GB tests. Current is too high.
GBV OVER	Configuring	GBV > 5.4V



GPT-9000/9000A Specifications

The specifications apply when the GPT-9000/9000A is powered on for at least 30 minutes at 15°C~35°C.

Specifications

AC Withstanding Voltage

Environment		
Range	Temperature	Humidity
Warranty	15°C ~ 35°C	≤70% (No condensation)
Operation	0°C ~ 40°C	≤70% (No condensation)
Storage	-10°C ~ 70°C	≤85% (No condensation)
Installation Location	Indoors at an ampli	tude of up to 2000m.

Output Voltage Range	$0.050 \text{kV} \sim 5.000 \text{kV}^1$
Output Voltage Resolution	2V
Output Voltage Accuracy	\pm (1% of setting +5V) with no load
Maximum Rated Load(Table1)	200 VA (5kV/40mA) [GPT-98XX] 500 VA (5kV/100mA) [GPT-99XX/99XXA]
Maximum Rated Current	40mA [GPT-98XX], 100mA [GPT-99XX/99XXA] 0.001mA ~ 10mA(0.050kV≤V≤0.5kV) 0.001mA ~ 40mA(0.5kV <v≤5kv) [gpt-98xx]<br="">0.001mA ~ 100mA(0.5kV<v≤5kv) <br="" [gpt-99xx="">99XXA]</v≤5kv)></v≤5kv)>
Output Voltage Waveform	Sine wave
Frequency	50 Hz / 60 Hz
Voltage Regulation	± 1% +5V
	[Maximum rated load \rightarrow no load]
Voltmeter Accuracy	\pm (1% of reading+ 5V)

0.001mA~040.0mA [GPT-98XX]

0.001mA~100.0mA [GPT-99XX/GPT-99XXA]

Continued...

Current Measurement Range



Current Best Resolution	GPT-98XX: 1uA 0.001mA(0.001mA~1.100mA) 0.01mA(01.11mA~11.00mA) 0.1mA(011.1~040.0mA) GPT-99XX/GPT-99XXA: 1uA 0.001mA(0.001mA~1.100mA) 0.01mA(01.11mA~11.00mA) 0.01mA(01.11mA~11.00mA)
Current Measurement	GPT-98XX:
Accuracy	\pm (1.5% of rdg + 30 counts) when HI SET<1.11mA \pm (1.5% of rdg + 3 counts) when HI SET \geq 1.11mA
	GPT-99XX/GPT-99XXA:
	\pm (1.5% of rdg + 30 counts) when HI SET<1.11mA \pm (1.5% of rdg + 3 counts) when HI SET \geq 1.11mA
Current Offset	130uA Max.
Judgment Accuracy	± (3% of setting + 40uA)
Judgment Valid Range (ACW)	HI SET: 0.011mA to 1.100mA 00.11mA to 11.00mA 001.1mA to 040.0mA(GPT-99xx/99xxA is 100.0mA) LOW SET: 0.010mA to 1.099mA 00.10mA to 10.99mA 001.0mA to 039.9mA(GPT-99xx/99xxA is 099.9mA)
Window Comparator Method	Yes
ARC DETECT	Yes
Rise-time Control Function	Yes
RAMP (Ramp Time)	0.1~999.9s
TIMER (Test Time)	OFF ² , 0.5s~999.9s
GND	ON/OFF

¹ At least 0.5 seconds is needed to reach a set voltage of 50V/10mA.
² The timer can only be turned off under special MANU mode (MANU=***-000).



DC Withstanding Voltage	
Output Voltage Range	$0.050kV \sim 6.000kV^{1}$
Output Voltage Resolution	2V
Output Voltage Accuracy	\pm (1% of setting +5V) with no load
Maximum Rated Load (Table 1)	
	100W (5kV/20mA)[GPT-99XX/99XXA]
Maximum Rated Current	10mA [GPT-98XX, 20mA [GPT-99XX/99XXA] 0.001mA ~ 2mA (0.050kV ≤V≤0.5kV) 0.001mA ~ 10mA (0.5kV <v≤6kv)[gpt-98xx] (0.5kv<v≤6kv)[gpt-99xx="" 0.001ma="" 20ma="" 99xxa]<="" td="" ~=""></v≤6kv)[gpt-98xx]>
Voltmeter Accuracy	\pm (1% of reading+ 5V)
Voltage Regulation	± 1% +5V
	[Maximum rated load → no load]
Current Measurement Range	0.001mA~010.0mA [GPT-98XX]
	0.001mA~020.0mA [GPT-99XX/99XXA]
Current Best Resolution	GPT-98XX:
	luA
	0.001mA(0.001mA~1.100mA)
	0.01mA(01.11mA~11.00mA)
	CDT 00\\\\\\00\\\\
	GPT-99XX/99XXA:
	1uA
	0.001mA(0.001mA~1.100mA) 0.01mA(01.11mA~11.00mA)
	0.1mA(011.0mA~020.0mA)
Current Measurement	GPT-98XX:
Accuracy	\pm (1.5% of rdg + 30 counts) when HI SET <1.11mA
riccuracy	(1.5% of rdg + 3 counts) when HI SET \geq 1.11mA
	(
	GPT-99XX/99XXA:
	\pm (1.5% of rdg + 30 counts) when HI SET <1.11mA
	(1.5% of rdg + 3 counts) when HI SET \geq 1.11mA
Current Offset	150uA Max.
Judgment Accuracy	± (3% of setting + 40uA)
Judgment Valid Range (DCW)	HI SET:
	0.011mA to 1.100mA
	00.11mA to 10.00mA(GPT-99xx/99xxA 11.00mA)
	001.1mA to 020.0mA(GPT-99xx/99xxA only)
	LOW SET:
	0.010mA to 1.099mA
	00.10mA to 09.99mA(GPT-99xx/99xxA 10.99mA) 001.0mA to 019.9mA(GPT-99xx/99xxA only)
Window Comparator Method	Yes
ARC DETECT	Yes
, inc Defect	163



Rise-time Control Function	Yes
RAMP (Ramp Time)	0.1~999.9s
TIMER (Test Time)	OFF ² , 0.5s~999.9s
GND	ON/OFF


¹ At least 0 .5 seconds is needed to reach a set voltage of 50V/2mA.
² The timer can only be turned off under special MANU mode (MANU=***-000).

Insulation Re	esistance Test
---------------	----------------

IIISUIAUOII KE	sistance rest		
Output Voltage		50V~1000V *GPT-99X 125V test point.	X/99XXA also includes a
Output Voltage Resolution		50V	
Output Voltage Accuracy		(1% of setting+5V) wit	h no load
Resistance M	easurement	$1M\Omega$ ~ $9500M\Omega$ (GPT-	98XX)
Range		1MΩ~50GΩ (GPT-99)	XX/99XXA)
Test Voltage		Measurement Range	Accuracy
(GPT-98XX)			
	50V≤V≤450V	1~50MΩ 51~2000MΩ	\pm (5% of reading +1 count) \pm (10% of reading +1 count)
	500V≤V≤1000V	1~500MΩ 501~9500MΩ	\pm (5% of reading +1 count) \pm (10% of reading +1 count)
(GPT-99XX/9	9XXA)		(,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
	50V≤V≤450V	0.001~0.050GΩ 0.051~2.000GΩ	\pm (5% of reading +1 count) \pm (10% of reading +1 count)
	500V≤V≤1000V	0.001~0.500GΩ 0.501~9.999GΩ 10.00~50.00GΩ	\pm (5% of reading +1 count) \pm (10% of reading +1 count) \pm (20% of reading +1 count)
Test Voltage		Judgment Range	Accuracy
(GPT-98XX)		, ,	,
·	50V≤V≤450V	1~50MΩ 51~2000MΩ	\pm (5% of setting +1 count) \pm (10% of setting +1 count)
	500V≤V≤1000V	1~500MΩ 501~9500MΩ	\pm (5% of setting +1 count) \pm (10% of setting +1 count)
(GPT-99XX/ 9			
	50V≤V≤450V	0.001~0.050GΩ 0.051~2.000GΩ	\pm (5% of setting +1 count) \pm (10% of setting +1 count)
	500V≤V≤1000V	0.001~0.500GΩ 0.501~9.999GΩ 10.00~50.00GΩ	\pm (5% of setting +1 count) \pm (10% of setting +1 count) \pm (20% of setting +1 count)
Voltmeter Accuracy		\pm (1% of reading +5V)	
Output Impedance		600kΩ	
Window Comparator Method		Yes	
Rise-time Control Function		Yes	
RAMP (Ramp Time)		0.1~999.9s	
TIMER (Test Time)		0.5s~999.9s	
GND		OFF	



Ground Bond Test	
Output Current Range	03.00A~30.00A (GPT-98XX)
	03.00A~32.00A (GPT-99XX)
Output Current Accuracy	\pm (1% of setting +0.2A) when $3A \le I \le 8A$
	\pm (1% of setting +0.05A) when 8A <i<math display="inline">\leq30A</i<math>
	(GPT-98XX)
	\pm (1% of setting +0.05A) when 8A <i<math display="inline">\leq32A</i<math>
	(GPT-99XX)
Output Current Resolution	0.01A
Frequency	50Hz/60Hz selectable
Ohmmeter Measurement Accuracy	\pm (1% of reading +2m Ω)
Ohmmeter Judgment Accuracy	\pm (1% of setting +2m Ω)
Ohmmeter Measurement Range	10 m Ω ~650.0m Ω (depending on output current)



Test Voltage	Max. 6V(AC)open-circuit
Ohmmeter Measurement	$0.1 m\Omega$
Resolution	
Windows Comparator Method	Yes



TIMER (Test Time)	0.5s~999.9s
GND	OFF
Interface	
REMOTE (Remote terminal)	Yes
SIGNAL IO	Yes
RS232	Yes
USB (Device)	Yes
GPIB	Yes (OPTION)
General	
DISPLAY	240 x 64 dot matrix LED back light LCD
MEMORY	AUTO/MANU mode 100 memory blocks total
POWER SOURCE	AC100V/120V/220V/230V ±10%
	50Hz/60Hz
	Power Consumption:
	Max. 500VA [GPT-98XX]
	Max. 1000VA [GPT-99XX]
ACCESSORIES	Power cord x1, Quick Start Guide x1
	User Manual x1 (CD)
	GHT-114x1 for GPT-9801/9802/9803/9901A/
	9902A/9903/9903A
	GHT-114x1, GTL-115x1 for GTP-9804/9904
DIMENSIONS & WEIGHT	GPT-98XX: Approx. 330(W) x 148(H) x 452(D) mm
	(Max.), 19kg(Max)
	GPT-99XX: Approx. 330(W) x 148(H) x 587(D) mm
	(Max.), 27kg(Max)
	GPT-99XXA: Approx. 330(W) x 148(H)
	x 482(D) mm(Max), 24kg(Max)
	. ()(), =8()

Table 1a: Output Limitation in Withstanding Voltage Testing (GPT-98XX)

Table 14: Output Ellination in Withbarning Voltage Testing (CFT 2070)			
	Upper Current	Pause	Output Time
AC	30mA≤I≤40mA	At least as long as the output time	Maximum 240 seconds
	0.001mA≤l<30 mA	Not necessary	Continuous output possible
DC	0.001mA≤l≤10 mA	Not necessary	Continuous output possible



GB	15A <i≤30a< th=""><th>At least as long as the output time</th><th>999.9</th></i≤30a<>	At least as long as the output time	999.9
	3A≤l≤15A	Not necessary	999.9
NOTE: Output Time = Ramp T	ime + Test Time		

Table 1b: Output Limitation in Withstanding Voltage Testing (GPT-99XX/99XXA)

	Upper Current	Pause	Output Time
AC	80mA≤I≤100mA	At least as long as the output time	Maximum 240 seconds
	0.001mA≤l<80 mA	Not necessary	Continuous output possible
DC	0.001mA≤l≤20 mA	Not necessary	Continuous output possible
GB	15A <i≤32a (99XX)</i≤32a 	At least as long as the output time	999.9
	3A≤l≤15A	Not necessary	999.9


NOTE:

- Output Time = Ramp Time + Test Time.
- TIMER Accuracy: ± (100ppm + 20ms)

Table 1c: GPT-9000 Capacitive Load


		Maximum		
	Test Voltage DCW	HI-SET Current	RAMP Time 🦯	Capacitive Load
1	1.000kV	I≧1.00mA	T≧1.0s	0.35uF
2	2.000kV	I≧2.00mA	T≧1.0s	0.35uF
3	3.000kV	I≧3.00mA	T≧1.0s	0.35uF
4	4.000kV	I≧3.00mA	T≧1.0s	0.35uF
5	5.000kV	I≧3.00mA	T≧1.0s	0.25uF
6	6.000kV	I≧3.00mA	T≧1.0s	0.125uF

GPT-9801/9802/9803 Dimensions






GPT-9804 Dimensions




GPT-9903 Dimensions






GPT-9904 Dimensions



GPT-9901A/9902A/9903A Dimensions





Certificate Of Compliance

We

GOOD WILL INSTRUMENT CO., LTD.

declare that the CE marking mentioned product

satisfies all the technical relations application to the product within the

scope of council:

Directive: EMC; LVD; WEEE; RoHS

The product is in conformity with the following standards or other normative documents:

⊙ ЕМС			
EN 61326-1 :	Electrical equipment for measurement, control and laboratory use — EMC requirements		
Conducted & Radiated En EN 55011 / EN 55032	nission	Electrical Fast Transients EN 61000-4-4	
Current Harmonics EN 61000-3-2 / EN 6100	0-3-12	Surge Immunity EN 61000-4-5	
Voltage Fluctuations EN 61000-3-3 / EN 6100	0-3-11	Conducted Susceptibility EN 61000-4-6	
Electrostatic Discharge EN 61000-4-2		Power Frequency Magnetic Field EN 61000-4-8	
		Voltage Dip/ Interruption EN 61000-4-11 / EN 61000-4-34	
© Safety			
EN 61010-1: Safety requirements for electrical equipment for measurement, control and laboratory use - Part 1: General requirements			

GOODWILL INSTRUMENT CO., LTD.

No. 7-1, Jhongsing Road, Tucheng District, New Taipei City 236, Taiwan

Tel: +886-2-2268-0389 Fax: +886-2-2268-0639

GOODWILL INSTRUMENT (SUZHOU) CO., LTD.

No. 521, Zhujiang Road, Snd, Suzhou Jiangsu 215011, China Tel: <u>+86-512-6661-7177</u> Fax: <u>+86-512-6661-7277</u>

Web: http://www.instek.com.cn
Email: marketing@instek.com.cn

GOODWILL INSTRUMENT EURO B.V.

De Run 5427A, 5504DG Veldhoven, The Netherlands

Tel: <u>+31-(0)40-2557790</u> Fax: <u>+31-(0)40-2541194</u>

Email: sales@gw-instek.eu

NDEX

Accessories12
Automatic test
add test85
edit settings84
load82
page view88
results95
running a test91
saving87
test file name86
Caution symbol5
Cleaning the instrument7
Declaration of conformity 182
Dimensions
Disposal instructions7
EN61010
measurement category6
pollution degree7
Environment
safety instruction7
External control108
Interlock key114
overview109
remote operation110
remote terminal109
signal I/O operation113
signal I/O overview111
FAQ165
Front panel diagram15
GPIB installation25
Ground
symbol5
Interlock key114
Line voltage selection23
List of features11
Manual tests
ARC mode52
fail mode56

ground mode5
max hold5
overview3
pass hold5
ramp up time5
results6
running a test6
saving6
special mode7
sweep
sweep graph8
test filename5
test frequency4
test function4
test limits4
test reference4
test selection3
test settings4
test time4
test voltage4
timing diagrams7
Marketing
contact16
Menu tree3
Operating precautions2
Overview1
Package contents1
Power on/off
safety instruction
Rear panel diagram1
Remote control11
Command list12
Command syntax12
function check11
interface configuration11
Service operation
about disassembly
contact16
Specifications17



GPT-9000/9000A Series User Manual

Sweep function	77	key lock	103, 106
Test errors		LCD	99
UK power cord		RS232	
Utility settings		start control	103, 106
buzzer	100	USB	
Control settings		Warning symbol	
double action		Workplace precautions	26
GPIB		Zeroing	74
interface	102	-	