

PEL-3212 (No Rack) contains below parts

Model Name	Part Number	Quantity	Description
PEL-3111	01EL311100GT	2	1KW LOAD

Connection & Structure Accessory:

Model Name	Part Number	Quantity	Description
PEL-005	11EL-00500101	1	Bus Bar Connector
PEL-006	11EL-00600101	1	Bus Bar Connector
GRA-414-E	01RA414E000GT	2	PEL-3111 3U Frame(Optional)

PEL-3323 (No Rack) contains below parts

Model Name	Part Number	Quantity	Description
PEL-3111	01EL311100GT	3	1KW LOAD

Connection & Structure Accessory:

Model Name	Part Number	Quantity	Description
PEL-005	11EL-00500101	1	Bus Bar Connector
PEL-006	11EL-00600101	1	Bus Bar Connector
PEL-007	11EL-00700101	1	Bus Bar Connector
GRA-414-E	01RA414E000GT	3	PEL-3111 3U Frame(Optional)

PEL-3424 (No Rack) contains below parts

Model Name	Part Number	Quantity	Description
PEL-3111	01EL311100GT	4	1KW LOAD

Connection & Structure Accessory:

Model Name	Part Number	Quantity	Description
PEL-005	11EL-00500101	1	Bus Bar Connector
PEL-006	11EL-00600101	1	Bus Bar Connector
PEL-007	11EL-00700101	2	Bus Bar Connector
GRA-414-E	01RA414E000GT	4	PEL-3111 3U Frame(Optional)

PEL-3535 (No Rack) contains below parts

Model Name	Part Number	Quantity	Description
PEL-3111	01EL311100GT	5	1KW LOAD

Connection & Structure Accessory:

Model Name	Part Number	Quantity	Description
PEL-005	11EL-00500101	1	Bus Bar Connector
PEL-006	11EL-00600101	1	Bus Bar Connector
PEL-007	11EL-00700101	3	Bus Bar Connector
GRA-414-E	01RA414E000GT	5	PEL-3111 3U Frame(Optional)

PEL-3322 (No Rack) contains below parts

Model Name	Part Number	Quantity	Description
PEL-3111	01EL311100GT	1	1KW LOAD Master
PEL-3211	01EL321100GT	1	2KW LOAD Booster

Connection & Structure Accessory:

Model Name	Part Number	Quantity	Description
PEL-005	11EL-00500101	1	Bus Bar Connector
PEL-008	11EL-00800101	1	Bus Bar Connector
GRA-413-E	01RA4130000GT	1	PEL-3111 3U Frame(Optional)
GRA-414-E	01RA414E000GT	1	PEL-3111 3U Frame(Optional)

PEL-3533 (No Rack) contains below parts

Model Name	Part Number	Quantity	Description
PEL-3111	01EL311100GT	1	1KW LOAD Master
PEL-3211	01EL321100GT	2	2KW LOAD Booster

Connection & Structure Accessory:

Model Name	Part Number	Quantity	Description
PEL-005	11EL-00500101	1	Bus Bar Connector
PEL-007	11EL-00700101	1	Bus Bar Connector
PEL-008	11EL-00800101	1	Bus Bar Connector
GRA-413-E	01RA4130000GT	2	PEL-3111 3U Frame(Optional)
GRA-414-E	01RA414E000GT	1	PEL-3111 3U Frame(Optional)

PEL-3744 (No Rack) contains below parts

Model Name	Part Number	Quantity	Description
PEL-3111	01EL311100GT	1	1KW LOAD Master
PEL-3211	01EL321100GT	3	2KW LOAD Booster

Connection & Structure Accessory:

Model Name	Part Number	Quantity	Description
PEL-005	11EL-00500101	1	Bus Bar Connector
PEL-006	11EL-00600101	1	Bus Bar Connector
PEL-008	11EL-00800101	1	Bus Bar Connector
PEL-009	11EL-00900101	1	Bus Bar Connector
GRA-413-E	01RA4130000GT	3	PEL-3111 3U Frame(Optional)
GRA-414-E	01RA414E000GT	1	PEL-3111 3U Frame(Optional)

PEL-3955 (No Rack) contains below parts

Model Name	Part Number	Quantity	Description
PEL-3111	01EL311100GT	1	1KW LOAD Master
PEL-3211	01EL321100GT	4	2KW LOAD Booster

Connection & Structure Accessory:

Model Name	Part Number	Quantity	Description
PEL-005	11EL-00500101	1	Bus Bar Connector
PEL-006	11EL-00600101	1	Bus Bar Connector
PEL-007	11EL-00700101	1	Bus Bar Connector
PEL-008	11EL-00800101	1	Bus Bar Connector
PEL-009	11EL-00900101	1	Bus Bar Connector
GRA-413-E	01RA4130000GT	4	PEL-3111 3U Frame(Optional)
GRA-414-E	01RA414E000GT	1	PEL-3111 3U Frame(Optional)