

Spectrum Analyzer

GSP-930

USER MANUAL

REVISION 1.1 APRIL 2012



ISO-9001 CERTIFIED MANUFACTURER

GW INSTEK

This manual contains proprietary information, which is protected by copyright. All rights are reserved. No part of this manual may be photocopied, reproduced or translated to another language without prior written consent of Good Will company.

The information in this manual was correct at the time of printing. However, Good Will continues to improve products and reserves the rights to change specification, equipment, and maintenance procedures at any time without notice.

Good Will Instrument Co., Ltd.
No. 7-1, Jhongsing Rd., Tucheng Dist., New Taipei City 236, Taiwan.

Table of Contents

SAFETY INSTRUCTIONS	3
GETTING STARTED	8
GSP-930 Introduction	9
Accessories.....	11
Appearance.....	13
First Use Instructions	24
BASIC OPERATION	36
Frequency Settings.....	39
Span Settings.....	43
Amplitude Settings	46
Autoset	59
Bandwidth/Average Settings	61
Sweep	66
Trace.....	72
Trigger	79
Marker	84
Display.....	98
System Settings	105
Preset	109
ADVANCED OPERATION	111
Measurement.....	112
Limit Line Testing	159
Sequence	165
Tracking Generator	170
Power Meter	173
FILE	178
File Overview	178

REMOTE CONTROL	194
Interface Configuration	195
FAQ	205
APPENDIX	206
Replace the Clock Battery	206
Glossary of Acronyms	207
GSP-930 Default Settings	209
Menu Tree.....	211
GSP-930 Specifications	240
GSP-930 Dimensions	249
Declaration of Conformity	250
INDEX	251

S SAFETY INSTRUCTIONS

This chapter contains important safety instructions that you must follow during operation and storage. Read the following before any operation to insure your safety and to keep the instrument in the best possible condition.

Safety Symbols

These safety symbols may appear in this manual or on the instrument.



WARNING

Warning: Identifies conditions or practices that could result in injury or loss of life.



CAUTION

Caution: Identifies conditions or practices that could result in damage to the instrument or to other properties.



DANGER High Voltage



Attention Refer to the Manual



Earth (ground) Terminal



Frame or Chassis Terminal



Do not dispose electronic equipment as unsorted municipal waste. Please use a separate collection facility or contact the supplier from which this instrument was purchased.

Safety Guidelines

General Guideline



CAUTION

- Do not place any heavy object on the instrument.
- Avoid severe impact or rough handling that leads to damaging the instrument.
- Do not discharge static electricity to the instrument.
- Use only mating connectors, not bare wires, for the terminals.
- Ensure signals to the RF input do not exceed +30dBm.
- Ensure reverse power to the TG output terminal does not exceed +30dBm.
- Do not supply any input signals to the TG output.
- Do not block the cooling fan opening.
- Do not disassemble the instrument unless you are qualified.

(Measurement categories) EN 61010-1:2010 specifies the measurement categories and their requirements as follows. The instrument falls under category II.


- Measurement category IV is for measurement performed at the source of low-voltage installation.
- Measurement category III is for measurement performed in the building installation.
- Measurement category II is for measurement performed on the circuits directly connected to the low voltage installation.
- Measurement category I is for measurements performed on circuits not directly connected to Mains.

Power Supply



WARNING

- AC Input voltage range: 100V~240V
 - Frequency: 50/60Hz
 - To avoid electrical shock connect the protective grounding conductor of the AC power cord to an earth ground.
-

- Battery
- Rating: 10.8V, 6 cell Li-ion battery
 - Turn off the power and remove the power cord before installing or removing the battery.
-  CAUTION
-

- Cleaning
- Disconnect the power cord before cleaning.
 - Use a soft cloth dampened in a solution of mild detergent and water. Do not spray any liquid.
 - Do not use chemicals containing harsh material such as benzene, toluene, xylene, and acetone.
-

- Operation Environment
- Location: Indoor, no direct sunlight, dust free, almost non-conductive pollution (Note below)
 - Temperature: 5°C to 45°C
 - Humidity: <90%
- (Pollution Degree) EN 61010-1:2010 specifies the pollution degrees and their requirements as follows. The instrument falls under degree 2.
- Pollution refers to “addition of foreign matter, solid, liquid, or gaseous (ionized gases), that may produce a reduction of dielectric strength or surface resistivity”.
- Pollution degree 1: No pollution or only dry, non-conductive pollution occurs. The pollution has no influence.
 - Pollution degree 2: Normally only non-conductive pollution occurs. Occasionally, however, a temporary conductivity caused by condensation must be expected.
 - Pollution degree 3: Conductive pollution occurs, or dry, non-conductive pollution occurs which becomes conductive due to condensation which is expected. In such conditions, equipment is normally protected against exposure to direct sunlight, precipitation, and full wind pressure, but neither temperature nor humidity is controlled.
-

- Storage environment
- Location: Indoor
 - Temperature: -20°C to 70°C
 - Humidity: <90%
-

Disposal

Do not dispose this instrument as unsorted municipal waste. Please use a separate collection facility or contact the supplier from which this instrument was purchased. Please make sure discarded electrical waste is properly recycled to reduce environmental impact.

Power cord for the United Kingdom

When using the instrument in the United Kingdom, make sure the power cord meets the following safety instructions.

NOTE: This lead/appliance must only be wired by competent persons




WARNING: THIS APPLIANCE MUST BE EARTHED

IMPORTANT: The wires in this lead are coloured in accordance with the following code:

Green/ Yellow:	Earth
Blue:	Neutral
Brown:	Live (Phase)



As the colours of the wires in main leads may not correspond with the coloured marking identified in your plug/appliance, proceed as follows:

The wire which is coloured Green & Yellow must be connected to the Earth terminal marked with either the letter E, the earth symbol  or coloured Green/Green & Yellow.

The wire which is coloured Blue must be connected to the terminal which is marked with the letter N or coloured Blue or Black.

The wire which is coloured Brown must be connected to the terminal marked with the letter L or P or coloured Brown or Red.


If in doubt, consult the instructions provided with the equipment or contact the supplier.

This cable/appliance should be protected by a suitably rated and approved HBC mains fuse: refer to the rating information on the equipment and/or user instructions for details. As a guide, a cable of 0.75mm² should be protected by a 3A or 5A fuse. Larger conductors would normally require 13A types, depending on the connection method used.

Any exposed wiring from a cable, plug or connection that is engaged in a live socket is extremely hazardous. If a cable or plug is deemed hazardous, turn off the mains power and remove the cable, any fuses and fuse assemblies. All hazardous wiring must be immediately destroyed and replaced in accordance to the above standard.

GETTING STARTED

This chapter provides a brief overview of the GSP-930, the package contents, instructions for first time use and an introduction to the front panel, rear panel and GUI.



GSP-930 Introduction	9
Main Features.....	9
Accessories	11
Package Contents	12

GSP-930 Introduction

The GSP-930 is the most advanced spectrum analyzer GW Instek has produced to date. The GSP-930 features a split window display to view data in spectrum, topographic or spectrographic views.

Main Features

- | | |
|-------------|--|
| Performance | <ul style="list-style-type: none">• 9kHz~3GHz bandwidth• 1Hz resolution• Nominal RBW accuracy of 5% <750kHz, 8% @>750kHz• Video bandwidth 1Hz~1MHz (10 steps)• Amplitude measurement range: DANL~30dBm (frequency dependent)• Input attenuation: 0 ~ 50dB• Phase noise: < -88dBc/Hz@1GHz, 10kHz |
| Features | <ul style="list-style-type: none">• 10%-step increments for RBW bandwidth• Three display modes: Spectrum, Topographic and Spectrographic• Split window display• Built-in EMI filter• Auto Wake-up• Built-in preamplifier• Gate sweep• Marker Frequency counter• Two operating modes: Spectrum and Power Meter mode• SEM measurement• ACPR measurement• OCBW measurement |
-

- Channel power measurement
 - Demodulation analyzer
 - Diverse marker functions and features with Peak Table
 - Sequence function to automatically perform pre-programmed sequential operations
 - Optional battery operation
-

Interface

- 8.4 color LCD (800×600)
- On-screen menu icons
- DVI-I video output
- RS-232 with RTS/CTS hardware flow control
- USB 2.0 with support for USB TMC
- LAN TCP/IP with LXI support
- Optional GPIB/IEEE488 interface
- IF output @ 886MHz
- Headphone output
- REF (reference clock) input/output BNC ports
- Alarm/Open collector output BNC port
- Trigger/Gate input BNC ports
- RF N-type input port
- Tracking generator output
- DC +7V/500mA output SMB port


Accessories

Standard Accessories	Part number	Description
	Region dependant	User manual
	Region dependant	Power cord
Options	Option number	Description
	Opt1.	Tracking generator
	Opt2.	Battery (11.1V/5200mAH Li-ion battery)
	Opt3.	GPIB interface (IEEE 488 bus)
Optional Accessories	Part number	Description
	PWS-06	USB Average Power Sensor (up to 6200 MHz; -32 to 20 dBm)
	GRA-415	6U Rack mount kit

Package Contents

Check the contents before using the GSP-930.

Opening the box




Contents (single unit)



- Main unit
(may include optional GPIB, TG output)
- Quick Start manual
- User Manual CD
- Power cord x1 (region dependent)
- Optional battery pack
- Calibration certificate


Appearance

GSP-930 Front Panel












LCD display 800×600 color LCD display. The display shows the soft keys for the current function, frequency, amplitude and marker information.

Function keys  ~  The F1 to F7 function keys directly correspond to the soft keys on the right-hand side of display.


Main keys  Sets the center frequency, start frequency, stop frequency, center frequency step and frequency offset values.

	Span	Sets the span, with options for full span, zero span and last span.
	Amplitude	Sets the amplitude reference level, attenuation, pre-amplifier controls, scale and other options for attenuation and scale.
	Autoset	Automatically searches the peak signal with maximum amplitude and displays it with appropriate horizontal and vertical scales.
<hr/>		
Control keys	BW/Avg	Sets the resolution bandwidth, video bandwidth, average type and turns the EMI filter on/off.
	Sweep	Sets the sweep time and gate time.
	Trace	Sets traces and trace related functions.
	Display	The Display key configures the windowing mode and basic display properties.
	Meas	Accesses measurement options such as ACPR, OCBW, demodulation measurements, SEM, TOI and other advanced measurements.
	Limit Line	Sets and tests Pass/Fail limit lines.
	Sequence	Access, set and edit program sequences.

		Sets the triggering modes.
File		File utilities options
		The Quick Save utility allows you to save either the state, trace, screen limit line, correction or sequence with only a single press.
		Save the trace, state etc., and save options.
		Recall the trace, state etc., and recall options.
Marker		Turns the Markers on/off and configures the markers.
		The <i>Marker-></i> key positions the markers on the trace.
		Finds each maximum and minimum peak. Used with the Marker function.
State	 LOCAL	The <i>Preset</i> key will restore the spectrum analyzer to the Factory or User-defined settings.
		The Preset key will also return the instrument back to local control after it has been in remote control mode.




The *Mode* key sets the spectrum analyzer to either Spectrum or Power Meter mode.




The *System* key shows system information, settings and other system related functions.

Power key




Turns the instrument on/off.

Scroll wheel




Edit values, select listed items.

Arrow keys



Increment/decrement values (in steps), select listed items.


RF input terminal



RF input port. Accepts RF inputs.

- Maximum input: +33dBm
- Input impedance: 50Ω
- Maximum DC voltage: ±50V
- N-type: female


DC power supply



SMB port supplies power for optional accessories.


- DC +7V
- 500mA Max.

Numeric keypad



The numeric keypad is used to enter values and parameters. It is often used in conjunction with the arrow keys and scroll wheel.

TG output port



The Tracking Generator (TG) output source.


- N-type: female
- Input impedance: 50Ω
- Output power: -50dBm to 0dBm
- Maximum reversed power: +30dBm

USB A, Micro SD




USB A port, Micro SD port for saving/recalling settings/files.

Rear Panel



RS232




RS232 9 pin DSUB port.

IF OUT



SMA IF Out port.


DVI-I



DVI video out port. Supports SVGA (800X600) @ 60Hz.


Fan

Power Socket



Power Socket:
100~240V, 50/60Hz.

Battery pack



Voltage: 10.8V
Capacity: 5200mAh

REF IN



BNC female reference input.

REF OUT



BNC female reference output:
10MHz, 50Ω impedance

Security Lock



ALARM OUT



BNC female open collector Alarm
output.

TRIG IN/GATE IN



BNC female 3.3V CMOS trigger
input/gated sweep input.

Phone



3.5mm stereo headphone jack
(wired for mono operation)

USB B




USB B Device port. USB 1.1/2.0

LAN



RJ-45 10Base-T/100Base-Tx

Display



- Reference level Displays the reference level. For details, see page 46.





- Attenuation Displays the vertical scale (attenuation) of the input signal. For details, see page 47.

- Date/Time Displays the date and time. See page 106 for details.











- Marker information Displays marker information. For details see page 83.











- LXI icon This icon indicates the status of the LXI connection. For details, see page 196.

- Function menu Soft menu keys associated with the F1 to F7 function keys to the right of the display.

Sweep settings		Sweep icon that shows the sweep status. See page 66 for details.
Trigger settings		Trigger icon that shows the trigger status. See page 79 details.
Pre-amp settings		Pre-amplifier icon that shows the Pre-amplifier status. See from page 48 for details.
Trace and detection settings		Trace icon that shows the trace type and the detection mode used for each trace. See from page 72 for details.
Status Icons	Displays the interface status, power source status, and alarm status, etc. See the Status Icon Overview on page 22 for a list of the status icons.	
Frequency/ Bandwidth settings	Displays the Start, Center and Stop frequencies, RBW, VBW, Span and Sweep settings.	
Entry/Message area	This area is used to show system messages, errors and input values/parameters.	
Trace and waveforms	Main display showing the input signals, traces (page 72), limit lines (159) and marker positions (83).	

Status Icon Overview

PreAmp		Indicates that the pre amplifier is on.
AC		Shown when running on AC power.
AC Charge		Shown when the AC power is charging the battery.
Alarm Off		Alarm buzzer output is currently off.
Alarm On		Alarm buzzer output is currently on.
Amplitude Offset		Indicates that the amplitude-shift is active. This icon appears when amplitude-related functions are used: Reference level offset Amplitude Correction Input Z = 75Ω Input Z cal >0
Battery indicator	 ~ 	Indicates the battery charge.
Bandwidth Indicator		Indicates that the RBW or VBW settings are in manual mode.
Average		Indicates that the Average function is active.

External Lock		Indicates that the system is now locked and refers to the external reference input signal
External Trigger		External trigger signal is being used.
Math		Trace math is being used.
Sequence Indicator		Shown when a sequence is running.
Sweep Indicator		Indicates that the sweep time is manually set.
Tracking generator		Indicates the tracking generator is turned on.
TG Normalization		Indicates that the tracking generator has been normalized.
Wake-up clock		Indicates that the wake-up clock is turned on.
USB		Indicates that a USB flash drive is inserted into the front panel and is recognized.
Micro SD		Indicates that a micro SD card is inserted into the front panel and is recognized.


First Use Instructions

Use the procedures below when first using the GSP-930 to tilt the stand, insert the battery pack, power up the instrument, setting the internal clock, the wake-up clock, updating the firmware and restoring the default settings. Lastly, the Conventions sections will introduce you to the basic operating conventions used throughout the user manual.


Tilting the Stand

Description The GSP-930 has two adjustable rubber feet that can be used to position the instrument into two preset orientations.

Upright Position Tuck the feet under the bottom of the instrument to stand the instrument upright.




Leaning Position Pull the feet back to have the instrument leaning back.




Inserting the Battery Pack

Description The GSP-930 has an optional battery pack. The battery should be inserted before power is connected to the AC power socket and before the unit is turned on.

- Steps**
1. Ensure the power is off and the AC power is disconnected.
 2. Remove the battery cover.
 3. Insert the battery as shown in the diagram below.
 4. Replace the battery cover.

Display Icon  The battery icon is displayed when GSP-930 is running on battery power.


Insertion Diagram




Power UP

Steps

1. Insert the AC power cord into the power socket.
2. The power button exterior will be lit blue to indicate that the GSP-930 is in standby mode.



3. Press the power button to turn the GSP-930 on.
4. The power button will turn orange and the GSP-930 will start to boot up.



It takes approximately 1.5 minutes for the GSP-930 to fully startup.

Power Down

Description The GSP-930 has two methods to power down: Normal and Forced Power Down.

The normal power down method will save the system state and end any running processes. The state is saved for the next time the instrument is turned back on.

The forced power down method only does a minimum state save.

Normal Power Down

Press the power button. The system will automatically handle the power down procedure in the following order:

- The system state is saved.
- Outstanding processes are closed in sequence.
- The LCD backlight is turned off.
- The system enters standby mode (the power key changes from orange to blue).



Note

The process takes ~10 seconds.

Forced Power Down

Press and hold the power button for ~4 seconds until the system turns off and the power button turns blue.




Note

The forced down mode might cause the GSP-930 to perform a longer system check the next time it is powered up.

Setting the Date, Time and Wake-Up Clock

Description The GSP-930 can be setup to power-up automatically using the Wakeup Clock function. This feature is useful to wake-up the instrument early and eliminate settling time.

System Date Example: Set the System Date to March 1, 2012


1. Press  > *Date/Time*[F4] > *Set Date*[F1] > *Year*[F1].
 2. Press *2012* > *Enter*[F1].
 3. Press *Month*[F2] > *3* > *Enter*[F1].
 4. Press *Day*[F3] > *1* > *Enter*[F1].
 5. Press *Return*[F7].
-



Note

The System Date will be shown at the top of the display.

System Time Example: Set the System Time to 9.00 AM

1. Press  > *Date/Time*[F4] > *Set Time*[F2] > *Hour*[F1].
2. Press *9* > *Enter*[F1].
3. Press *Minute*[F2] > *0* > *Enter*[F1].
4. Press *Second*[F3] > *0* > *Enter*[F1].
5. Press *Return*[F7].




Note

The System Time will be shown at the top of the display.

System Wake-Up
Clock

Example: Set the GSP-930 to wake up at 9.00 AM

1. Press  > *Date/Time*[F4] > *Wake-Up Clock*[F3] > *Clock*[F1].
 2. Press *Clock*[F1] to choose a clock (1 ~ 7).
 3. Press *State*[F2] to turn the clock on/off.
 4. Press *Hour*[F3] > 9 > *Enter*[F1].
 5. Press *Minute*[F4] > 0 > *Enter*[F1].
 6. Press [F5] and choose *Rept.* (Repeat) or *Single*.
 7. Press *Select Date*[F6] and select a day.
 8. Press *Return*[F7] to save the Wake-Up Clock settings.
-



Note

The system time is kept with the CR2032 clock battery. If the system time/ wake up clock can no longer be set, please replace the clock battery. See page 206.

Firmware Update

Description The GSP-930 allows the firmware to be updated by end-users. Before using the GSP-930, please check the GW Instek website or ask your local distributor for the latest firmware.

System version Before updating the firmware, please check the firmware version.

1. Press **(System)** > *System Information* [F1].
2. The firmware will be listed on the display.



3. Press any other key to exit out of the System Information screen.
4. To upgrade the firmware, insert the new firmware onto a USB flash drive or Micro SD card and put the drive/ card into the appropriate front panel port. The firmware files should be located in a directory named "gsp930".
5. Press **(System)** > *More 1/2* [F7] > *Upgrade* [F3].

6. The spectrum analyzer will automatically find the firmware on the USB flash drive and start to update the firmware. When finished, the message “Upgrade is finished” will be shown at the bottom of the screen followed by “Rebooting”.



7. The system will automatically restart after the rebooting message.



Note

The upgrade process may take a few minutes.


Restoring Default Settings

Description

The factory default settings or user-defined presets can be easily restored using the Preset key on the front panel. By default, the factory default settings are restored with the Preset key.

For details on how to configure the preset settings, please see page 109.


Steps

1. Press .
2. The spectrum analyzer will load the preset settings.


Conventions

The following conventions are used throughout the user manual. Read the conventions below for a basic grasp of how to operate the GSP-930 menu system and front panel keys.

Soft Menu keys The F1 to F7 function keys on the right side of the display correspond directly to the soft-menu keys on their left.



Input Parameter Values



Selecting this type of menu key will allow you to enter a new value with the numeric keypad or increment/decrement the value using the scroll wheel.

Toggle State




Pressing this menu key will toggle the state.

Toggle State &
Input Parameter



Pressing this menu key will allow you to toggle the state of the function between Auto and Man(ual) state. When in the Man state, the parameter value can be manually edited. Use the numeric keypad to enter the new value or use the scroll wheel to increment/decrement the current value.

Sub Menu




Pressing this menu key will enter a submenu.

Sub Menu to
select parameter




Pressing this menu key will enter a submenu to select a parameter.

Active Function



Pressing this type of menu key will activate that function. The menu key will be highlighted to show it is the active function.

Parameter input



Parameter values can be entered using the numeric keypad, the scroll wheel and occasionally with the arrow keys.

Using the numeric keypad

When prompted to enter a parameter, use the number keys (0~9), the decimal key (.) and the sign key (+/-) to enter a value. After a value has been entered, the soft-menu keys can be used to select the units.

The value of the parameter is shown at the bottom of the screen as it is edited.



Edited parameter

Back Space

Use the backspace key to delete the last character or number entered.

Using the scroll wheel

Use the scroll wheel to alter the current value. Clockwise increases the value, anti-clockwise decreases the value.

Directional arrows

Use the directional arrows to select discrete parameters or to alter values by a coarser resolution than the scroll wheel. Left decreases the value, right increases the value.

BASIC OPERATION

Frequency Settings	39
Center Frequency	39
Start and Stop Frequency	40
Center Frequency Step	41
Frequency Offset	42
Span Settings	43
Span	43
Full Span	44
Zero Span	44
Last Span	45
Amplitude Settings	46
Reference Level	46
Attenuation	47
Scale/Div	48
Scale Type	48
View Scale	49
Vertical Scale Units	50
Reference Level Offset	50
Amplitude Correction	51
Create a Correction Set	52
Amplitude Correction On/Off	54
Delete Correction Set	55
Save Correction Set To Memory	55
Recall Correction Set From Memory	56
Input Impedance	56
Input Impedance Calibration	57
Using the Built-in Pre-Amplifier	57
Autoset	59
Using Autoset	59
Limiting the Autoset Vertical Search Range	60

Limiting the Autoset Horizontal Search Range.....60

Bandwidth/Average Settings 61

Resolution Bandwidth Setting (RBW).....61

Video Bandwidth Settings (VBW)62

VBW/RBW Ratio62

Average Trace.....63

Average Type65

EMI Filter.....66

Sweep..... 66

Sweep Time.....66

Single Sweep.....67

Continuous Sweep68

Gated Sweep Overview.....68

Using the Gated Sweep Mode70

Trace 72

Selecting a Trace.....72

Trace Math74

Trace Detection Mode75

Trigger..... 79

Selecting a Trigger Type.....79

 Free Run Mode.....79

 Activate Video Trigger79

 Activate External Trigger.....81

Selecting the Trigger Mode82

Set the Trigger Delay Time83

Marker..... 84

Activating a Marker.....85

 Activate a Normal Marker85

 Move Marker Manually86

 Move Marker to Preset Locations.....86

 Activate Delta Marker87

 Move Delta Marker(s)Manually88

Marker Functions89

 Marker Noise89

 Frequency Counter90

Move Marker to Trace91

Show Markers in Table92

Peak Search93

Move Marker to Peak	93
Move Marker and Peak to Center	93
Search for Peaks	94
Peak Configuration	95
Peak Table	96

Display 98

Adjusting the LCD Brightness.....	98
Turning the LCD Backlight Off.....	98
Setting a Display Line (Reference Level Line)	99
Using the Video Out Port.....	99
Setting the Display Mode.....	100
Split Spectrum View	103

System Settings 105

System Information	105
Error Messages	105
Set the System Language.....	106
Set the Date and Time.....	106
Using the Wake-Up Clock.....	107
Alarm Output.....	108

Preset 109

Using the Preset Key	109
Save the User Preset Settings	109
Preset Type Settings.....	110
Power on Preset Settings	110

Frequency Settings

Center Frequency

Description The center frequency function sets the center frequency and centers the display to the center frequency.

Operation 1. Press **Frequency** > **Center[F1]** and enter the frequency and unit.

Range: 0kHz~3GHz
 Resolution: 1Hz
 Default 1.5GHz

Display

Center frequency



Set Center Frequency

Start and Stop Frequency

Description The start/stop frequency function will set the start and stop frequency of the span.


- Operation**
1. To set the start frequency, press **Frequency** > *Start Freq[F2]* and enter the frequency and unit.
 2. To set the stop frequency, press **Frequency** > *Stop Freq[F3]* and enter the frequency and unit.

Range: 0kHz~3GHz
 Resolution: 1Hz
 Default Start frequency: 0Hz
 Default Stop frequency: 3GHz

Display

Start Frequency

Stop Frequency



Start Frequency

Stop Frequency

 **Note**

The start and stop frequency can change when the span settings are used.
 The stop frequency must be set higher than the start frequency (for spans $\neq 0$), otherwise the span will be automatically set to 100Hz.

Center Frequency Step

Description The CF Step function sets the step size of the center frequency when using the arrow keys.

When the arrow keys are used to alter the center frequency, each press will move the center frequency by the step size specified by the CF Step function.

In auto mode, the center frequency step size is equal to 10% (1 division) of the span.

- Operation**
1. Press **Frequency** > *CF Step*[F4] and set the CF Step to Auto or Man.
 2. If Man was selected, set the frequency and unit of the center frequency step size.

Manual Range: 100Hz~3GHz
 Auto range: 1/10 of span frequency

Display



Frequency Offset

Description The Freq Offset function allows you to add an offset to the Center, Start and Stop frequencies as well as the marker frequencies. The offset value does not affect displaying the trace on the display.

Operation 1. Press **Frequency** > *Freq Offset[F5]* and set the offset value.

The Center, Start, Stop and Marker frequencies are updated accordingly.

Offset Range: 0Hz~100GHz

Display



Span Settings

Span


Description The Span function will set the frequency range of the sweep. The sweep will be centered around the center frequency.

Setting the span will alter the start and stop frequencies.

Operation 1. Press **Span** > *Span[F1]* and enter the span frequency range and unit.

Range: 0kHz~3GHz
 Resolution: 1Hz
 Default Span: 3GHz


Display



Full Span


Description The Full Span function will set the span to the full frequency range.

 This function will set the start and stop frequencies to 0Hz and 3GHz respectively.

Operation 1. Press  > *Full Span*[F2].

Zero Span


Description The Zero Span function will set the frequency range of the sweep to 0Hz and fixes the start and stop frequencies to the center frequency. The Zero Span function measures the time domain characteristics of the input signal at the center frequency. The horizontal axis is displayed in the time domain.

Operation 1. Press  > *Zero Span*[F3].

 The span changes accordingly.

Display

Time domain



0Hz Span

Example: Amplitude modulation



Note

The measurement functions such as TOI, SEM, CNR, CTB, CSO, ACPR, OCBW, phase, Jitter and NdB are not available with the zero span setting:

Last Span

Description

The last span function returns the spectrum analyzer to the previous span settings.

Operation

1. Press Span > *Last Span*[F4].

Amplitude Settings

The vertical display scale is defined by the reference level amplitude, attenuation, scale and external gain/loss.


Reference Level

Description The reference level defines the absolute level of the amplitude on the top graticule in voltage or power.

Operation 1. Press **Amplitude** > *Ref Level*[F1] and enter the reference level amplitude and unit.

Range: -120dBm ~ 30dBm
Units: dBm, W, V, dBmV, dBuV
Resolution: 1dBm

Display Ref Level reading Reference Level



Attenuation


Description The attenuation of the input signal level can set to automatic (Auto) or manual (Man). When the attenuation is set to Man, the input attenuator can be changed manually in 1dB steps.

- Operation**
1. Press **Amplitude** > *Attenuation*[F2] and select Auto or Man.
 2. If Man was selected, enter the attenuation level and unit.

Range: 0dBm ~ 50dBm
Units: dBm
Resolution: 1dB


Display

Attenuation level



Scale/Div

Description Sets the logarithmic units for the vertical divisions when the scale is set to Log.

Operation 1. Press  > *Scale/Div*[F3] repeatedly to select the vertical division units.

Unit Range: 10, 5, 2, 1

Display Scale




Note

The Scale/Div function is only selectable when the scale is set to Log (logarithmic).

Scale Type

Description Sets the vertical scale in linear or logarithmic units.
By default the linear scale is set to volts and the logarithmic scale is set to dBm.

Operation 1. Press  > *Scale Type*[F4] and set the vertical scale to Log or Lin.



Note

If the unit scale is changed (i.e. dBm → volts), the *displayed* vertical scale type will remain in the set linear or logarithmic setting.


View Scale

Description The Scale function turns the vertical scale on/off. The value of each graticule division is displayed with same units used for the Ref Level settings.

- Operation**
1. Press **Amplitude** > *Scale*[F5] to toggle the Scale on or off.
 2. Press *Scale Pos.*[F6] to toggle the position of the scale when on.


Scale position: Left, Center, Right

Display





The vertical scale is displayed on the left hand side by default.

Vertical Scale Units


Description	Change the vertical units for both linear or logarithmic scales.
Operation	<ol style="list-style-type: none"> Press  > <i>More[F7]>Y Axis[F1]</i> and then choose the desired units. The units are changed accordingly. <p>Units: dBm, dBmV, dBuV, Watts, Volts</p>

Reference Level Offset

Description	<p>The Reference Level Offset function sets an offset value to the reference level to compensate for any loss or gain from an external network or device.</p> <p>The offset value does not affect the input attenuation or the on-screen trace.</p> <p>This setting will change the reference level readout, the scale readout and the marker readout.</p>
Operation	<ol style="list-style-type: none"> Press  > <i>More[F7]>RefLvlOffset[F2]</i> and set the offset level and unit. To remove the offset level, set the reference offset to 0 dB. <p>Range: 0dB ~ 50dB</p>
Display Icon	 The AMP icon is displayed at the bottom of the screen.

Example:


Ref: 0dBm



Before reference level offset(offset: 0dB)

Ref: 10dBm

Reference level
offset: 10dB



After reference level offset (offset: 10dB)

Amplitude Correction


Description

Amplitude correction adjusts the frequency response of the spectrum analyzer by altering the amplitudes at specified frequencies. This allows the spectrum analyzer to compensate for loss or gain from an external network or device at certain frequencies.

Range

Correction Sets: 5 sets of 30 points
 Amplitude: -40dB to +40dB
 Amplitude Resolution: 0.1dB
 Frequency: 9kHz to 3GHz
 Frequency Resolution: 1Hz

Display



Example: The diagram above shows how amplitude correction is used to compensate for any losses or gains at specific frequencies.

Create a Correction Set


Description	The GSP-930 can create and edit up to 5 sets of correction points. The correction points and associated values are all tabulated for ease of use.
-------------	---

Operation	1. Press Amplitude > <i>More</i> [F7] > <i>Correction</i> [F3] > <i>Correction Set</i> [F1] and choose a correction set to edit/create.
-----------	--

Correction set:	1~5
-----------------	-----

2. Press *Edit*[F3].

The GSP-930 will split into two screens. The top screen will show the waveform and the bottom screen will provide an overview of the correction points.



3. Press *Point Num*[F1] and choose a point number to edit.


Point Num: 1~30

4. Press *Frequency*[F2] and choose the frequency of the selected point.

Press *Gain Offset*[F3] and choose the amplitude of the select point. The units will be the same as those used for the vertical scale.

The frequency of the point values displayed in the correction table on the bottom display.

Correction Table



5. Repeat steps 2 to 4 for any other correction points.
6. To delete the selected point, press *Delete Point*[F6].
7. Press *Return*[F7]>*Save Correction*[F5] to save the correction set.



Note

Note that the correction points are automatically sorted by frequency (low → high). The correction set must be saved before it can be turned on.

The frequency values *displayed* in the correction table are rounded down for display purposes only. The actual frequency for each point can be seen in the Frequency soft-key.

Amplitude Correction On/Off

Description Any one of the 5 correction sets can be turned on.

Activate Correction 1. Press **Amplitude** > *More*[F7]>*Correction*[F3]>*Correction Set*[F1] and choose a correction set.

Correction Set: 1~5

2. Press *Correction*[F2] and toggle correction on.

- Deactivate Correction
1. Press **Amplitude** > *More*[F7]>*Correction*[F3]>*Correction*[F2] to turn correction back off.
-

Delete Correction Set

- Operation
1. Press **Amplitude** > *More*[F7]>*Correction*[F3]>*Correction Set*[F1] and choose the correction set to delete.

Correction Set: 1~5
 2. Press *Delete Correction*[F6].
The selected correction set will be deleted.


Save Correction Set To Memory

- Operation
1. Press **Save** > *Save To*[F1] and choose the save location.

Location: Register, Local, USB, SD
 2. Press *Type*[F2]> *Correction*[F5].
 3. Press *Data Source*[F3] and choose a correction.

Correction Set: Correction 1~5
 4. Press *Save Now*[F7].
 5. The correction set will be saved to the selected location. For more information on Save and Recall, please see page 170.


Recall Correction Set From Memory

- Operation
1. Press  > *Recall*[F1] and choose the recall location:

Location: Register, Local, USB, SD
 2. Press *Type*[F2] > *Correction*[F5].
 3. Press *Destination*[F3] and choose a correction set.

Correction Set: Correction 1~5
 4. Press *Recall Now*[F4].
 5. The current correction set will be recalled from the selected location. For more information on Save and Recall, please see page 170.

Input Impedance

- Description Sets the input impedance to 75Ω or 50Ω.
-
- Operation
1. Press  > *More*[F7] > *Input Z*[F4] to toggle the input impedance.

Range: 75Ω, 50Ω


Input Impedance Calibration

Description When an external impedance converter module (optional accessory ADP-101) is used to convert the impedance of a device from 50Ω to 75Ω, some external loss can be induced. The Input Z Cal function can be used to compensate for these losses with an offset value.



Note

The Input Z Cal function is only available when the input impedance is set to 75Ω.

Operation 1. Press  > More[F7]>Input Z Cal[F5] and set the impedance offset.

Range: 0dB to +10dB

Resolution: 1dB

Display Icon



The AMP icon is displayed at the bottom of the screen when Input Z Cal≠0dB.

Using the Built-in Pre-Amplifier

Description The built-in pre-amplifier boosts weak input signals, such as EMI testing signals, to levels that are easy to handle, over the entire frequency range. The built-in pre-amplifier on the GSP-930 has a nominal gain of 20dB.

In the Auto setting, the pre-amplifier will be automatically turned on when the reference level is less than -30dBm. When the reference level is greater than -30dBm, the pre-amplifier is turned off.

The bypass setting turns the pre-amplifier off.

Operation

1. Press **Amplitude** > *More*[F7]>*Preamp*[F6] to toggle the Preamp state.

Range:

Auto, Bypass


Display Icon



The Pr-amp icon indicates that the pre amplifier is on.

Example:

Pr-amp icon



Note

When the pre-amplifier is on, the attenuator becomes fixed at 0dB (i.e. Attenuation = 0dB).

Autoset

The Autoset function searches the peak signals in two stages (full span & 0Hz - 100MHz limited span), picks the signal peak with the maximum amplitude, and then shows it in the display.

Using Autoset


Operation

1. Press  > *Autoset[F1]*.


Autoset Range

Amplitude: -80dBm ~ +20dBm
 Span: 100Hz ~ 3GHz

Example:



Before Autoset, preset state



After Autoset




Note

RBW, VBW and sweep settings are reset to Auto when the Autoset function is used.

Limiting the Autoset Vertical Search Range

Description You can set the amplitude floor so that the signals lower than the setting will be ignored by the Autoset search.

- Operation**
1. Press  > *Amp.Floor[F2]* and switch the range from Auto to Man.
 2. Enter the amplitude limit and unit for the Autoset search.

Range: -80 to +20dBm




Note

See page 48 for setting the amplitude units.

Limiting the Autoset Horizontal Search Range

Description You can change the frequency span limit in the display to get a better view of the Autoset result. By default, the frequency span after Autoset is set at 3MHz.

- Operation**
1. Press  > *Span[F3]* and switch the range from Auto to Man.
 2. Enter the span frequency for the Autoset search.

Manual Range: 100Hz to 3GHz


Bandwidth/Average Settings

BW/Avg key sets the resolution bandwidth (RBW), video bandwidth (VBW) and averaging functions. The resolution, sweep time, and averaging are in a trade-off relationship, so configuration should be done with care.


Resolution Bandwidth Setting (RBW)


Description RBW (Resolution Bandwidth) defines the width of the IF (intermediate frequency) filter that is used to separate signal peaks from one another. The narrower the RBW, the greater the capability to separate signals at close frequencies. But it also makes the sweep time longer under specific frequency spans (the display is updated less frequently).

Operation

1. Press  > *RBW[F1]* and set the RBW to Auto or Man.
2. Set the resolution bandwidth and unit for Man mode.

Mode: Auto, Man
 Frequency Range(3dB): 10Hz~3kHz (1-3-10 step)
 10kHz~1MHz (10% step)
 Frequency Range(6dB): 200Hz, 9kHz, 120kHz


Display Icon  The BW icon is displayed at the bottom of the screen when the RBW is in Man mode.

 **Note** If the RBW settings have an asterisk (*), it indicates that the -6dB filters are used.


Video Bandwidth Settings (VBW)

Description VBW (Video Bandwidth) defines the smoothness of the trace on the display. Combined with RBW, VBW defines the ability to sort out the target signal from surrounding noise or adjacent peaks.

Operation

1. Press  > *VBW[F2]* and set the VBW to Auto or Man.
2. Set the video bandwidth and unit for Man mode.

Mode: Auto, Man
 Frequency Range(3dB): 1Hz~1MHz (1-3-10 step)

Display Icon  The BW icon is displayed at the bottom of the screen when the VBW is in Man mode.

VBW/RBW Ratio


Description The VBW/RBW function is used to view the ratio between the video bandwidth and the resolution bandwidth.

The VBW/RBW ratio is altered by setting the RBW and or VBW settings, see page 61 & 62 respectively.

View VBW/RBW ratio

1. Press .
2. The ratio is displayed on the *VBW/RBW[F3]* soft key.

Display



Tip

Signals that are masked by the noise floor level should have a ratio of less than 1 to smooth the noise out.


Signals with strong frequency components should use a ratio equal to or greater than 1.

Average Trace

Description

The Average function averages the trace for a user-defined number of times before it is displayed. This feature smooths the noise level, but has the drawback of slowing down the display update rate.

Operation

1. Press  > *Average*[F4] and toggle Average on or off.
2. Set the number of averages.


Range: 4 ~ 200
 Default: 20

Display Icon




The AVG icon is displayed at the bottom of the screen when the Average function is on.

Example:



Average: Off



Average: On (20x)


Average Type

Description The Average Type function determines how the GSP-930 determines the average value.

LOG Average: Averages the trace points on a logarithmic scale.

Volt Average: Averages the amplitudes of the trace points on a linear voltage scale.

Power Average: Averages the trace points on a logarithmic scale in watts.


Operation 1. Press  > *Average Type*[F5] and choose the average type.

Range: LOG Power, Volt
Average, Power Average
Default: LOG Power

EMI Filter

Description The built-in EMI filter is used for specific measurement situations such as EMI average detection, where a higher level of sensitivity is required than the standard configuration. When turned on, the RBW is set to -6dB, indicated by an asterisk (*).

When any measurement functions are turned on (see page 111 for details), the EMI filter is automatically disabled. Conversely if the EMI filter is turned on, any measurement functions are turned off.


Operation 1. Press  > *EMI Filter[F6]* and toggle EMI filter on or off.

Sweep

The GSP-930 has a number of sweep options including setting the sweep time and sweep mode(continuous, single). The GSP-930 also has gated sweep modes.


Sweep Time

Description Sweep time defines the length of time the system takes to "sweep" the current frequency span. Note, however, that sweep time and RBW/VBW are in a trade-off. Faster sweep times update the display more frequently but make RBW and VBW wider, reducing the capability to separate signals at close frequencies.

Operation 1. Press  > *Sweep Time*[F1] and toggle the Sweep time to Auto or Man.


2. Set the sweep time for the Man mode.

Mode:	Auto, Man
Range:	22ms ~ 1000s (span>0Hz) 50us ~ 1000s (span=0Hz)
Resolution:	10us


Display Icon  The SWT icon will be displayed at the bottom of the screen when in the sweep is in manual mode.

Single Sweep

Description The single sweep function is used to perform a single sweep. When Sweep Single is pressed the GSP-930 will perform a single sweep and then stop.

Operation 1. Press  > *Sweep Single*[F2] to put the spectrum analyzer into single sweep mode.

2. Press *Sweep Single*[F2] again to perform a single sweep.



Display Icon  The Sweep Single icon is displayed on the right-hand side of the screen when the sweep is in single mode.




You must wait for the single sweep to finish before pressing the Single Sweep key again.

If a setting is changed whilst the spectrum analyzer is still sweeping, the single sweep will immediately start over.

Continuous Sweep

Description	The GSP-930 has two main sweeping modes: single and continuous. Use the continuous mode to have the sweep constantly updated.
Operation	1. Press  > <i>Sweep Cont</i> [F3] to put the spectrum analyzer into continuous sweep mode.
Display Icon	 The Sweep Cont icon is displayed on the right-hand side of the screen when the sweep is in continuous mode.


 **Note** The GSP-930 will now continuously sweep unless the mode is changed to single sweep mode or if the system is waiting for a trigger condition.

Gated Sweep Overview

Description	The Gated Sweep mode allows a trigger signal to dictate when the spectrum analyzer can sweep. This mode is useful for characterizing signals that are pulsed on and off, such as RF burst transmissions or for measuring spurious noise levels between transmission bursts.
Overview	<ol style="list-style-type: none"> 1. The trigger signal must be synchronized to the period of the input signal (shown as RF burst below). 2. The start of the gate time is produced from the positive or negative edge of the trigger signal + the delay time. 3. The end of the gate time is determined by the

set gate length.

4. The gated sweep should not be positioned at either end of the transmission.



Example: The diagram above demonstrates the relationship between the input trigger, the input signal and the position of the gated sweep relative to the input signal.






Please take into consideration RBW settling time. Setting the delay time too short may not leave enough time for the RBW filter to resolve.

Using the Gated Sweep Mode

- Connection
1. Connect a trigger signal (3.3v CMOS) to the GATE IN port on the rear panel.



- Operation
1. Press  > *GateDelay[F5]* and set the gate delay time.
 2. Press  > *Gated Length[F6]* and set the gate time length.
 3. Press  > *Gated Sweep[F4]* and turn the mode on.

Gate Delay: 0s ~ 1000s
 Gate Length: 10us ~ 1000s


Display Icon



The Sweep Gated icon is displayed when Gated Sweep is turned on.


Example:

The example below shows the spectrum of an FSK modulated signal when gated sweep mode is off.



The example below shows the same signal with the gated sweep timed to sweep when only the desired frequency is output.

Gated sweep icon



 Note

Gate Delay and Gate Length must first be set before Gated Sweep is turned on.

Trace

The GSP-930 is able to set the parameters of up to 4 different traces on the display at once. Each trace is represented by a different color and is updated with each sweep.

Selecting a Trace

Description	Each trace (1, 2, 3, 4) is represented by a different color. When activated, an icon for each trace color and function is shown to the left of the display. When a trace is selected, parameters can be set/edited from the trace menu.
-------------	---

Trace Color:	1: Yellow
	2: Pink
	3: Blue
	4: Red

Trace Type	The type of trace used determines how the trace data is stored or manipulated before being displayed. The analyzer updates each trace according to the type of trace used.
------------	--


Clear and Write	The GSP-930 continuously updates the display with each sweep.
-----------------	---

Hold Max/ Hold Min	The maximum or minimum points are maintained for the selected trace. The trace points are updated each sweep if new maximum or minimum points are found.
-----------------------	--

View View will hold the selected trace and stop updating the trace data for the selected trace. Pressing *View*[F4] will display the trace data that was cleared using the *Blank*[F5] key.

Blank Clears the selected trace from the display and stores trace data. The trace data can be restored by pressing *View*[F4].

Display Icon



Operation

1. Press **Trace** > *Trace*[F1] and choose the trace number.

Trace: 1, 2, 3, 4

2. Select the trace type:

Clear & Write[F2]
Max Hold[F3]
Min Hold[F4]
View[F5]
Blank[F6]




Traces, 2, 3 and 4 are set to *Blank* by default.

Trace Math

Description Performs trace math from two traces (TR1, TR2) and stores the result in the currently selected trace. It also performs trace shift.

Math functions	Power Diff	Subtracts the TR1 amplitude data from the TR2 amplitude data. The TR1 data TR2 data are converted to watts. The result is converted back to dBm.
	Log Diff	Subtracts the TR1 amplitude data from the TR2 amplitude data and then adds a logarithmic reference. Both the TR1 and TR2 data is in dBm. The resultant trace of the subtraction is in dB. When the result is added to a logarithmic reference the resulting data is in dBm.
	LOG Offset	Adds a reference to the TR1 trace

- Operation**
1. Press  > *More[F1]>Trace Math[F1]*.
 2. Press *TR1[F1]* and select the first trace source:

TR1: Trace 2, Trace 3, Trace 4
 3. Press *TR2[F2]* and select the second trace source:

TR2: Trace 2, Trace 3, Trace 4

- Select the trace math function:

PowerDiff[F3]

LogDiff[F4]

LogOffset[F5]

- If LogDiff was selected, set the reference level and unit.

LogDiff ref range: -120dBm ~ 30dBm

LogDiff ref units: dBm, W

- If LogOffset was selected, set the offset level and unit.

LogOffset range: -50dB~+50dB

- To turn trace math off, press the *OFF*[F6].

Display Icon



The Math icon is displayed when trace math is turned on.

Trace Detection Mode

Description


Each time the spectrum analyzer samples data for each point on the trace, a number of samples are usually taken for each point, known as a sample bucket. The actual value of each point is determined by the detector from the samples in each bucket.

Each selected trace, (1, 2, 3, 4), can use a different detection mode.

Detection modes	Auto	Automatically chooses an appropriate mode based on the values of all the samples.
	Normal	While the signal level is constantly increasing or decreasing, the positive peaks are detected. Otherwise, detecting mode switches between positive peak and negative peaks. Useful for picking up burst phenomenon while avoiding excessive noise.
	Peak+	Detects positive peak signals by selecting the maximum peak value for each point from each bucket. This mode is useful for sinusoidal signals.
	Peak-	Detects negative peak signals by selecting the lowest peak value for each point from each bucket. This mode is not recommended for amplitude measurement.
	Sample	Randomly selects a value from the bucket sample. Useful for noise signals.
	Average	Calculates the average of all the samples in the sample bucket.

Auto Detector
Selection Method

Below is a flow chart diagram showing the
Detector selection for the Auto mode.









Operation

1. Press **Trace** > **More**[F7]>**Detection**[F2].
2. Select the trace detection mode for the selected trace:

Auto[F1]
Normal[F2]
Peak+[F3]
Peak-[F4]
Sample[F5]
Average[F6]

3. The display will return the Trace menu.

Display Icon		Normal		Average icon
		Peak+ icon		Peak - icon
		Sample icon		Average icon

Trigger

The Trigger function sets the signal conditions upon which the spectrum analyzer triggers captured waveforms, including frequency, amplitude, and delay. An external trigger signal, instead of the default internal signal, may be used as required for special conditions.

The sections below can be used to skip to the relevant section:

- Free Run Mode → from page 79
- Activate Video Trigger → from page 79
- Activate External Trigger → from page 81
- Selecting Trigger Mode → from page 81
- Set the Trigger Delay Time → page 83

Selecting a Trigger Type

Free Run Mode


Description	In free run mode all signals are captured and the trigger conditions are not used.
-------------	--

Free Run Mode	1. Press  > <i>Free Run</i> [F1] to run in free mode.
---------------	--

Activate Video Trigger

Description	Sets the video trigger level for video signals. When the video signal voltage level exceeds* the video trigger level, a trigger signal will be generated. *for positive video edge
-------------	---

Parameters	<p>Video Edge: Determines the polarity of the video trigger.</p> <p>Positive: The signal voltage exceeds the video level at the trigger frequency.</p> <p>Negative: The signal voltage is lower than the video level at the trigger frequency.</p> <p>Video Level: The trigger voltage level.</p> <p>Trigger Frequency: Sets the frequency to start triggering</p>
------------	--

Operation	<ol style="list-style-type: none"> 1. Press  > <i>Trigger Condition</i>[F2] > <i>Video</i>[F1] 2. Press <i>Video Edge</i>[F1] and choose the edge. <p>Range: Positive, Negative</p> <ol style="list-style-type: none"> 3. Press <i>Video Level</i>[F2] and set the video voltage trigger level. <p>Trigger level: (-120dBm to +30dBm) +Ref Level Offset</p> <ol style="list-style-type: none"> 4. Press <i>Trigger Freq</i>[F3] and choose the frequency at which the spectrum analyzer will check the triggering conditions. <p>Frequency: 0-3GHz+frequency offset</p>
-----------	--




Note

Set the trigger back to Free Run to disable the video trigger.

Activate External Trigger

Description The external trigger is used when an external trigger signal is input into the rear panel TRIG IN port. The external trigger signal can be configured as positive or negative edge.

Trigger: 3.3V, CMOS


Operation 1. Press  > *Trigger Condition*[F2] > *Ext.Edge*[F2] and select the trigger edge:

Pos: Positive edge
Neg: Negative edge

2. Connect the external trigger signal to the rear panel TRIG IN port.




3. Press *Action Now*[F5] to activate the external trigger.
4. The system will now wait the trigger conditions to be matched before starting a sweep.

Display Icon  The EXT Trigger icon is displayed when the external trigger is activated.



The trigger will revert back to the Free Run mode if any parameter settings are changed, such as the span or amplitude settings.


Selecting the Trigger Mode

Description	In free run mode all signals are captured and the trigger conditions are not used.	
Modes	Normal:	The spectrum analyzer captures every signal that meets the trigger conditions.
	Single:	The spectrum analyzer captures the first signal that meets the trigger conditions.
	Continuous:	The spectrum analyzer captures the first signal that meets the trigger conditions then switches to free run mode thereafter.
Operation	1. Press  > <i>Trigger Mode</i> [F3] to toggle the trigger mode:	
	Nor.:	Normal
	Sgl.:	Single
	Cont.:	Continuous
	2. Press <i>Action Now</i> [F5] to manually start triggering.	

Set the Trigger Delay Time

Description Sets the delay time between when the analyzer triggers and when the analyzer begins to capture the signal.

Delay time range: 1ns to 1ks

Operation 1. Press  > *Trigger Delay*[F4] and set the trigger delay time.

Delay range: 0~1000s

Marker

A Marker shows the frequency and amplitude of a waveform point. The GSP-930 can activate up to 6 markers or marker pairs simultaneously as well as up to 10 peak markers in the marker table.

The marker table helps editing and viewing multiple markers in a single display.

A delta marker shows the frequency and amplitude differences between the reference marker.

The GSP-930 can automatically move a marker to various locations including the peak signal, center frequency, and start/stop frequency. Other marker operations regarding signal peaks are available in the Peak Search function.

- Activating a Marker → from page 85
- Move Marker Manually → from page 86
- Move Marker to Preset Locations → from page 86
- Activate Delta Marker → from page 87
- Move Delta Marker(s)Manually → from page 88
- Marker Functions → from page 89
- Move Marker to Trace → from page 91
- Show Markers in Table → from page 92
- Peak Search → from page 93
- Peak Configuration → from page 95
- Peak Table → from page 96

Activating a Marker

There are two basic marker types, normal markers and delta markers. Normal markers are used to measure the frequency/time or amplitude of a point on the trace. Delta markers are used to measure the difference between a reference point and a selected point on the trace.


Activate a Normal Marker

Operation

1. Press **Marker** > *Select Marker*[F1] and select a marker number.





Marker: 1~6

2. Press [F2] to turn the selected marker on.
3. Press *Normal*[F3] to set the selected marker to the Normal type.
4. The display will show the marker on the trace (centered by default) with the marker measurement at the top of the display.




Move Marker Manually

Operation

1. Press  > *Select Marker[F1]* and select a marker number.
2. Use the left/right arrow keys to move the marker one grid division. 
3. Use the scroll wheel to move the marker in fine increments. 
4. Alternatively, the numeric keypad can be used to directly enter the frequency of the marker position. 

Move Marker to Preset Locations

Description


The  key is used to move the selected marker to a number of preset positions.

Functions



Mkr>Center: Move to center frequency.
 Mkr>Start: Move to start frequency.
 Mkr>Stop: Move to stop frequency.
 Mkr>CF Step: Move to step frequency.
 Mkr>Ref Lvl: Move to reference level amplitude.



Note

When the  key is used, the span and other settings may be automatically changed.

Operation

1. Press  > *Select Marker[F1]* and select a marker number.
2. Press  and select a marker position:

Mkr>Center[F1]
Mkr>Start [F2]
Mkr>Stop[F3]
Mkr>CF Step[F4]
Mkr>Ref Lv/[F5]

Activate Delta Marker


Description Delta markers are marker pairs that measure the difference in frequency/time and amplitude between a reference marker and a delta marker.

When delta markers are activated, the reference and delta marker appear at the position of the selected marker, or in the center of the display if the selected marker has not yet be activated.

The marker measurement is located at the top of the display, under the “normal marker” measurement.

Delta Markers	Ref:	Reference marker, designated as \downarrow .
	Delta:	Delta marker, designated as $\Delta\downarrow$.

Operation

1. Press  > *Select Marker[F1]* and select a marker number.
2. Press [F2] to turn the selected marker on.
3. Press *Delta[F4]>Delta[F1]* to set the selected marker to the Delta type.

Move Delta Marker(s) Manually

Move Delta or Reference Marker 1. Press $\text{Marker} > \Delta[F4] > \text{Move}[F2] > \text{Move Ref}[F2]$ to move the reference marker.

2. Press $\text{Marker} > \Delta[F4] > \text{Move}[F2] > \text{Move} \Delta[F3]$ to move the Delta marker.

3. Move the selected marker in the same fashion as a normal marker, see page 86

Move Both reference and delta marker 1. Press either *Move Pair Span*[F4] or *Move Pair Center*[F5] to move both markers at the same time.

Move Pair Span: Sets the frequency span between both markers. The span can be positive or negative:

$$\underset{\downarrow}{1} \leftarrow +\text{span} \rightarrow \underset{\downarrow}{\Delta 1}$$

$$\underset{\downarrow}{\Delta 1} \leftarrow -\text{span} \rightarrow \underset{\downarrow}{1}$$

Move Pair Center: Moves both markers at the same time, keeping the span between both markers even throughout.


2. Move both markers in the same fashion as a normal marker, see page 86

Marker Functions

Marker Noise

Description The noise marker function calculates the average noise level over a bandwidth of 1Hz, referenced from the marker position.

- Operation**
1. Press **Marker** > *Select Marker[F1]* and select a marker number.
 2. Press **[F2]** to turn the selected marker on.
 3. Press *Normal[F3]* and then position the marker to the desired location.
 4. Press *Function[F5]>Marker Noise* and turn Marker Noise on.
 5. The display will show the noise level measurement at the top of the screen in dBm/Hz.




Frequency Counter

Description The frequency counter function is used to make accurate frequency measurements.

- Operation**
1. Press **Marker** > *Select Marker*[F1] and select a marker number.
 2. Press [F2] to turn the selected marker on.
 3. Press *Normal*[F3] and then position the marker to the desired location.
 4. Press *Function*[F5]>*Frequency Counter*[F1] and turn the counter function on.
 5. Press *Resolution*[F2] and set the resolution:

Auto:	Automatically chooses the best resolution.
Man:	Allows the resolution to be manually set.
Man Range:	1Hz, 10Hz, 100Hz, 1kHz
 6. The display will show the frequency measurement at the top of the screen at the selected resolution.




Move Marker to Trace

Description The Marker Trace function moves the selected marker to any of the currently active traces.

- Operation**
1. Press **Marker** > *Select Marker*[F1] and select a marker number.
 2. Press [F2] to turn the selected marker on.
 3. Press *More 1/2*[F7]>*Marker Trace*[F1] and choose a trace to move the current marker to. Only active traces can be selected.

Auto[F1]
Trace1[F2]
Trace2[F3]
Trace3[F4]
Trace4[F5]

4. In the example below, marker 1 is set to Trace1 and marker 2 is set to Trace2.



Show Markers in Table

Description The GSP-930 has a Marker Table function to show all the active markers and measurements at once.





- Operation**
1. Press **Marker** > *More 1/2*[F7]>*Marker Table*[F2] and turn the marker table on.
 2. The display will split into two screens. The bottom half will show the Marker Table with the marker ID(normal, reference or delta), trace, x-axis position (frequency/time) and the amplitude of the marker.





Marker Table

Peak Search

Move Marker to Peak

Description	The  key is used to find trace peaks.
Operation	<ol style="list-style-type: none">1. Press  > <i>Select Marker[F1]</i> and select a marker number.2. Press  > <i>Peak Search[F1]</i>. The marker will move to the highest signal peak.3. To continually search for the peak each sweep, press,  > <i>More 1/2[F7]</i> > <i>Peak Track[F1]</i> and set <i>Peak Track</i> to on.

Move Marker and Peak to Center

Description	The Center function moves the marker to the highest signal peak and moves the center frequency to that peak.
Operation	<ol style="list-style-type: none">1. Press  > <i>Select Marker[F1]</i> and select a marker number.2. Press  > <i>Mkr</i> > <i>Center[F2]</i>.



Note

The span will not be changed.


Search for Peaks

Description The **Peak Search** key can be used to search for a number of different peaks.


Peak Search	Next Peak:	Searches for next highest peak visible on the display.
	Next Peak Right:	Searches for the next peak to the right of the marker.
	Next Peak Left:	Searches for the next peak to the left of the marker.
	Min Search:	Searches for the lowest peak.

- Operation**
1. Press **Marker** > *Select Marker[F1]* and select a marker number.
 2. Press **Peak Search** and select the type of peak you wish to find.


**Example:
Next Peak**



Example:
Next Peak Right



Example:
Next Peak Left




Peak Configuration

Description


There are two peak search configuration options: Peak Excursion and Peak Threshold.

Peak Excursion: Peak Excursion sets the minimum value above the peak threshold for which peaks will be detected.

Peak Threshold: Peak threshold sets the minimum threshold level for the analyzer to detect peaks. Any value above the Peak Threshold + Peak Excursion will be detected as a peak.



Operation

1. Press  >More 1/2[F7].
2. Press *Peak Excursion*[F2] to set the excursion level.
3. Press *Peak Threshold*[F3] to set the peak threshold.


Peak Excursion: 0~100dB
 Peak Threshold: -120dB~+30dB

Peak Table

Description


The Peak Table function will display all peaks (up to 10) that meet the peak configuration settings. The amplitude and frequency for each peak is listed.

Operation

1. Press  >More 1/2[F7]>*Peak Table*[F5].

2. Press *Peak Sort*[F2] and set the sorting type:
 - Freq: Sort by frequency in ascending order.
 - Amp: Sort by amplitude in ascending order.
3. Press *Peak Table*[F1] to turn the peak table on.
4. The display splits in two. The bottom screen shows the peak table with the peak marker ID, X-axis position and amplitude.

Peak markers




Peak Table


Display

The Display key configures the basic display settings as well as setting up the display mode (spectrum, spectrographic, topographic) and the split screen modes.

Adjusting the LCD Brightness

Description	The LCD brightness levels can be adjusted to three pre-set levels.
Operation	1. Press  > <i>LCD Brightness[F2]</i> to toggle the display brightness: Hi: High brightness Mid: Medium brightness Lo: Low brightness

Turning the LCD Backlight Off


Description	The LCD backlight can be turned off to preserve power or to prolong the lifetime of the LCD display when not in use.
Operation	1. Press  > <i>LCD Backlight[F3]</i> and turn the LCD backlight off. 2. When the backlight is off, press any function key to turn the LCD backlight back on.

Setting a Display Line (Reference Level Line)

Description The Display Line function is used to super-impose a reference level line over the traces.

- Operation**
1. Press **Display** > *Display Line*[F4] to turn the display line on.
 2. Set the display line level and unit.

Example:



Display line set at -50dBm

Using the Video Out Port

Description The GSP-930 has a dedicated DVI terminal to output the display to an external monitor. The video output is always on.

Output resolution 800 x 600 (fixed)


- Operation**
1. Connect an external monitor to the rear panel DVI terminal.

DVI - I



Setting the Display Mode

Description	The GSP-930 has three different display modes for viewing: spectrum, spectrograph and topographic. It is also possible to view the spectrum with the spectrographic or topographic views using a split screen.	
	Spectrum	Default display mode.
	Spectrogram	Useful for viewing frequency or power in the time domain.
	Topographic	Useful for observing the frequency of events with a trace.


Operation 1. Press  > *Window Setup*[F1] and select the display mode:

- Spectrum*[F1]:
- Spectrogram*[F3]:
- Topographic*[F4]:
- Spectrogram+Spectrum*[F5]:
- Topographic+Spectrum*[F6]:

 Note

The same trace is used on the top and bottom for the Spectrogram+Spectrum and Topographic+Spectrum modes.


Example:
Spectrogram



The Spectrogram view shows signals in both the frequency and time domain. The X-axis represents frequency, the Y-axis represents time and the color of each point represents the amplitude at a particular frequency & time (Red = high → dark blue = low).


Each new trace is shown at the bottom of the display and older traces are pushed up toward the top of the display until they are removed.

Topographic




The topographic view shows the frequency of events. The topographic view is useful for observing smaller signals that have been overpowered by stronger signals or to easily observe intermittent events. Color is used to represent the frequency of an event. Red represents a high frequency of occurrence, while blue represents events that occur rarely.

Spectrogram
+Spectrum



Displays both spectrographic and spectrum views of the signal.

Topographic
+Spectrum



Displays both topographic and spectrum views of the signal.

Split Spectrum View

Description The split spectrum view is able to view two different sweep ranges on the display at the same time using a split screen view. The top and bottom view can have independent sweep ranges, amplitudes, spans and other settings. However only one split screen (top or bottom) can be swept each time.

- Operation**
1. Press **Display** > *Window Setup*[F1] > *Split Spectrum*[F2] > *Active Win*[F1] to activate the upper split screen.
 2. Pressing *Active Win*. [F1] will toggle the sweep between the upper and lower screen.
 3. Press *Alternate Sweep*[F2] for the analyzer to alternate the sweep between the upper and lower screen at the end of each sweep.




Note

No operations can be performed in alternate sweep mode.

After exiting the split spectrum view, the analyzer will use the settings from the active window. The settings for the inactive screen will be retained for the next time that split spectrum view is used.

Example:




System Settings

System Information


Description The System Information displays the following:

Serial Number	Installed Options
Version:	Calibration Date:
Software	LOI
Firmware	RF
File sys	TG
RF	DNS Hostname
TG	MAC Address
DSP	
Wordlist	
Core	

Operation 1. Press  > *System Information*[F1] to bring up a list of the system information.

Error Messages

Description View error messages that are in the error queue by message number, description and time. All errors from the system error queue are logged when operating the analyzer. For a list of the error messages, please see the programming manual.


Operation 1. Press  > *Error message*[F2] to bring up the error message table.

2. Press *Prev Page*[F2] and *Next Page*[F3] to navigate through each page of the error list.

3. Press *Clear Error Queue*[F6] to clear the error messages from the list.

Set the System Language

Description The GSP-930 supports a number of languages. The system language sets the soft menu keys to the selected language.

- Operation** 1. Press  > *Language*[F3] and choose the system language.

Set the Date and Time

- Operation** 1. Press  > *Date/Time*[F4].

2. Press *Set Date*[F1] to set the date:

Year[F1] Sets the year.

Month[F2] Sets the month.

Day[F3] Sets the day.

3. Press *Set Time*[F2] to set the system time:

Hour[F1] Sets the hour (24hr).

Minute[F2] Sets the minute.

Second[F3] Sets the second.


4. The system time and date will be shown at the top of the display.

Time, Date



Using the Wake-Up Clock

Description The GSP-930 has a wake-up clock to allow the spectrum analyzer to automatically turn on at a set time.

Operation 1. Press  > *Date/Time*[F4] > *Wake-Up Clock*[F3] and set the following parameters:

- | | |
|--------------------------|--|
| <i>Clock</i> [F1] | Choose a wake-up clock (1~7). |
| <i>State</i> [F2] | Turns the selected clock on/off. |
| <i>Hour</i> [F3] | Set the wake-up hour |
| <i>Minute</i> [F4] | Set the wake-up minute. |
| <i>Rept. Single</i> [F5] | Set the wake-up clock to repeat or single. |




Only single days can be configured for the wake-up clock.

Alarm Output

Description Allows the pass/fail output to be output via the ALARM OUT port.

Output: Open collector



Operation


1. Press System > *Alarm Output*[F6] and toggle the ALARM OUT port on or off.

Preset

The Preset function loads either factory default states or the user-defined states – depending on the Preset configuration settings.

- Using the Preset Key → from page 109
- Save the User Preset Settings → from page 109
- Preset Type Settings → from page 110
- Power on Preset Settings → from page 110

Using the Preset Key


Description	The  key loads the factory default state or user-defined preset settings. See the Preset Type Settings on page 109 to set the type of preset settings that are loaded.
-------------	---

Factory Preset	The factory default settings are listed on page 209
----------------	---


Operation	Press  to load the preset settings.
-----------	--


Save the User Preset Settings

Description	The user-defined preset settings can be created by saving the current state as the user-defined preset settings.
-------------	--

Operation	Press  > <i>Pwr On/Preset[F5]</i> > <i>Save User Preset[F3]</i> to save the current state as the <i>User Preset</i> settings.
-----------	--

Preset Type Settings


Description Each time the  key is pressed, a set of preset configuration settings are loaded. The preset configuration settings can be either the factory default settings or the user-defined settings.

Operation 1. Press  >Pwr On/Preset[F5]>Preset Type[2] and choose the preset type:

User Preset[F1]
Factory Preset[F2]

Power on Preset Settings

Description When the spectrum analyzer is turned on, either the preset configuration settings are loaded (default) or the configuration settings that were used before the instrument was turned off.

Operation 1. Press  >Pwr On/Preset[F5]>Power On[F1] and choose the power on settings:

Power On: Last, Preset

 **Note**

See Preset Type Settings on page 209 for details on the preset conditions.

The last preset conditions cannot be loaded if the instrument was not powered down correctly the last time it was used. Please see page 27 for details.

A ADVANCED OPERATION

Measurement.....	112
Channel Analysis Overview.....	112
ACPR.....	114
OCBW.....	117
AM/FM Analysis	119
AM Analysis	119
FM Analysis.....	123
AM/FM Demodulation	127
N dB Bandwidth	128
Phase Jitter Measurement	129
Spectrum Emission Mask Overview	132
Spectrum Emission Mask Testing.....	144
Third Order Intermodulation Distortion (TOI)	150
CNR/CSO/CTB Measurement	152
Carrier to Noise Ratio (CNR)	152
Composite Second Order (CSO).....	155
Composite Triple Beat (CTB).....	156
Limit Line Testing	159
Creating a Limit (Point by Point).....	159
Creating a Limit (from Trace Data).....	161
Creating a Limit (from marker data).....	162
Delete Limit Line	163
Pass Fail Testing.....	163
Sequence	165
Editing a Sequence.....	165
Running a Sequence.....	169

Measurement

This section describes how to use the automatic measurement modes. The GSP-930 includes the following measurements:

- ACPR → from page 114
- OCBW → from page 117
- AM demodulation → from page 119
- FM demodulation → from page 123
- N dB measurement → page 128
- Phase Jitter → page 129
- SEM measurement → from page 132
- TOI measurement → from page 150
- CNR/CSO/CTB measurement → from page 152

Channel Analysis Overview


Description	Channel analysis measurement includes ACPR (adjacent channel power) and OCBW (occupied bandwidth) measurements.	
Parameters	Channel bandwidth	The frequency bandwidth the target channel occupies. Range: Between 0Hz~3GHz (0Hz excepted)
	Channel Space	The frequency distance between each main channel. Range: Between 0Hz~3GHz

Adjacent channel bandwidth 1 & 2	<p>The frequency bandwidth the adjacent channels occupy.</p> <p>Range: Between 0Hz~3GHz (0Hz excepted)</p>
Adjacent channel offset 1 ~ 3	<p>The frequency distance between the adjacent channels and main channel.</p> <p>Range: 1 Between 0Hz~3GHz (0Hz excepted)</p>
OCBW%	<p>The ratio of occupied bandwidth to the amount of power consumed.</p> <p>Range: 0% to 100%, 0.1% resolution.</p>

ACPR


Description Adjacent channel power refers to the amount of power leaked to the adjacent channel from the main channel. This measurement is a ratio of the main channel power to power in the adjacent channel.

Example



Operation:
Setting up the main channel

1. Press **Meas** > *Channel Analysis*[F1] > *ACPR*[F2] and turn ACPR on.
 - *Any other measurement mode will automatically be disabled.*
2. The display splits into two screens. The top screen shows the main channel, adjacent channels and their corresponding limits. The bottom screen shows the ACPR measurement results in real time.



3. Press **Meas** > *Channel Analysis*[F1]>*ACPR Setup*[F1]> and set the following:

- Main CHBW*[F1] Set the bandwidth of the main channel.
- Main CH H Limit*[F2] Set the low limit for the main channel.
- Main CH Limit*[F3] Set the high limit for the main channel
- CH SPC*[F4] Specify the channel spacing


Operation:
Setting up the adjacent channel(s)

1. Press *ADJCH Setup*[F5] to setup the adjacent channels:
 - ADJCH*[F1] Choose an adjacent channel number: 1, 2, 3
 - [F2] Toggle the selected channel on/off.
 - ADJCHBW*[F3] Choose the bandwidth of the selected channel.

- ADJCH Offset[F4]* Set the adjacent channel offset.
- ADJCH HLimit[F5]* Set the adjacent channel high limit.
- ADJCH LLimit[F5]* Set the adjacent channel low limit.

2. Repeat the above steps for the other adjacent channels, if needed.

Move Channels
Up/Down

1. Press  > *Channel Analysis[F1]* and press the following to move to another channel:

- Channel Move Up[F5]* Next main channel.
- Channel Move Down[F6]* Previous main channel.




The channel space (CH SPC) parameter determines where the next main channel is located.

OCBW


Description Occupied bandwidth measurements are used to measure the power of the occupied channel as a percentage to the power of the channel.

Example



Operation:
Setting up the
main channel

1. Press **Meas** > **Channel Analysis[F1]** > **OCBW[F4]** and turn OCBW on.
 - *Any other measurement mode will automatically be disabled.*
2. The display splits into two screens. The top shows the channel bandwidth. The bottom screen shows the OCBW measurement results in real time.



Channel power and total power results

3. Press *OCBW Setup*[F3] to enter the OCBW setup:

- CHBW*[F1] Set the channel bandwidth.
- CH SPC*[F2] Set the channel space between main channels.
- OCBW%*[F3] Set the % of the OCBW to CHBW.

Move Channels Up/Down

1. Press **Meas** > *Channel Analysis*[F1] and select:
 - Channel Move Up*[F5] Next main channel.
 - Channel Move Down*[F6] Previous main channel.


 **Note**

The channel space (CH SPC) parameter determines where the next main channel is located.


The CH SPC parameters from the ACPR and OCBW setups are independent.

AM/FM Analysis

AM Analysis

Description	When amplitude modulation is turned on, the input signal is centered on the center frequency and the span is automatically set to zero-span.	
Measurement items	AM Depth:	Current, Min, Max
	Mod. Rate:	Current, Min, Max
	Carrier Pwr:	Current, Min, Max
	Carrier Freq Offset:	Current, Min, Max
	SINAD:	Current, Min, Max
Operation: configuration	<ol style="list-style-type: none"> 1. Set the center frequency to the carrier frequency (page 39). 2. Press  > Demod[F2] > AM Analysis[F1] > AM Analysis[F1] and turn AM analysis on. <ul style="list-style-type: none"> • Any other measurement mode will automatically be disabled. 3. The display splits into two screens. The top shows the AM waveform in the time domain. The bottom screen shows the AM measurement. 	

AM waveform



AM modulation measurements

4. Press *Setup*[F2]>*IF Bandwidth*[F1] and set the Intermediate frequency bandwidth.
 - Set with adequate bandwidth to accommodate spectrum contained in the carrier.
5. Press *LPF*[F2] to set the low pass filter frequency, alternatively the frequency can be set to bypass:

AM Signal Frequency (Hz)	Selectable bandwidth of LPF (Hz)				
≥78,125	156,250	78,125	52,083	39,063	31,250
≥39,063	78,125	39,063	26,042	19,531	15,625
≥19,531	39,063	19,531	13,021	9,766	7,813
≥7,813	15,625	7,813	5,208	3,906	3,125
≥3,906	7,813	3,906	2,604	1,953	1,563
≥1,953	3,906	1,953	1,302	977	781
≥781	1,563	781	521	391	313
≥391	781	391	260	195	156
≥195	391	195	130	98	78
≥78	156	78	52	39	31
≥39	78	39	26	20	16
≥20	39	20	13	10	8
≥8	16	8	5	4	3

6. Press *Time Axis* [F3] to set horizontal axis parameters:

<i>Ref. Value[F1]</i>	Sets the starting time on the time axis.
<i>Ref. Pos[F2]</i>	Shifts the waveform X number of grid subdivisions.
<i>Scale/Div[F3]</i>	Sets the grid division scale when Auto Scale is Off.
<i>Auto Scale[F4]</i>	Toggles auto-scaling on/off.

7. Press *Depth Axis[F4]* to set depth (vertical) parameters:

<i>Ref. Value[F1]</i>	Offsets the reference position as a percentage of the vertical scale/ div.
<i>Ref. Pos[F2]</i>	Sets the reference position of the waveform on a horizontal grid subdivision (1:10).
<i>Scale/Div[F3]</i>	Sets the horizontal grid division scale when Auto Scale is Off.
<i>Auto Scale[F4]</i>	Toggles auto-scaling on/off.

Operation:
trigger
configuration


8. Press *AF Trigger[F5]* to set the triggering conditions:

<i>FreeRun[F1]</i>	Disables the trigger, this is the default setting.
<i>Edge Slope[F2]</i>	Sets the trigger to rising or falling edge.

<i>Trigger Mode[F3]</i>	Sets the triggering mode: Nor.: Normal trigger Sgl.: Single trigger Cont.: Continuously trigger
<i>Trigger Level[F4]</i>	Sets the trigger level as a percentage of the depth.
<i>Trigger Delay[F5]</i>	Sets the trigger delay time: 0 to 1ks
<i>Run Now[F6]</i>	Turns FreeRun mode off and uses the user-defined trigger settings.




Note

The MAX and MIN measurements are held until higher or lower values are found. To reset the MAX and MIN measurements, press  >
Demod[F2]>AM Analysis[F1]>Min/Max Reset[F3].

FM Analysis

Description	When frequency modulation is turned on, the input signal is centered on the carrier frequency and the span is automatically set to zero-span.
-------------	---

Measurement items	Freq. Deviation:	Current, Min, Max
	Mod. Rate:	Current, Min, Max
	Carrier Pwr:	Current, Min, Max
	Carrier Freq Offset:	Current, Min, Max
	SINAD:	Current, Min, Max

- | | |
|--------------------------|--|
| Operation: configuration | <ol style="list-style-type: none"> 1. Set the center frequency to the carrier frequency (page 39). 2. Press  > Demod[F2] > FM Analysis[F2] > FM Analysis[F1] and turn FM analysis on. <ul style="list-style-type: none"> • Any other measurement mode will automatically be disabled. 3. The display splits into two screens. The top shows the FM waveform in the time domain. The bottom screen shows the FM measurement. |
|--------------------------|--|

FM waveform



FM modulation measurements

4. Press *Setup*[F2]>*IF Bandwidth*[F1] and set the Intermediate frequency bandwidth. (10kHz, 30kHz, 100kHz, 300kHz, 1MHz,)
 - *Set with adequate bandwidth to accommodate spectrum contained in the carrier.*

5. Press *LPF*[F2] to set the low pass filter frequency, alternatively the frequency can be set to bypass:

FM Signal Frequency (Hz)	Selectable bandwidth of LPF (Hz)				
	156,250	78,125	52,083	39,063	31,250
≥78,125	156,250	78,125	52,083	39,063	31,250
≥39,063	78,125	39,063	26,042	19,531	15,625
≥19,531	39,063	19,531	13,021	9,766	7,813
≥7,813	15,625	7,813	5,208	3,906	3,125
≥3,906	7,813	3,906	2,604	1,953	1,563
≥1,953	3,906	1,953	1,302	977	781
≥781	1,563	781	521	391	313
≥391	781	391	260	195	156
≥195	391	195	130	98	78
≥78	156	78	52	39	31
≥39	78	39	26	20	16
≥20	39	20	13	10	8
≥8	16	8	5	4	3

6. Press *Time Axis*[F3] to set horizontal axis parameters:

<i>Ref. Value</i> [F1]	Sets the starting time on the time axis.
<i>Ref. Pos</i> [F2]	Shifts the waveform X number of grid subdivisions.
<i>Scale/Div</i> [F3]	Sets the grid division scale when Auto Scale is Off.
<i>Auto Scale</i> [F4]	Toggles auto-scaling on/off.

7. Press *Deviation Axis*[F4] to set depth (vertical) parameters:

<i>Ref. Value</i> [F1]	Offsets the reference position (in frequency).
<i>Ref. Pos</i> [F2]	Sets the reference position of the waveform on a horizontal grid subdivision (1:10).
<i>Scale/Div</i> [F3]	Sets the horizontal grid division scale.
<i>Auto Scale</i> [F4]	Toggles auto-scaling on/off.

Operation:
trigger
configuration


8. Press *AF Trigger*[F5] to set the triggering conditions:

<i>FreeRun</i> [F1]	Disables the trigger, this is the default setting.
<i>Edge Slope</i> [F2]	Sets the trigger to rising or falling edge.

<i>Trigger Mode[F3]</i>	Sets the triggering mode: Nor.: Normal trigger Sgl.: Single trigger Cont.: Continuously trigger
<i>Trigger Level[F4]</i>	Sets the trigger level as a frequency.
<i>Trigger Delay[F5]</i>	Sets the trigger delay time: 0 to 1ks
<i>Run Now[F6]</i>	Turns FreeRun mode off and uses the user-defined trigger settings.





Note


The MAX and MIN measurements are held until higher or lower values are found. To reset the MAX and MIN measurements, press  >
Demod[F2]>FM Analysis[F1]>Min/Max Reset[F3].

AM/FM Demodulation

Description The GSP-930 has a convenient AM/FM demodulation function to tune into AM or FM broadcast signals and listen to the demodulated baseband signals using the ear phone out socket.

- Operation: Setup**
1. Set the center frequency to the desired FM/ AM carrier frequency. See page 39 for details.
 2. Set the span to zero. See page 44 for details.
 3. Set the Preamp to Auto. See page 57.

Connection Connect headphones or a speaker to the phone output port.  

- Operation**
4. Press  > *Demod*[F2] > *Sound*[F3] > *Ear Phone Out*[F1] and turn the ear phone out on.
 5. Press *Volume*[F2] to set the volume output:


Volume: 0~15, default 7
 6. Press *Digital Gain Control*[F3] to change the gain:

Gain: 0~18dB, 6dB step
 7. Press *Demod Type*[F4] to choose AM or FM demodulation.


N dB Bandwidth

Description N dB bandwidth measurements are used to measure the frequency bandwidth that covers a specified amplitude (N dB) from the top of the peak.

Example



- Operation**
1. Press **Meas** > *NdB Bandwidth*[F3] > *NdB BW*[F1] and turn N dB BW on.
 - *Any other measurement mode will automatically be disabled.*
 2. The display splits into two screens. The top shows the trace with markers for NdB and NdB BW. The bottom screen shows the N dB measurement results in real time.



N dB BW Measurement

3. Press $NdB[F2]$ to set the NdB amplitude:

Amplitude: 0.1dB ~ 80.0 dB



Note


The NdB bandwidth measurements are strongly tied to the RBW and VBW.

Phase Jitter Measurement

Description	Phase Jitter refers to the amount of phase fluctuation and can be used to evaluate stability of a signal in the time domain.	
Parameters	Start Offset:	The start frequency with respect to the center frequency.
	Stop Offset:	The stop frequency with respect to the center frequency.

Measurement items	Carrier Power:	dBm
	Jitter in phase:	rad
	Jitter in time:	ns

Example



Operation:
Setting up the
main channel

1. Press Meas > *Phase Jitter*[F4] > *Phase Jitter*[F1] and turn Phase Jitter on.
 - *Any other measurement mode will automatically be disabled.*

2. The display splits into two screens. The top shows the trace with the start and stop offsets. The bottom screen shows the phase jitter measurements.



Phase jitter measurements

3. Press *Start Offset*[F2] to set the start offset:

Offset: (0Hz ~ ½ span freq)

4. Press *Stop Offset*[F3] to set the stop offset:

Offset: (0Hz ~ ½ span freq)



Note

The phase jitter measurements are strongly tied to the RBW and VBW.


Spectrum Emission Mask Overview

Description SEM measurements are used to measure the out-of-channel emissions relative to the in-channel power. SEM measurements are usually calculated for specified power bands at a number of different offsets to the carrier frequency. SEM measurements are often carried out for a number of different wireless standards.

For 3GPP, the GSP-930 supports BS (base station) and UE (user equipment) testing standards for both FDD (frequency-division duplexing) and TDD (time-division duplexing) modes.

The GSP-930 also supports SEM testing for 802.11b, 802.11g, 802.11n and 802.16 as well as user defined emission mask testing

Example



Parameters Chan Inte BW: Channel Integration Bandwidth. The Chan Inte BW is used to measure the in-channel power.

Chan Span:	Used to define the span of the main channel when measuring the channel power.
RBW:	Sets the resolution bandwidth for the main channel when measuring the in-channel power.
Total Power Reference:	The total power of the carrier that is used as the reference for calculating the offset power.
PSD Ref:	The mean power spectral density of the carrier that is used as the reference for calculating the offset power.
Select Offset:	Selects the offset pairs (1 ~ 5) used for configuration.
Start Freq:	Sets the start frequency offset for the selected offset number.
Stop Freq:	Sets the stop frequency offset for the selected offset number.
RBW:	Sets the resolution bandwidth of the selected offset number.
Abs Start:	Sets the absolute level limit at the Start Freq for selected offset number.

Abs Stop: Sets the absolute level limit at the Stop Freq for the selected offset number. The Abs Stop level limit can be set to Couple or Man. Man allows Abs Stop to be user-defined, while Couple will lock Abs Stop to the Abs Start level limit.

Rel Start: Sets the relative level limit at the Start Freq for the selected offset number.

Rel Stop: Sets the relative level limit at the Stop Freq for the selected offset number. Rel Stop can be set to Couple or Man. Man allows Rel Stop to be user-defined, while Couple will lock Rel Stop to the Rel Start level limit.

Fail Mask: Sets the fail conditions for measurement with regards to the level limits: Absolute, Relative, Absolute & Relative, Absolute or Relative.

Measurement items

Main Channel Bandwidth: Unit: Hz

Total Power: Unit: dBm

PSD (Power Spectral Density): Unit: dBm/Hz

Offset 1~5: Lower dBm, Upper dBm

3GPP Operating Bands*

Operating Band	UL Frequencies UE transmit, Node B receive	DL Frequencies UE receive, Node B transmit
I	1920~1980MHz	2110~2170MHz
II	1850~1910MHz	1930~1990 MHz
II	1710~1785MHz	1805~1880MHz
IV	1710~1755MHz	2110~2155MHz
V	824~849MHz	869~894MHz
VI	830~840MHz	875~885MHz
VII	2500~2570MHz	2620~2690MHz
VIII	880~915MHz	925~960MHz
IX	1749.9~1784.9MHz	1844.9~1879.9MHz
X	1710~1770MHz	2110~2170MHz
XI	1427.9~1452.9MHz	1475.9~1500.9MHz
XII	698~716MHz	728~746MHz
XIII	777~787MHz	746~756MHz
XIV	788~796MHz	758~768MHz
XV	Reserved	Reserved
XVI	Reserved	Reserved
XVII	Reserved	Reserved
XVIII	Reserved	Reserved
XIX	830~845MHz	875~890MHz
XX	832~862MHz	791~821MHz
XXI	1447.9~1462.9MHz	1495.9~1510.9MHz
XXV	1850~1915MHz	1930~1995MHz

*for FDD, referenced from ETSI:

3GPP TS 25.101 version 10.2.0 Release 10

3GPP TS 25.104 version 10.2.0 Release 10

3GPP-FDD BS For the FDD configuration, different limits can be chosen based on the total channel power, P.

The default value for Δf_{max} is 12.5MHz. Δf_{max} can be user-defined.

The channel span is set to 5MHz.

Note: A, B, C, D, E denote offsets 1 to 5, respectively.

$P \geq 43$	Unit: MHz	Abs ^[1]	RBW
	$2.5 \leq A < 2.7$	-14dBm	30kHz
	$2.7 \leq B < 3.5$	-14 ~ -26dBm	30kHz
	$3.5 \leq C < \Delta f_{max}$	-13dBm	1MHz
$39 \leq P < 43$	Unit: MHz	Abs ^[1]	RBW
	$2.5 \leq A < 2.7$	-15dBm	30kHz
	$2.7 \leq B < 3.5$	-14 ~ -26dBm	30kHz
	$3.5 \leq C < 7.5$	-13dBm	1MHz
$31 \leq P < 39$	Unit: MHz	Abs ^[1]	RBW
	$2.5 \leq A < 2.7$	P-53dB	30kHz
	$2.7 \leq B < 3.5$	P-53dB~ P-56dB	30kHz
	$3.5 \leq C < 7.5$	P-52dB	1MHz
$P < 31$	Unit: MHz	Abs ^[1]	RBW
	$2.5 \leq A < 2.7$	-22dBm	30kHz
	$2.7 \leq B < 3.5$	-22 ~ -34dBm	30kHz
	$3.5 \leq C < 7.5$	-21dBm	1MHz
	$7.5 \leq D < \Delta f_{max}$	-25dBm	1MHz

For $P < 31$, two additional power limits (shown below) can be selected via the *Additional Max Out. Pwr* option for Home BS applications:

(The default value for Δf_{max} is 14.5 MHz. Δf_{max} can be user-defined)

$6 \leq P \leq 20$	Unit: MHz	Abs ^[1]	RBW
	$12.5 \leq E < \Delta f_{max}$	P- 56dB	1MHz
P<6	Unit: MHz	Abs ^[1]	RBW
	$12.5 \leq E < \Delta f_{max}$	-50dBm	1MHz

**3GPP-FDD BS
Additional
Requirements**

For operation in bands II, IV, V, X, XII, XIII, XIV and XXV, additional requirements (listed below) apply in addition to the minimum requirements listed above.

Bands: II, IV, X	Unit: MHz	Additional ^[3]	RBW
	$2.5 \leq A < 3.5$	-15dBm	30kHz
	$3.5 \leq B < \Delta f_{max}$	-13dBm	1MHz
Bands: V	Unit: MHz	Additional ^[3]	RBW
	$2.5 \leq A < 3.5$	-15dBm	30kHz
	$3.5 \leq B < \Delta f_{max}$	-13dBm	100kHz
Bands: XII, XIII, XIV	Unit: MHz	Additional ^[3]	RBW
	$2.5 \leq A < 3.5$	-13dBm	30kHz
	$3.5 \leq B < \Delta f_{max}$	-13dBm	100kHz

3GPP-FDD UE

The channel span is set to 5MHz.

Note: A, B, C, D, E denote offsets 1 to 5, respectively.

Unit: MHz	Rel	Abs ^[1]	RBW
$2.5 \leq A < 3.5$	-35~-50dBc	-71.1dBm	30kHz
$3.5 \leq B < 7.5$	-35~-39dBc	-55.8dBm	1MHz
$7.5 \leq C < 8.5$	-39~-49dBc	-55.8dBm	1MHz
$8.5 \leq D < 12.5$	-49~-49dBc	-55.8dBm	1MHz

3GPP-FDD UE Additional Requirements	Additional requirements for 3GPP-FDD UE.			
	Bands II, IV, X	Unit: MHz	Additional ^[3]	RBW
		$2.5 \leq A < 3.5$	-15dBm	30kHz
		$3.5 \leq B < 12.5$	-15dBm	1MHz
	Band V	Unit: MHz	Additional ^[3]	RBW
		$2.5 \leq A < 3.5$	-15dBm	30kHz
		$3.5 \leq B < 12.5$	-13dBm	100kHz
	Bands XII, XIII, XIV	Unit: MHz	Additional ^[3]	RBW
		$2.5 \leq A < 3.5$	-13dBm	30kHz
		$3.5 \leq B < 12.5$	-13dBm	100kHz

3GPP-TDD BS
3.84Mcps*

For the TDD configuration, different limits can be chosen based on the total channel power,

The channel span:
3.84Mcps: 5MHz.

Note: A, B, C, D, E denote offsets 1 to 5, respectively.

$P \geq 43$	Unit: MHz	Abs ^[1]	RBW
	$2.5 \leq A < 2.7$	-14dBm	30kHz
	$2.7 \leq B < 3.5$	-14 ~ -26dBm	30kHz
	$3.5 \leq C < 12$	-13dBm	1MHz
$39 \leq P < 43$	Unit: MHz	Abs ^[1]	RBW
	$2.5 \leq A < 2.7$	-14dBm	30kHz
	$2.7 \leq B < 3.5$	-14 ~ -26dBm	30kHz
	$3.5 \leq C < 7.5$	-13dBm	1MHz
	$7.5 \leq D < 12$	P-56dB	1MHz

31 ≤ P < 39	Unit: MHz	Abs ^[1]	RBW
	2.5 ≤ A < 2.7	P-53dBm	30kHz
	2.7 ≤ B < 3.5	P-53~P-65dBm	30kHz
	3.5 ≤ C < 7.5	P-52dBm	1MHz
	7.5 ≤ C < 12	P-56dBm	1MHz
P ≤ 31	Unit: MHz	Abs ^[1]	RBW
	2.5 ≤ A < 2.7	-22dBm	30kHz
	2.7 ≤ B < 3.5	-22 ~ -34dBm	30kHz
	3.5 ≤ C < 7.5	-21dBm	1MHz
	7.5 ≤ D < 12	-25dBm	1MHz

*referenced from ETSI:

3GPP TS 25.102 version 10.2.0 Release 10

3GPP TS 25.105 version 10.3.0 Release 10

3GPP-TDD BS
1.28Mcps

The channel span:
1.28Mcps: 1.6MHz.

P ≥ 34	Unit: MHz	Abs ^[1]	RBW
	0.8 ≤ A < 1	-20dBm	30kHz
	1 ≤ B < 1.8	-20 ~ -28dBm	30kHz
	1.8 ≤ C < 3.5	-13dBm	1MHz
26 ≤ P < 34	Unit: MHz	Abs ^[1]	RBW
	0.8 ≤ A < 1	P-54dB	30kHz
	1 ≤ B < 1.8	P-54~P-62dB	30kHz
	1.8 ≤ C < 3.5	P-47dB	1MHz
P < 26	Unit: MHz	Abs ^[1]	RBW
	0.8 ≤ A < 1	-28dBm	30kHz
	1 ≤ B < 1.8	-28~-36dBm	30kHz
	1.8 ≤ C < 3.5	-21dBm	1MHz

3GPP-TDD BS
7.68 Mcps

The channel span:
7.68Mcps: 10MHz.

P \geq 43	Unit: MHz	Abs ^[1]	RBW
	5 \leq A<5.2	-17dBm	30kHz
	5.2 \leq B<6	-17 ~ -29dBm	30kHz
	6 \leq C<24.5	-16dBm	1MHz
39 \leq P<43	Unit: MHz	Abs ^[1]	RBW
	5 \leq A<5.2	-17dBm	30kHz
	5.2 \leq B<6	-17 ~ -29dBm	30kHz
	6 \leq C<15	-16dBm	1MHz
31 \leq P<39	Unit: MHz	Abs ^[1]	RBW
	5 \leq A<5.2	P-56dB	30kHz
	5.2 \leq B<6	P-56~P-68dB	30kHz
	6 \leq C<15	P-55dB	1MHz
P<31	Unit: MHz	Abs ^[1]	RBW
	5 \leq A<5.2	-25dBm	30kHz
	5.2 \leq B<6	-25~-37dBm	30kHz
	6 \leq C<15	-24dBm	1MHz
	15 \leq D \leq 24.5	-28dBm	1MHz

3GPP-TDD UE The channel span:
 3.84Mcps: 5MHz.
 1.28Mcps: 1.6MHz.
 7.68Mcps: 10MHz.

Note: A, B, C, D, E denote offsets 1 to 5, respectively.

3.84Mcps	Unit: MHz	Rel ^[2]	RBW
	$2.5 \leq A < 3.5$	-35~-50dBc	30kHz
	$3.5 \leq B < 7.5$	-35 ~ -39dBc	1MHz
	$7.5 \leq C < 8.5$	-39~-49dBc	1MHz
1.28Mcps	Unit: MHz	Rel ^[2]	RBW
	$0.8 \leq A < 1.8$	-35~-49dBc	30kHz
	$1.8 \leq B < 2.4$	-49~-59.2dBc	30kHz
	$2.4 \leq C < 4$	-44dBc	1MHz
7.68Mcps	Unit: MHz	Rel ^[2]	RBW
	$5 \leq A < 5.75$	-38~-46dBc	30kHz
	$5.75 \leq B < 7$	-46 ~ -53dBc	30kHz
	$7 \leq C < 15$	-38~-42dBc	1MHz
	$15 \leq D < 17$	-42~-52dBc	1MHz
	$17 \leq E < 25$	-53dBc	1MHz

802.11b* The channel span: 22MHz

Note: A, B denotes offsets 1 and offset 2.
 Here the default value of “f” is 24MHz. This can be user-defined.

Unit: MHz	Rel ^[2]	RBW
$11 \leq A < 22$	-30dBc	100kHz
$22 \leq B < f$	-50dBc	100kHz

*reference: IEEE Std 802.11b-1999

802.11g

The channel span:

ERP-OFDM/DSSS-OFDM : 18MHz

ERP-DSSS/ERP-PBCC/ERP-CCK: 22MHz

Note: A, B, C, D denote offsets 1 to 4, respectively.
 Here the default value of “f” is 40MHz (ERP-OFDM/
 DSSS-OFDM) or 25MHz (ERP-DSSS/ ERP-PBCC/
 ERP-CCK). This can be user-defined.

	Unit: MHz	Rel ^[2]	RBW
ERP-OFDM/ DSSS- OFDM	$9 \leq A < 11$	-0~-20dBc	100kHz
	$11 \leq B < 20$	-20~-28dBc	100kHz
	$20 \leq C < 30$	-28~-40dBc	100kHz
	$30 \leq D < f$	-40dBc	100kHz
	Unit: MHz	Rel ^[2]	RBW
ERP-DSSS/ ERP-PBCC/ ERP-CCK	$11 \leq A < 22$	-30dBc	100kHz
	$22 \leq B < f$	-50dBc	100kHz

*reference: IEEE Std 802.11a-1999

802.11n

The channel span:

CH BW 20MHz: 18MHz

CH BW 40MHz: 38MHz

Note: A, B, C, D denote offsets 1 to 4, respectively.
 Here the default value of “f” is 40MHz(CHBW
 20MHz) or 70MHz(CHBW 40MHz). This can be user-
 defined.

	Unit: MHz	Rel ^[2]	RBW
CH BW 20MHz	$9 \leq A < 11$	-0~-20dBc	100kHz
	$11 \leq B < 20$	-20~-28dBc	100kHz
	$20 \leq C < 30$	-28~-45dBc	100kHz
	$30 \leq D < f$	-45dBc	100kHz

	Unit: MHz	Rel ^[2]	RBW
CH BW 40MHz	$19 \leq A < 21$	0~-20dBc	100kHz
	$21 \leq B < 40$	-20~-28dBc	100kHz
	$40 \leq C < 60$	-28~-45dBc	100kHz
	$60 \leq D < f$	-45dBc	100kHz

*reference: IEEE Std 802.1n-2009

802.16* The channel span:
 CH BW 20MHz: 19MHz
 CH BW 10MHz: 9.5MHz

Note: A, B, C, D denote offsets 1 to 4, respectively.
 Here the default value of “f” is 16.75MHz(CHBW 20MHz) or 31.5MHz(CHBW 10MHz). This can be user-defined.

	Unit: MHz	Rel ^[2]	RBW
CH BW 20MHz	$9.5 \leq A < 10.9$	0~-25dBc	100kHz
	$10.9 \leq B < 19.5$	-25~-32dBc	100kHz
	$19.5 \leq C < 29.5$	-32~-50dBc	100kHz
	$29.5 \leq D < f$	-50dBc	100kHz

	Unit: MHz	Rel ^[2]	RBW
CH BW 10MHz	$4.75 \leq A < 5.45$	0~-25dBc	100kHz
	$5.45 \leq B < 9.75$	-25~-32dBc	100kHz
	$9.75 \leq C < 14.75$	-32~-50dBc	100kHz
	$14.75 \leq D < f$	-50dBc	100kHz

*reference: IEEE Std 802.16-2009



Note

- ^[1] Abs: Absolute limit
 - ^[2] Rel: Relative limit(to the total power or the power spectral density, depending on the compliance of the main channel)
 - ^[3] Additional: Additional absolute limit
- Pass Fail Criteria:


Case 1: When both Abs and Rel are used, the

highest value (Abs or Rel) is used as the Pass/Fail judgment. The trace points under the limit indicate a pass.


Case2: If the additional limit is used, the higher value from case1 is compared to the additional limit. The lowest one is used as the pass/fail judgment.

Spectrum Emission Mask Testing

Description	For spectrum emission mask testing, the GSP-930 has pre-defined testing parameters for 3GPP, 802.11x and 802.16. The GSP-930 also allows you to perform user-defined SEM testing.
-------------	---

- | | |
|------------|--|
| Operation: | <ol style="list-style-type: none">1. Press  > SEM[F5]>SEM[F2] and turn SEM on.<ul style="list-style-type: none">• <i>Any other measurement mode will automatically be disabled.</i>2. The display splits into two screens. The top shows the trace with the absolute and or relative masks. The bottom screen shows the SEM measurement results. |
|------------|--|
-

Absolute
limit line



SEM measurements

User Defined Parameters

1. Press *Setup*[F1]>*User Define*[F6] to set SEM measurement to user defined parameters.
2. Press *Meas Type*[F1] choose between *TotalPwrRef*[F1] or *PSDRef*[F2].
3. Press *Ref. Channel*[F2] and set the following:

- ChanIntegBW*[F1] Sets the channel integration bandwidth.
- Chan Span*[F2] Sets the channel span
- RBW*[F3] Sets the resolution bandwidth.
- TotalPwrRef*[F4]/
PSDRef[F4] Sets the total power/PSD reference level.

4. Press *Return*[F7] to return the previous menu.

5. Press *Offset/Limit*[F3] to set the offset parameters:

<i>SelectOffset</i> [F1]	Select which offset to edit.
[F2]	Toggles the selected offset on/off.
<i>StartFreq</i> [F3]	Sets the start frequency of the selected offset.
<i>StopFreq</i> [F4]	Sets the Stop Frequency of the selected offset.
<i>RBW</i> [F5]	Sets the RBW of the selected offset.

6. Press *More 1/2*[F6] to set absolute and relative level limits and conditions:

<i>Abs Start</i> [F2]	Sets the absolute start level limit for the selected offset.
<i>Abs Stop</i> [F3]	Sets the absolute stop level limit for the selected offset.
	Man: Allows a user-defined Abs Stop level
	Couple: Sets the Abs Stop level to the Abs Start level.
<i>Rel Start</i> [F4]	Sets the relative start level limit for the selected offset.

Rel Stop[F5] Sets the relative stop level for the selected offset.

Man: Allows a user-defined Abs Stop level.

Couple: Sets the Rel Stop level to the Rel Start level.

7. Press *Fail Mask[F6]* to set the Fail Mask conditions:

Absolute[F1] Sets the fail condition to the Absolute level limit.

Relative[F2] Sets the fail condition to the relative level limit.

Abs AND Rel[F3] Sets the fail condition as both the absolute and relative level limits.

Abs OR Rel[F4] Sets the fail condition to either the absolute or relative level limits.

8. Press *Select Offset[F1]* and repeat the above steps for any other offsets.

Offset: 1~5

Pre-Set Test
Parameters:
3GPP

For details on 3GPP SEM test parameters, please see the SEM overview on page 132.

1. Press *Setup[F1]>3GPP[F1]* to choose 3GPP measurement.

2. Press *Ref. Channel*[F2] and set the following:

RBW[F3] Sets the resolution bandwidth.

3. All other reference channel settings are pre-defined.

4. Press *Return*[F7] to return the previous menu.

5. Press *Offset/Limit*[F3]>*Duplexing Mode*[F1] and choose FDD or TDD duplexing:

6. For FDD, press *FDD Setup*[F2] set the FDD parameters, for TDD, press *TDD Setup*[F3]:

Transmission[F1] Toggles between BS and UE testing

Chip Rate[F2] Selects the bandwidth of the RRC filter that is used to measure the in-channel power for TDD duplexing:
3.84MHz, 1.28MHz,
7.68MHz

Max Out Pwr[F2/F3] Sets the maximum output power for BS tests:
P>=43
39<=P<=43
31<=P<=39
P<31

<i>Add.limits[F4]</i>	Selects the operating bands for FDD duplexing: None BandII BandIV BandV BandX BandX11 BandXIII BandXIV
<i>MinOffset/ Limit Value[F5]</i>	Allows you to view the parameters of each of the offsets, including start/stop frequency, RBW, Abs Start/Stop and Rel Start/Stop.

Pre-Set Test Parameters: 802.XX For details on 802.11x and 802.16 SEM test parameters, please see the SEM overview on page 132

1. Press *Setup[F1]*> and choose a 802.XX test:

802.11b[F2]
802.11g[F3]
802.11n[F4]
802.16[F5]

2. Press *Ref. Channel[F2]* to view the predefined settings for channel integrated bandwidth, channel span, RBW and PSD ref.
3. Press *Offset/Limit[F3]* to view the parameter values of each of the offsets, including Start and Stop Frequency, RBW, Rel Start and Stop

Third Order Intermodulation Distortion (TOI)


Description Third order intermodulation distortion measurement is used to calculate the TOI products caused by two signals that are close together in frequency in a non-linear system. Both the upper and lower third order intercept points (IP₃) are calculated. Markers are placed at the frequencies of the TOI products and their respective base signals.

Limits can be placed on the upper and lower TOI products for limit testing.

Parameters	Reference Lower	Sets the reference level to lowest base signal.
	Reference Upper	Set the reference level to the highest base signal.
	Limit	Sets the limit in dBm for pass/fail testing
	Pass/Fail Test	Enables/disables pass/fail testing.

Measurement items	Base Upper	Frequency, dBm, dBc.
	Base Lower	Frequency, dBm, dBc
	3 rd Order Lower	Frequency, dBm, dBc, limit, Intercept point
	3 rd Order Upper	Frequency, dBm, dBc, limit, Intercept point
	Δf	Frequency


Example



Operation:

1. Press **Meas** > **TOI[F6]**>**TOI[F1]** and turn TOI on.
 - Any other measurement mode will automatically be disabled.
2. The display splits into two screens. The top shows the trace with markers in the upper and lower base frequencies and the upper and lower 3rd order intermodulation products. The bottom screen shows the TOI measurements and pass/fail results.

3rd Order Lower and 3rd Order upper marker
 lower upper base upper
 marker marker



TOI measurement and results

3. Press *Reference*[F2] to set the reference to the upper or lower base frequencies.

4. Press *Limit*[F3] and set the limit for the upper and lower 3rd order intermodulation product amplitude.

5. Press *Pass/Fail Test*[F4] to toggle pass/fail testing on/off.


CNR/CSO/CTB Measurement

Carrier to Noise Ratio (CNR)

Description	Carrier to noise ratio calculates the difference in amplitude between the carrier signal and the noise level present in the transmission. CNR measurements are used for both analog and digital CATV.	
Parameters	Noise Marking	<p>Sets the position of the delta marker ($\Delta 1$) using two options:</p> <p>MIN: The delta marker will search for the minimum between the carrier frequency and the carrier frequency + 4MHz.</p> <p>ΔMarker: User defined delta marker position.</p>

Measurement items	Visual Carrier	frequency, amplitude
	CNR	amplitude difference
	Δf	frequency difference between visual carrier and noise marker.

Example




Operation:

1. Press **Meas** > **CNR/CSO/CTB[F7]** > **Setup[F1]** > **CNR[F1]** to choose CNR measurement.
2. Press **Noise Marking[F1]** and toggle the noise marker type between Min and Δ Marker.
3. If Min was selected, press **Return[F7]** to return to the previous menu.
4. If Δ Marker was selected, press **Marker** > **Delta[F4]** > **Delta[F1]** and set the delta marker position.
- See page 86 for details on moving markers.

Press **Meas** > **CNR/CSO/CTB[F7]** to return to the previous menu.

5. Press **CNR[F2]** and turn CNR on.
 - Any other measurement mode will automatically be disabled.
 - Ensure the aural and color subcarriers are disabled before CNR is turned on.
6. The display splits into two screens. The top shows the trace with the visual carrier marker and the noise marker. The bottom screen shows the CNR measurements.



CNR measurements

7. Press **CNR CH SP[F2]** to set the channel space.

Range: 0~3GHz

8. Press **Channel Move Down[F4]** or **Channel Move Up [F5]** to move to the next or previous channel.



Note

Ensure the aural and color subcarriers are turned off when making CNR measurements.


Composite Second Order (CSO)

Description Composite Second Order measurement calculates the difference in amplitude between the carrier signal and the composite second order beat.


Parameters CSO CH SP: The channel space.

Measurement items Visual Carrier: frequency, amplitude
 Channel Space: frequency
 CSO: amplitude difference

Example



- Operation:**
1. Press Meas > CNR/CSO/CTB[F7]>Setup[F1]>CSO[F2] and choose CSO.
 2. Press CSO[F2] and toggle CSO on.
 - Any other measurement mode will automatically be disabled.
 3. The display splits into two screens. The top shows the trace with the visual carrier marker and the CSO beat marker. The bottom screen shows the CSO measurements.



4. Press *CSO CH SP[F2]* to set the channel space.


Range: 0~3GHz

5. Press *Channel Move Down[F4]* or *Channel Move Up [F5]* to move to next or previous channel.

Composite Triple Beat (CTB)


Description	Composite triple beat measurement calculates the difference in amplitude between the visual carrier and the composite triple beat amplitude.
Measurement items	Visual Carrier: frequency, amplitude CTB: amplitude difference from the visual carrier and the triple beat Triple Beat: amplitude

Example




Operation:

1. Press **Meas** > **CNR/CSO/CTB[F7]** > **Setup[F1]** > **CTB[F2]** > **Return[F7]** to choose CTB measurement and return to the previous menu.
2. Press **CTB[F2]** and turn CTB on.
 - Any other measurement mode will automatically be disabled.
3. The display splits into two screens. The top shows the trace with the visual carrier marker. The bottom screen shows the CTB measurements.
 - This will place a marker (1) on the visual carrier and record the amplitude.



CTB measurements

4. Turn off the visual carrier signal from the input and press the  key on the front panel.
5. A second trace will appear to mark the CTB amplitude.
 - This will place a marker ($\frac{2}{\diamond}$) on the second trace and calculate the difference ($\frac{1}{\diamond} - \frac{2}{\diamond}$).
6. Press CTB CH SP[F2] to set the channel space.

Range: 0~3GHz

7. Press *Channel Move Down*[F4] or *Channel Move Up* [F5] to move to next or previous channel.



Note

To perform the CTB measurement again, press *Setup*[F1]>*CTB*[F3]>*Restart*[F1].


Limit Line Testing


The limit line is used to set the upper or lower amplitude limits over the entire frequency range. The limit lines can be used to detect whether the input signal is above, below or within the limit lines.

The limit lines can be manually or automatically created. The limit lines can be manually edited by frequency or from the trace data or marker points.

- Creating a Limit (Point by Point) → from page 159.
- Creating a Limit (from Trace Data) → from page 161.
- Creating a Limit (from marker data) → from page 162.
- Creating a Limit (from marker data) → from page 162
- Delete Limit Line → from page 163
- Pass Fail Testing → from page 163

Creating a Limit (Point by Point)

Description	Create a limit manually, point by point. A maximum of ten points can be used.
Operation	<ol style="list-style-type: none"> 1. Press  > <i>Edit Limit Lines</i>[F1]><i>Limit Line</i> [F1] and choose a limit line. Limit line: 1~5 2. Press <i>Point by Point</i>[F2]. <p>The GSP-930 is split into two screens. The top screen shows the trace and limit lines and the bottom screen shows the limit line table.</p>



3. Press *Point Num*[F1] and choose a point number to edit (must start at #1).
4. Press *Frequency*[F2] and set the frequency of the first point.
5. Press *Limit*[F3] and set the amplitude level of the point.

All the points will be displayed in a limit line table at the bottom of the display.

6. Repeat steps 3-5 for the remaining points (max 10).
7. To delete the selected point, press *Delete Point*[F6].
8. Press *Return*[F7]>*Save Save Limit Line*[F5] to save the currently selected limit line.



Note that the limit lines are automatically sorted by frequency (low → high).

Creating a Limit (from Trace Data)

Description Trace data can be used to create limit lines. A 10 point limit line is created from the trace data at each grid division as well as the start and stop frequencies.


Operation 1. Press **Limit Line** > *Edit Limit Lines[F1]* > *Limit Line [F1]* and choose a limit line. (limit line 1~5).

Limit line: 1~5

2. Press *Trace Data to Limit Line[F3]*.

The GSP-930 is split into two screens. The top screen shows the trace and limit lines and the bottom screen shows the limit line table.

Spectrum display



Limit Line Table

3. Press *Limit Offset[F2]* and set an offset level.
4. Press *Create Limit Line Now[F1]*.
 - A limit line will automatically be created based on the trace and offset level.

- A limit line can be created any number of times.
5. Press *Return*[F7]>*Save Save Limit Line*[F5] to save the currently selected limit line.

Creating a Limit (from marker data)

Description Marker data can be used to create limit lines. Please see the marker chapter on page 83 for details on markers. A maximum of 10 points can be created.


- Operation**
1. Press **Limit Line** > *Edit Limit Lines*[F1]>*Limit Line* [F1] and choose a limit line.

Limit line: 1~5

2. Press *Mkr Data to Limit Line*[F4].

The GSP-930 is split into two screens. The top screen shows the trace and limit lines and the bottom screen shows the limit line table.

Spectrum display



Limit Line Table

3. Press *Point Num*[F1] and choose a point number

to edit (must start at #1).

4. Press *Limit Offset*[F3] and set offset level for the point.
5. Press *Mkr Data to Point*[F2]. This adds the currently active marker's position to the selected point.
6. The marker position can be moved at this point using the scroll wheel. Press the Enter key to set the position.
7. Repeat steps 3-5 for any other points (max 10).
8. Press *Return*[F7]>*Save Limit Line*[F5] to save the currently selected limit line.




Note

Using this function will also change the position of marker 1 outside of the limit function.

Delete Limit Line


Description	Any one of the 5 limit lines can be deleted.
-------------	--

Activate Correction	<ol style="list-style-type: none"> 1. Press  > <i>Edit Limit Lines</i>[F1]><i>Limit Line</i>[F1] and choose a limit line (limit line 1~5) to delete. 2. Press <i>Delete Limit Line</i>[F6]. The data from the chosen limit line will be deleted.
------------------------	--

Pass Fail Testing

Description	Before pass/fail testing can begin, limit lines for the upper and lower limits must first be saved. See the page 116.
-------------	---

Operation

1. Press  > *Pass/Fail Test*.
2. To set a high limit, press *High Limit[F1]* and choose one of the limit lines as the upper (high) limit.
3. To set the low limit, press *Low Limit[F2]* and select one of the limit lines as the lower limit.
4. Press *Pass Criterion[F3]* and select the pass criteria.

Criteria: All-In, Max-In, Min-In

5. Press *Pass/Fail Test* and turn the testing on.
6. The test result appears in the bottom of the display.

Pass: 

Fail: 

Display Icon



The alarm icon is shown at the bottom of the display whenever testing is turned on.



Note

At least one limit line (high or low) must be turned on to enable testing.

If the high limit or low limit is turned off, the maximum or minimum* display level is set automatically as the high or low limit, respectively.

* +30dBm+Ref level offset or -120dBm+Ref level offset


Sequence

The Sequence function records and plays back user-defined macros, up to 5 sequences are available in repeat or single running mode, each with up to 20 steps. Delays and pauses can also be introduced into a sequence to view measurement results during a sequence. Sequences can also call other sequences to create longer sequences.


The sections below can be used to skip to the relevant section:

- Edit Sequence → from page 165
- Run Sequence → from page 169

Editing a Sequence

Edit a Sequence 7. Press  > *Sequence[F1]* and choose a sequence to edit/create.

Sequence: 1~5

8. Press *Edit[F2]* > *Start Edit[F1]* to start editing the selected sequence.
9. The display splits into two screens. The top screen shows the main screen. The bottom screen shows the Sequence Editor with the sequence steps.
 - The  **Start Edit** icon appears in the sequence editor window.

Main display



Start Edit/Stop Edit icon

Sequence Editor window

Add a Step

Up to 20 steps can be added to each sequence. Each panel operation is recorded as a step. After each panel operation is performed, press the **Enter** key to record the step (in some cases this is not necessary – check if the operation appears in the sequence editor window).

In the following example the center frequency and span are added as steps to a sequence:

1. Press **Frequency** > *Center Freq[F1]* > 20MHz > **Enter** .
2. Press **Span** > *Zero Span[F3]* > **Enter** .
3. The two operations are added to the Sequence Editor.



Note


The arrow keys can be used to move the cursor to the desired step.

Add Delay to Sequence

The delay function adds a delay between steps.

1. Press *Delay Time*[F2]> and enter the delay time.

Range: 100ms ~ 10s

2. Press  to add the delay time to the sequence editor.
 - *The delay time will be inserted as a step.*





Note

The arrow keys can be used to move the cursor to the desired step.

Pause Sequence

The Wait to Go function is used to pause a sequence until Continue[F1] is pressed. This is useful for observing measurements before moving onto the next step.


1. Press *Wait to Go*[F3]> .
- *Wait to Go will be inserted as a step.*



2. When a sequence is running, Press *Continue*[F1] to resume running the sequence.

Insert Sequence Inserts another sequence into the current sequence.

1. Press *Do Sequence*[F4]> and select a sequence to insert into the current sequence.
 - *The selected sequence will be inserted as a step.*




Note


The current sequence cannot be inserted into itself.

Delete Step Any step in the Sequence Editor can be deleted.

1. Use the arrow keys on the front panel to highlight the step you wish to delete.




2. Press *Delete Step*[F5] > to delete the step.
 - *The selected step will be removed from the Sequence editor.*




Stop Editing 1. Press *Stop Edit*[F6].


2. The  **Start Edit** icon turns off.

Save Current Sequence After a sequence has been edited (and stopped) it can be saved.

1. Press  > Save Sequence [F4] > to save the sequence.
 2. The selected sequence will be saved.
-

Delete Current Sequence 1. Press  > Delete Sequence [F5] > to delete the current sequence.

Running a Sequence

Run Mode 1. Press  > *Sequence*[F1] and choose a sequence.

2. Press *Run Mode*[F6] and toggle the run mode:

Single	Runs the sequence once only.
Cont.	Runs the sequence continually until Stop Running Sequence[F7] is pressed (Note: the Stop Running Sequence[F7] option only appears when the sequence is running)

Run Sequence 3. Press *Run Now*[F7] to start running the selected sequence.

4. Press *Stop Running Sequence*[F7] to stop the sequence.

- *In single mode the sequence will stop running when all steps have finished.*


Tracking Generator

The tracking generator is a factory installed option that generates a sweep signal with its sweep time and frequency range matching the GSP-930. The amplitude is maintained at a constant value over the entire frequency range. This is useful for testing the frequency response of the DUT.

- Activate the Tracking Generator → from page 170
- Normalize the Tracking Generator → from page 171

Activate Tracking Generator

Operation

1. Press  >More 1/2[F7]>Option[F1]>Tracking Generator[F1]>TG[F1] and toggle the tracking generator on.
 - *The TG OUTPUT will be activated.*

2. Press *TG Level*[F2] to set the output level of the tracking generator.

Range: -50 to 0dBm

3. Press *TG Lvl Offset*[F3] to set the offset level of the tracking generator to compensate for system gain/loss.

Range: -10dB to 10dB

4. Press *TG Lvl Step*[F4] to set the step resolution of the TG level.

Range: 0.5 to 50dB, 0.5dB step


5. Press *Power Sweep*[F5] to vary the output power of the TG to the rate of the sweep. At the beginning of the sweep, the output power is at

the set TG Level and increases/ decreases linearly to the set Power Sweep level at the end of the sweep.

Range: -5dB to +5dB

Normalize the Tracking Generator

Background The normalize function subtracts the trace after each sweep with a reference trace. The resultant trace is added to a normalized reference level.

- Operation**
1. Press  > More 1/2[F7] > Option[F1] > Tracking Generator[F1] > TG[F1] and toggle the tracking generator on.
 2. Press *Normalize*[F6] to enter the Normalization menu.
 3. Press *Norm. Ref. Level*[F2] to set the vertical level of the normalized reference.

Range: 0dB~100dB

4. Press *Norm. Ref. Position*[F3] offsets the normalized trace on the screen.

Range: 10~0 grid divisions.
(top to bottom)

5. Press *Norm.[F5]* to toggle the normalized data on/off.

Alternatively, press *Exe. Norm.[F1]* to perform the normalization again.



Note

The normalized data will be turned off automatically if any X-axis related parameters are changed or if the TG output level is changed.

The warning message, “Execute Normalization again!” will appear under these circumstances.

Power Meter


When using the optional power meter, the GSP can measure and log the average signal power level of a DUT from -32dBm ~ +20dBm over an operating frequency range of 1Mhz to 6.2GHz.

- Activating Power Meter Mode → from page 173
- Data Logging Power Meter Measurements → from page 175

Activating Power Meter Mode

Operation

1. Press **Mode** > *Power Meter*[F2] to enter the power meter mode.
2. The display splits into two screens. The top screen shows the power measurement in dBm or W. The bottom screen shows a graph of the measurements.



3. Press *Power Unit*[F1] and choose the unit:

Unit	dBm, W
------	--------



- Press *Frequency*[F2] choose measurement frequency:

Frequency	1MHz~6200MHz
Resolution:	1MHz

- Press *Sensor Mode*[F3] to choose measurement speed (and thus accuracy) of the power meter:

Low Noise:	100ms/sample, typical
Fast:	30ms/sample, typical


- To create pass fail tests, press *Pass/Fail Test*[F4] and set the following parameters:

<i>High Limit</i> [F1]:	-100dBm~20dBm
<i>Low Limit</i> [F2]:	-100dBm~20dBm
<i>Pass/Fail Test</i> [F3]:	On, Off
<i>Pass Icon:</i>	
<i>Fail Icon:</i>	

- Press *Trigger*[F5] to toggle between a free run (internal) trigger and an external trigger.

Trigger:	Free, Ext
----------	-----------

Ext trigger input:	3.3V CMOS
--------------------	-----------



- Press *MAX/MIN HOLD*[F6] to toggle the MAX/MIN hold measurements on/off in the power meter bar.
 - The MIN/MAX measurements will be displayed in the power bar meter in the center of the screen.



Note

The return to the Spectrum Mode, press Mode > *Spectrum[F1]*.

Data Logging Power Meter Measurements

Description When in Power Meter mode, the spectrum analyzer is able to log the power meter measurements over a user-defined time period at user-defined intervals.

- Operation**
1. Press Save to enter the save menu.
 2. Press *Type[F2]* and select *Power Meter[F7]*.
 3. Press *Data Source[F3]* and select *Power State[F1]*.
 4. Press *PMET Record Option[F4]* and set the recording options:

Record Stop[F1]: Sets the recording time for automatic data logging:
 00 :00 :00 (continuous) or
 00 :00 :01 ~ 23 :59 :59

Record Step[F2]: 1sec ~ 999sec

5. Press *Save To[F1]* and select a destination source:

Register 1~6: Internal memory registers, these internal registers are not part of local memory

Local: Internal memory

SD Card:

External micro SD card




Note

The micro SD card option will only be available when a micro SD card is inserted into the front panel port.


6. After a destination has been selected, recording options appear.

7. To name the log file, press *Name[F1]*. Name the selected file using the F1~F7 keys, as shown below or use the numeric keypad to enter numbers.




Limitations:

- *No spaces*
- *Only 1~9, A~Z, a~z characters allowed*



8. The filename appears on the bottom of the screen as it is created.



Press  to confirm setting the filename.



Note

If the file name is not user-defined, a file name will be automatically created in the following format:

File name: type_data source_file number.file extension

The file number parameter is incremented each time the same file type is created.

9. To start recording power meter measurements, press *Record Now*[F3].

A message “SaveFinish!!” will be displayed at the bottom of the screen when the recording has finished.

Stop Recording

To manually stop the recording, press *Record Stop*[F2].

FILE

File Overview

The File function is used for basic file related operations including navigation, sorting copying and deleting. The GSP-930 has a number of different file formats for trace data, limit lines, amplitude correction, sequences and other panel operations. File source and destination locations (local, USB or micro SD) can also be chose with the file function.

- File Type Overview → from page 179
- File Types → from page 180
- Using the File Explorer → from page 181
- Copy Files → from page 183
- Move Files → from page 183
- Delete Files → from page 184
- Rename Files → from page 185
- Save Files → from page 187
- Recall Files → from page 190
- Quick Save → from page 192

File Type Overview

Local	The GSP-930 has 16MB of local memory to save data to.
USB	The GSP-930 can save to an external USB flash memory drive. USB Type: 1.1/2.0
Micro SD	The GSP-930 can save to a micro SD card. Format: SDSC, SDHC

File Types

Overview	The file types are listed in order as shown in the file
State	<p>State data contains the state of the each of the panel operations:</p> <ul style="list-style-type: none"> • <i>Frequency</i> • <i>Span</i> • <i>Amplitude</i> • <i>BW/Avg</i> • <i>Sweep</i> • <i>Trace</i> • <i>Display</i> • <i>Meas</i> • <i>Limit Line</i> • <i>Sequence</i> • <i>Trigger</i> • <i>Marker</i> • <i>Marker-></i> • <i>Peak Search</i> • <i>Preset</i> • <i>Mode</i> • <i>System</i>
Trace	<p>Trace data contains the trace data in comma separated values.</p> <ul style="list-style-type: none"> • <i>Center frequency</i> • <i>Span</i> • <i>Resolution Bandwidth</i> • <i>Video Bandwidth</i> • <i>Reference Level</i> • <i>Sweep Time</i> • <i>Point number (trace data points)</i>
Screen	Contains the JPEG file of the display (800X600)
Limit Line	<p>The limit line data contains the following in comma separated values:</p> <ul style="list-style-type: none"> • <i>Point number</i> • <i>Frequency value of point</i> • <i>Magnitude of point</i> • <i>Magnitude unit</i>

Correction	Correction data contains the following correction (line) data: <ul style="list-style-type: none"> • <i>Point number</i> • <i>Frequency value of point</i> • <i>Gain offset of point</i> • <i>Unit</i>
Sequence	The sequence files contain the sequence number and step operations for that sequence. This data is not designed to be user editable.
Power Meter	The power meter data contains: <ul style="list-style-type: none"> • <i>Date</i> • <i>Time</i> • <i>Power in dBm</i>

Using the File Explorer

Connect External Memory	To view files on a USB flash drive or micro SD card, insert the appropriate device into the front panel port.
-------------------------	---


Selecting files 1. Press  >File Explorer.

2. Select memory location:

<i>Local[F1]:</i>	Internal memory
<i>USB[F2]:</i>	Front panel USB memory.
<i>SD Card[F3]:</i>	Micro SD card.

3. The up/down arrow keys or the scroll wheel can be used to move up/down the file list.



4. The left/right arrow keys can be used to move to the next/previous page of files in the file list. 

View Files by Type The file explorer can be configured to only view files of a certain type. For details on file types, please see page 179.

1. Press *Type*[F2] and select a file type to view:

All	All file types can be viewed
State	View state files only
Trace	View trace files only
Screen	View screen shots only
Limit Line	View limit lines only
Correction	View correction data only
Sequence	View sequence files only
Power Meter	View power meter files only

After selecting a file type, only those types of files will be listed by the file explorer.

Sort Files Files can be sorted in ascending order by either name or by date. By default, files are sorted by name.

1. Press *Sort By*[F3] and choose the sorting type:

Name:	Sort by alphabetical order
Date	Sort by file creation date




Note

The USB and micro SD card options will only be available when a flash drive/SD card is inserted into the front panel ports.

Copy Files

Description	Files from local memory can be copied to external memory such as USB or micro SD card and vice versa.
-------------	---

Connect External Memory	Insert either a USB flash drive or micro SD card into the front panel connectors.
-------------------------	---

- | | |
|-----------------|--|
| Selecting files | <ol style="list-style-type: none">1. Press  >File Explorer.2. Select a file from local or external memory.3. Press <i>Copy to</i> [F4].4. Press <i>Media</i> [F1] and select the destination to copy to (local, USB, SD card).5. Press <i>Copy Now</i> [F2].6. The file is copied to the destination directory. |
|-----------------|--|
-




Note

The USB and micro SD card options will only be available when a flash drive/SD card is inserted into the front panel ports.

Move Files

Description	Files from local memory can be moved to external memory such as USB or micro SD card and vice versa.
-------------	--

Connect External Memory	Insert either a USB flash drive or micro SD card into the front panel connectors.
-------------------------	---


- Selecting files
1. Press  >File Explorer.
 2. Select a file from local or external memory.
 3. Press *Move to*[F4].
 4. Press *Media* [F1] and select the destination to move to (local, USB, SD card).
 5. Press *Move Now* [F2].
 6. The file is moved to the destination.



Note

The USB and micro SD card options will only be available when a flash drive/SD card is inserted into the front panel ports.

Delete Files

Description	Any files in local memory or external memory such as USB or micro SD card can be deleted.
Connect External Memory	To delete files on a USB flash drive or micro SD card, insert the appropriate device into the front panel port.
Delete File	<ol style="list-style-type: none"> 1. Press  >File Explorer. 2. Select a file from local or external memory. 3. Press <i>Delete</i>[F5]. 4. Press <i>Delete Now</i>[F1]. 5. The file will be deleted after <i>Delete Now</i> is pressed.

Delete Warning 1. To enable a prompt to confirm the deletion of a file, press *Delete Warning*[F2] and select an option:

- | | |
|-----------|--|
| Don't Ask | No confirmation dialog box will appear when a file is deleted. |
| Ask | Will prompt for the user to confirm whether to delete the file or not. |





The USB and micro SD card options will only be available when a flash drive/SD card is inserted into the front panel ports.

Rename Files

Description Any files in local memory or external memory such as USB or micro SD card can be renamed.


Connect External Memory To rename files on a USB flash drive or micro SD card, insert the appropriate device into the front panel ports.

- Rename File
1. Press  >File Explorer.
 2. Select a file from local or external memory.
 3. Press *Rename*[F6].
 4. Rename the selected file using the F1~F7 keys, as shown below or use the numeric keypad to enter numbers:




Limitations:

- No spaces
- Only 1~9, A~Z, a~z characters allowed



5. The filename appears in the list as it is renamed.

Filename




6. Press to confirm the renaming of the file.




Note

The USB and micro SD card options will only be available when a flash drive/SD card is inserted into the front panel ports.

Save Files

Description	Any function settings or configurations that have been applied to the spectrum analyzer can be saved using the  key.
-------------	---

Connect External Memory	To save files on a USB flash drive or micro SD card, insert the appropriate device into the front panel ports.
-------------------------	--

- Save File
1. Press  to enter the Save menu.
 2. Press *Type[F2]* and select a file type to save. See page 179 for details on file types:

State:	State data
Trace:	Trace data
Screen:	Screen shots
Limit Line:	Limit line data
Correction:	Correction data
Sequence:	Sequence files
Power meter	Power meter data

3. Press *Data Source[F3]* to select a data source for the file type if needed:

For state data:	Local state data
For trace data:	Trace1~4
For screen shots:	Normal: Screen shot is saved as is Save Toner: inverts the image file color to reduce ink when printing.
For limit line:	Limit line 1~5
For correction:	Correction data 1~5
For sequence:	Sequence 1~5

For power meter: Power meter 1 ~5

4. For trace data, press Format[F4] to select the format type to save:


Trace: Save trace data only
 Trace+State: Save trace and state data

5. Press *Save To*[F1] and select a destination source:

Register 1~6: Internal memory registers, these internal registers are not part of local memory
 Local: Internal memory
 USB: External memory
 SD Card: External micro SD card


6. After a destination has been selected, the file can be named or saved immediately.

7. To name the selected file, press *Name*[F5]. Name the selected file using the F1~F7 keys, as shown below or use the numeric keypad to enter numbers.:




Limitations:

- *No spaces*
- *Only 1~9, A~Z, a~z characters allowed*



8. The filename appears on the bottom of the screen as it is created.



9. Press **Enter** to confirm the naming of the file.



If the file name is not user-defined, a default naming scheme will be used. See the note below for details.

10. To save the selected file type, press *Save Now*[F3].

A message “SaveFinish!!” will be displayed at the bottom of the screen when the save is successful.



Note

If the file name is not user-defined, a file name will be automatically created in the following format for data files:

File name: Type_data source_XX.file extension

The image file names will be automatically created in the following format:

File name: NowPicture_XX.jpg

The XX parameter is incremented each time the same file type is created.



Note

The USB and micro SD card options will only be available when a flash drive/SD card is inserted into the front panel ports.


Recall Files

Description

Any file that has previously been saved can be recalled using the  key.

Connect External Memory

To recall files from a USB flash drive or micro SD card, insert the appropriate device into the front panel ports.

1. Press  to enter the Recall menu.
2. Press *Type[F2]* and select a file type to save. See page 179 for details on file types:

State:	State data
Trace:	Trace data
Limit Line:	Limit line data
Correction:	Correction data
Sequence:	Sequence files

Power meter Power meter data

3. Press *Destination*[F3] to select the destination for the file type:

For State data: Local state data

For Trace data: Trace1~4

For Limit Lines: Limit line 1~5

For Correction: Correction data 1~5

For Sequence: Sequence 1~5

For Power Meter: Power meter 1 ~5

Recall File

1. Press *Recall From*[F1] and select a source location:

Register 1~6: Internal memory registers,
these internal registers are not
part of local memory

Local: Internal memory

USB External USB memory

SD Card: External micro SD card






2. To Recall the selected file type, press *Recall Now*[F1].
3. A message "Finish!!" will be displayed at the bottom of the screen when the recall is successful.



Note

The USB and micro SD card options will only be available when a flash drive/SD card is inserted into the front panel ports.

Quick Save

Description	The  key is a hot key to save files with a single press. The type of file that is saved is pre-configured with the  key. By default, the  the key will save screen shots to the local memory or to an external flash drive (if inserted).
Supported File Types	Screen, trace, state, limit line, correction, sequence.
Connect External Memory	To save files a USB flash drive or micro SD card, insert the appropriate device into the front panel ports.
Quick Save Setup	1. Press the  key and configure the file Type, Data Source and Format. See page 187 for details.
Using the Quick Save key	1. Press  at any time to save the selected file type using the settings above. 2. A “Save Finish!!” message will shown at the bottom of the screen when the save has been completed.

**Note**

The file name will be automatically created in the following format for data files:

File name: Type_data source_XX.file extension

The image file names will be automatically created in the following format:

File name: QuickJpg_XX.jpg

The XX parameter is incremented each time the same file type is created.

**Note**

The USB and micro SD card options will only be available when a flash drive/SD card is inserted into the front panel ports.

REMOTE CONTROL


This chapter describes basic configuration of IEEE488.2 based remote control. For a command list, refer to the programming manual, downloadable from GW Instek website, www.gwinstek.com

Interface Configuration	195
Configure to USB Remote Interface	195
Configure GPIB Interface	195
Configure the LAN and LXI Interface	196
Configure RS232C	199
RS232C Remote Control Function Check	199
LXI Browser Interface and Function Check	201

Interface Configuration

Configure to USB Remote Interface

USB configuration	PC side connector	Type A, host
	GSP side connector	Rear panel Type B, slave
	Speed	1.1/2.0 (full speed/high speed)
	USB Class	USB TMC (USB T&M class)


- Panel operation
1. Connect the USB cable to the rear panel USB B port. 
 2. Press **System** > More 1/2 [F7] > RmtInterface Config [F2] > USB Mode and toggle the USB mode to Device.



It may take a few moments to switch USB modes.

Configure GPIB Interface

To use GPIB, the optional GPIB port must be installed.

- Configure GPIB
1. Ensure the spectrum analyzer is off before proceeding.
 2. Connect a GPIB cable from a GPIB controller to the GPIB port on the spectrum analyzer. 
 3. Turn the spectrum analyzer on.

4. Press System >More 1/2[F7]>RmtInterface Config[F2]>GPIB Addr and set the GPIB address.

GPIB address 0~30

- GPIB constraints
- *Maximum 15 devices altogether, 20m cable length, 2m between each device*
 - *Unique address assigned to each device*
 - *At least 2/3 of the devices turned On*
 - *No loop or parallel connection*

Configure the LAN and LXI Interface

The GSP-930 is a class C LXI compliant instrument. The LXI specification allows instrumentation to be configured for basic remote control or monitoring over a LAN.

For details on the LXI specification and compliance classes, please see the LXI website @ <http://www.lxistandard.org>.


Background	The LAN interface is used for remote control over a network. The spectrum analyzer supports DHCP connections so the instrument can be automatically connected to an existing network. Alternatively, network settings can also be manually configured.
------------	--

LAN configuration Settings	IP Address	Default Gateway
	Subnet Mask	DNS Server
	DHCP on/off	

Connection	Connect an Ethernet cable from the network to the rear panel LAN port.
------------	--



Settings

1. Press  > More 1/2[F7] > RmtInterface > LAN[F2] > LAN Config[F1] to set the LAN settings:

- IP Address[F1]* Sets the IP address.
- Subnet Mask[F2]* Sets the subnet mask.
- Default Gateway[F3]* Sets the default gateway.
- DNS Server[F4]* Sets the DNS server address
- LAN Config[F5]* Toggles the LAN configuration between DHCP and manual settings.

2. Press *Apply[F6]* to confirm the LAN configuration settings.

Display Icon





The LXI icon turns green when connected to a LAN and will flash if the “Identification” setting is on, see page 201.

Set Password

The password on the LXI webpage can be set from the spectrum analyzer. The password is shown in the system information.


By default the password is set to: lxiWNpwnd

1. Press  > More 1/2[F7] > RmtInterface Config[F2] > LAN[F2] > LXIPassword[F2] to set the password.
2. Enter the password using the F1~F7 keys, as shown below, or use the numeric keypad to enter numbers:




Limitations:

- *No spaces*
- *Only 1~9, A~Z, a~z characters allowed*



Menu tree to enter the password

3. The password appears on the bottom of the screen as it is created.



4. Press **Enter** to confirm setting the password.

Reset LAN

It may be necessary to reset the LAN configuration settings before the LAN can be used.

1. Press **System** >More 1/2[F7]>RmtInterface Config[F2]>LAN Reset[F3] to reset the LAN.
2. The GSP-930 will now automatically reboot.



Each time the LAN is reset, the default password is restored.


Default password: lxiWNpwd

Configure RS232C

Background The RS232C interface is used for remote control with a PC.

RS232C Configuration settings	Baud Rate	Stop bit: 1 (fixed)
	Parity: none (fixed)	Data bit: 8 (fixed)

Connection Connect an RS232C cable from the PC to the rear panel RS232 port.



- Press **System** > More 1/2 [F7] > RmtInterface Config > RS232 BaudRate [F4] to set the baud rate.

300	600	1200
2400	4800	9600
19200	38400	57600
115200		

RS232C Remote Control Function Check

Functionality check Invoke a terminal application such as MTTY (Multi-Threaded TTY).

To check the COM port No, see the Device Manager in the PC. For WinXP; Control panel → System → Hardware tab.

Run this query command via the terminal after the instrument has been configured for RS232 remote control (page 197).

*idn?

This should return the Manufacturer, Model

number, Serial number, and Firmware version in the following format.

- *GW-INSTEK,GSP-930,XXXXXXXXXXXXX,
V.X.X.X.X*

Manufacturer: GW-INSTEK

Model number : GSP-930

Serial number : XXXXXXXXXXXXX

Firmware version : V.X.X.X



Note

For further details, please see the programming manual, available on the GW Instek web site @ www.gwinstek.com.

LXI Browser Interface and Function Check

Functionality check


Enter the IP address of the spectrum analyzer in a web browser after the instrument has been configured and connected to the LAN (page 196).

http:// XXX.XXX.XXX.XXX

The web browser interface appears:

Welcome Page

The Welcome Page lists all the LXI and LAN configuration settings as well as the instrument identification. The instrument identification can be disabled from this page.



 Note




The LXI icon in the GSP-930 display will flash when the Identification setting is turned on.

View & Modify Configuration

The View & Modify Configuration allows you to modify the LAN settings from the browser. A password must be entered to alter the settings.

Password: lxiWNpwd
 [Note: password is case sensitive.]



 **Note**


If the “Factory Defaults” option is chosen, the password will be reset back to the default password

It will also be necessary to manually reset the spectrum analyzer when a message prompts you to do so on the web browser.

SCPI Command


The SCPI Command page allows you to enter SCPI commands directly from the browser for full remote control. Please see the programming manual for details. A password must be entered before remote commands can be used.

Password: lxiWN\rpwd
 [Note: password is case sensitive.]



Get Image

The Get Image page allows the browser to remotely capture a screenshot of the GSP-930 display.



Note

For further details, please see the programming manual, available on the GW Instek web site @ www.gwinstek.com.

GPIB/LAN Control Function Check

Functionality
check

Please use the National Instruments
Measurement & Automation Controller
software to confirm GPIB/LAN functionality.

See the National Instrument website,
<http://www.ni.com> for details.



Note

For further details, please see the programming
manual, available on the GW Instek web site @
www.gwinstek.com.

F AQ

-
- I connected the signal but it does not appear on screen.
 - I want to see which optional items are installed.
 - The performance does not match the specification

I connected the signal but it does not appear on screen.

Run Autoset and let the GSP-930 find the best display scale for your target signal. Press the Autoset key, then press Autoset[F1]. For details, see page 59.

I want to see which optional items are installed.

Check the optional items in the system information window. Press the System key → System Information[F1]. For details, see page 105.

The performance does not match the specification.

Make sure the device is powered On for at least 30 minutes, within +20°C~+30°C. This is necessary to stabilize the unit to match the specification.

For more information, contact your local dealer or GWInstek at www.gwinstek.com / marketing@goodwill.com.

APPENDIX

Replace the Clock Battery


Background

The system clock and wake-up clock keep time using a button battery.


Battery type: CR2032, 3V, 210mAh

Connection

1. Turn off the GSP-930 and remove the battery cover and battery (if connected).



2. Replace the battery with the same type and specification.



Glossary of Acronyms

Acronym	Definition
3GPP	3 rd Generation Partnership Project
ACPR	Adjacent Channel Power Ratio
BS	Base Station
CF	Center Frequency
CH BW	Channel Bandwidth
CH SPC	Channel Space
CNR	Carrier to Noise Ratio
CSO	Composite Second Order
CTB	Composite Triple Beat
DANL	Displayed Average Noise Level
Def.	Default
DL	Down Link
DSSS-OFDM	Direct Sequence Spread Spectrum- Orthogonal Frequency Division Multiplexing
EMI	Electromagnetic Interference
ERP-CCK	Extended Rate Physical layer- Complimentary Code Keying
ERP-DSSS	Extended Rate Physical layer- Direct Sequence Spread Spectrum
ERP-OFDM	Extended Rate Physical layer- Orthogonal Frequency Division Multiplexing
ERP-PBCC	Extended Rate Physical layer- Packet Binary Convolutional Code
ETSI	European Telecommunications Standards Institute
FDD	Frequency-Division Duplexing
IF	Intermediate Frequency
LOI	Local Oscillator
LPF	Low Pass Filter
LXI	LAN eXtensions for Instrumentation
OCBW	Occupied Channel Bandwidth
PSD	Power Spectral Density
RBW	Resolution Bandwidth
REF	Reference
SEM	Spectrum Emission Mask
SINAD	Signal to Noise and Distortion Ratio
TDD	Time-Division Duplexing

TG	Tracking Generator
TOI	Third Order Intercept
UE	User Equipment
UP	Up Link
VBW	Video Bandwidth

GSP-930 Default Settings


The following default settings are the factory configuration settings for the spectrum analyzer (Function settings/Test settings).


Frequency		
Center Frequency: 1.5GHz	Start Frequency: 0Hz	
Stop Frequency: 3GHz	CF Step: Auto	
Frequency Offset: 0Hz		
Span		
Span: 3GHz		
Amplitude		
Reference level: 0.00dBm	Attenuation: Auto	
Scale Div: 10	Scale Type: Log	
Scale: Off	Y Axis: dBm	
Reference level offset: 0.00dBm	Correction: Off	
Input Z: 50Ω	Input Z calibration: 0.000dB	
Preamp: Bypass		
Autoset		
Amp.Floor: Auto	Span: Auto	
BW/Avg		
RBW: Auto	VBW: Auto	
VBW/RBW: N/A	Average: Off	
Average Power: Log Power	EMI Filter: Off	
Sweep		
Sweep Time: Auto	Sweep: Continuous	
Gated Sweep: Off	Gate Delay: 50ms	
Gate Length: 540ms		
Trace		
Activated traces: trace 1	Trace Type: Clear and Write	
Trace Math: Off	Detection: Auto, Normal	
Display		
Window Setup: Spectrum	LCD Brightness: Hi	
LCD Backlight: On	Display Line, -50.0dBm, Off	

Meas		
	ACPR: Off	OCBW: Off
	AM Analysis: Off	FM Analysis: Off
	Ear phone Out: Off	NdB BW: Off
	Phase Jitter: Off	SEM: Off
	TOI: Off	CNR/CSO/CTB: Off
Limit Line		
	Limit lines: Off	Pass/Fail Test: Off
Sequence		
	Sequence Off	
Trigger		
	Free Run	
File		
	Type: All	Sort by: Name
Quick Save		
	Type: Screen	Data Source:Normal
Save		
	Type: Screen	Data Source:Normal
Recall		
	Type: State	Destination: Local State
Marker		
	Marker: Off	Data Source:Normal
Marker->		
	N/A	
Peak Search		
	Peak Track: Off	Peak Excursion: 10dB
	Peak Threshold: 50dBm	Peak Table: Off
Mode		
	Mode: Spectrum	
System		
	Language: region dependent	Power On: Preset
	Preset Type: Factory Preset	Alarm Output: Off
		Remote Interface Config
		GPIB Address: 2
	Option	LAN: DHCP
	Tracking generator: Off	RS232 BaudRate: 115200
		USB Mode: Host

Menu Tree

Amplitude






Frequency, Span, Autoset, BW Avg, Sweep



Frequency	Span	Autoset
Center Freq 1.2345GHz	Span 1.2345GHz	Autoset
Start Freq 1.2345GHz	Full Span	Amp. Floor -80.00dBm <u>Auto</u> Man
Stop Freq 1.2345GHz	Zero Span	Span 3.00000MHz <u>Auto</u> Man
CF Step 1.00000MHz <u>Auto</u> Man	Last Span	
Freq Offset 0.00Hz		

BW/Avg		Sweep
RBW 1MHz <u>Auto</u> Man		Sweep Time 50.00 ms <u>Auto</u> Man
VBW 1MHz <u>Auto</u> Man		Sweep Single
VBW/RBW 1.00000		Sweep Cont
Average 20 <u>On</u> <u>Off</u>		Gated Sweep Mode <u>On</u> Off
Average Type> Log Power		Gate Delay 50.0 ms
EMI Filter <u>On</u> <u>Off</u>		Gate Length 540 ms


Limit Line




Trigger, Sequence




Trace, Display




Marker




Peak Search, Marker->




System




From: System>Date/
Time>Wake-Up Clock Edit>




From: System>More 1/2>
Rmt Interface Config>





From: System> More 1/2
>Option





From: System>More 1/2>
Rmt Interface Config>
RS232 Baud Rate




Mode, File






Save


(Mode = Power Meter)



From: Save>Save To>Local




(Mode = Spectrum)




Recall


(Mode = Power Meter)




(Mode = Spectrum)




Measure




From: Measure>Demod




From: Measure>TOI



From: Measure>CNR/CSO/CTB




From: Measure>Demod>AM
Analysis




* see page 120 for the selectable LPF filter bandwidths.

From: Measure>Demod>FM
Analysis




* see page 124 for the selectable LPF filter bandwidths.


From: Measure>SEM




From: Measure>SEM>3GPP>
REF. Channel






From: Measure>SEM>3GPP>
Offset/Limit





From: Measure>SEM>3GPP>
Offset/Limit>FDD Setup





From: Measure>SEM>
802.11b/g/n/
802.16>Ref. Channel

↓

Chan Integ BW 3.84MHz
Chan Span 3.96MHz
RBW 10kHz
PSD Ref -74.3dBm/Hz
Return

From:
Measure>SEM>
802.11g>Offset/
Limit

↓

Modulation> ERP-OFDM/ DSSS-OFDM
Min Offset/Limit Value>
Return

↔

ERP-OFDM/ DSSS-OPEM
ERP-DSSS/ ERP-PBCC/ ERP-CCK
Return

From:
Measure>SEM>
802.11n>Offset/
Limit

↓

CH BW <u>20M</u> 40M
Min Offset/Limit Value>
Return

From:
Measure>SEM>
802.16>Offset/Limit

↓

CH BW <u>10M</u> 20M
Min Offset/Limit Value>
Return

From:
Measure>SEM>
802.11b>Offset/Limit

↓

Offset 1 2
Start Freq 2.7MHz
Stop Freq 2.7MHz
RBW 3MHz
Rel Start -22dBc
Rel Stop -22dBc
Return


From: Measure>SEM>
802.11n/802.16>Offset/Limit>
Min Offset/Limit

↓

Offset 1 2 3 4
Start Freq 2.7MHz
Stop Freq 2.7MHz
RBW 3MHz
Rel Start -22dBc
Rel Stop -22dBc
Return


From: Measure>SEM>802.11g<
 Offset/Limit>Min Offset/Limit


802.11g modulation=DSSS



From: Measure>SEM>802.11g<
 Offset/Limit>Min Offset/Limit

802.11g modulation=OFDM





GSP-930 Specifications

The specifications apply when the GSP is powered on for at least 30 minutes to warm-up to a temperature of 20°C to 30°C, unless specified otherwise.

Frequency

Frequency		
Range	9 kHz to 3.0 GHz	
Resolution	1 Hz	
Frequency Reference		
Accuracy	$\pm[(\text{period since last adjustment} \times \text{aging rate}) + \text{stability over temperature} + \text{supply voltage stability}]$	
Aging Rate	± 2 ppm max.	1 year after last adjustment
Frequency Stability over Temperature	± 0.025 ppm	0 to 50 °C
Supply Voltage Stability	± 0.02 ppm	
Frequency Readout Accuracy		
Start, Stop, Center, Marker	$\pm(\text{marker frequency indication} \times \text{frequency reference accuracy} + 10\% \times \text{RBW} + \text{frequency resolution}^1)$	
Sweep points	601	Span > 0
	6 to 601	Span = 0
Marker Frequency Counter		
Resolution	1 Hz, 10 Hz, 100 Hz, 1 kHz	
Accuracy	$\pm(\text{marker frequency indication} \times \text{frequency reference accuracy} + \text{counter resolution})$	RBW/Span ≥ 0.02 ; Mkr level to DNL > 30 dB
Frequency Span		
Range	0 Hz (zero span), 100 Hz to 3 GHz	
Resolution	1 Hz	
Accuracy	\pm frequency resolution ¹	

Phase Noise		
Offset from Carrier		Fc = 1 GHz; RBW = 1 kHz, VBW = 10 Hz; Average ≥ 40
10 kHz	<-88 dBc/Hz	<i>Typical^k</i>
100 kHz	<-95 dBc/Hz	<i>Typical</i>
1 MHz	<-113 dBc/Hz	<i>Typical</i>
Resolution Bandwidth (RBW) Filter		
Filter Bandwidth	10 Hz to 3 kHz in 1-3-10 sequence	-3dB bandwidth subtotal: 6 filters
	10 kHz to 1 MHz, increment in 10% step	-3dB bandwidth; min. RBW = 10 kHz @ zero span Subtotal: 49 filters
	200 Hz, 9 kHz, 120 kHz	-6dB bandwidth
Accuracy	± 8%, RBW ≥ 750 kHz	Nominal ³
	± 5%, RBW < 750 kHz	Nominal
Shape Factor	< 4.5:1	Normal Bandwidth ratio: -60dB:-3dB
Video Bandwidth (VBW) Filter		
Filter Bandwidth	1 Hz to 1 MHz in 1-3-10 sequence	-3dB bandwidth

[1] Frequency Resolution = Span/(Sweep points - 1)

[2] Typical specifications in this datasheet mean that the performance can be exhibited in 80% of the units with a 95% confidence level over the temperature range 20 to 30 °C. They are not covered by the product warranty.

[3] Nominal values indicate expected performance. They are not covered by the product warranty.

Amplitude

Amplitude Range		
Measurement Range	100 kHz to 1 MHz	Displayed Average Noise Level (DANL) to 18 dBm
	1 MHz to 10 MHz	DANL to 21 dBm
	10 MHz to 3 GHz	DANL to 30 dBm
Attenuator		
Input Attenuator Range	0 to 50 dB, in 1 dB step	Auto or manual setup
Maximum Safe Input Level		
Average Total Power	≥ +33 dBm	Input attenuator ≥10 dB
DC Voltage	± 50 V	

1 dB Gain Compression

Total Power at 1st Mixer	> 0 dBm	<i>Typical</i> ; $F_c \geq 50$ MHz; preamp. off
Total Power at the Preamp	> -22 dBm	<i>Typical</i> ; $F_c \geq 50$ MHz; preamp. on
		mixer power level (dBm) = input power (dBm) - attenuation (dB)

Displayed Average Noise Level (DANL)

Preamp off	0 dB attenuation; RBW 10 Hz; VBW 10 Hz; span 500 Hz; reference level = -60dBm; trace average ≥ 40	
9 kHz to 100 kHz	< -93 dBm,	
100 kHz to 1 MHz	< -90 dBm - 3 x (f/100 kHz) dB	Nominal
1 MHz to 10 MHz	< -122 dBm	
10 MHz to 3 GHz	< -122 dBm	
Preamp on	0 dB attenuation; RBW 10 Hz; VBW 10Hz; span 500 Hz; reference level = -60dBm; trace average ≥ 40	
100 kHz to 1 MHz	< -108 dBm - 3 x (f/100 kHz) dB	
1 MHz to 10 MHz	< -142 dBm	Nominal
10 MHz to 3 GHz	< -145 dBm + 3 x (f/1 GHz) dB	

Level Display Range

Scales	Log, Linear	
Units	dBm, dBmV, dBuV, V, W	
Marker Level	0.01 dB	Log scale
Readout	0.01 % of reference level	Linear scale
Level Display Modes	Trace, Topographic, Spectrogram	Single / split Windows
Number of Traces	4	
Detector	Positive-peak, negative-peak, sample, normal, RMS(not Video)	Can be setup for each trace separately
Trace Functions	Clear & Write, Max/Min Hold, View, Blank, Average	

Absolute Amplitude Accuracy

Absolute Point	Center=160 MHz ; RBW 10 kHz; VBW 1 kHz; span 100 kHz; log scale; 1 dB/div; peak detector; 20 to 30°C; signal 0 dBm	
Preamp off	± 0.3 dB	Ref level 0 dBm; 10 dB RF attenuation
Preamp on	± 0.4 dB	Ref level -30 dBm; 0 dB RF attenuation

Frequency Response

Preamp off	Attenuation: 10 dB; Reference: 160 MHz; 20 to 30°C	
100 kHz to 2.0 GHz	± 0.5 dB	
2.0GHz to 3.0 GHz	± 0.7 dB	
Preamp on	Attenuation: 0 dB; Reference: 160 MHz; 20 to 30°C	
1 MHz to 2.0 GHz	± 0.6 dB	
2.0GHz to 3.0 GHz	± 0.8 dB	

Attenuation Switching Uncertainty

Attenuator setting 0 to 50 dB in 1 dB step		
Uncertainty	± 0.15 dB	reference: 160 MHz, 10dB attenuation

RBW Filter Switching Uncertainty

10 Hz to 1 MHz	± 0.15 dB	reference : 10 kHz RBW
----------------	-----------	------------------------

Level Measurement Uncertainty

Overall Amplitude Accuracy	± 1.5 dB	20 to 30°C; frequency > 1 MHz; Signal input 0 to -50 dBm; Reference level 0 to -50 dBm; Input attenuation 10 dB; RBW 1 kHz; VBW 1 kHz; after cal; Preamp Off
	± 0.5 dB	<i>Typical</i>

Spurious Response		
Second Harmonic Intercept		Preamp off; signal input -30dBm; 0 dB attenuation
	+35 dBm	<i>Typical</i> ; 10 MHz < fc < 775 MHz
	+60 dBm	<i>Typical</i> ; 775 MHz ≤ fc < 1.5 GHz
Third-order Intercept		Preamp off; signal input -30dBm; 0 dB attenuation
	> 1dBm	300 MHz to 3 GHz
Input Related Spurious	< -60 dBc	Signal level -30 dBm at 1st mixer; 20 to 30°C
Residual Response (inherent)	<-90 dBm	Input terminated; 0 dB attenuation; Preamp off

Sweep

Sweep Time		
Range	22 ms to 1000 s	Span > 0 Hz
	50 us to 1000 s	Span = 0 Hz; Min Resolution = 10 us
Sweep Mode	Continuous; Single	
Trigger Source	Free run; Video; External	
Trigger Slope	Positive or negative edge	

RF Preamplifier

Frequency Range	1 MHz to 3 GHz	
Gain	18 dB	Nominal (installed as standard)

Front Panel Input/Output

RF Input		
Connector Type	N-type female	
Impedance	50 ohm, nominal	
VSWR	<1.6 :1	300 kHz to 3 GHz; Input attenuator ≥ 10 dB

Power for Option

Connector Type	SMB male	
Voltage/Current	DC +7V / 500 mA max	With short-circuit protection

USB Host

Connector Type	A plug	
Protocol	Version 2.0	Supports Full/High/Low speed

MicroSD Socket

Protocol	SD 1.1	
Supported Cards	microSD, microSDHC	Up to 32GB capacity

Rear Panel Input/Output

Reference Output

Connector Type	BNC female
Output Frequency	10 MHz
Output Amplitude	3.3V CMOS
Output Impedance	50 ohm

Reference Input

Connector Type	BNC female
Input Reference Frequency	10 MHz
Input Amplitude	-5 dBm to +10 dBm
Frequency Lock Range	Within ± 5 ppm of the input reference frequency

Alarm Output

Connector Type	BNC female; Open-collector
----------------	----------------------------

Trigger Input/ Gated Sweep Input

Connector Type	BNC female
Input Amplitude	3.3V CMOS
Switch	Auto selection by function

LAN TCP/IP Interface

Connector Type	RJ-45
Base	10Base-T; 100Base-Tx; Auto-MDIX

USB Device

Connector Type	B plug	For remote control only; supports USB TMC
Protocol	Version 2.0	Supports Full/High speed

IF Output		
Connector Type	SMA female	
Impedance	50 ohm	Nominal
IF Frequency	886 MHz	Nominal
Output level	-25 dBm	10 dB attenuation; RF input: 0 dBm @ 1 GHz;
Earphone Output		
Connector Type	3.5mm stereo jack, wired for mono operation	
Video Output		
Connector Type	DVI-I (integrated analog and digital) , Single Link	Compatible with VGA or HDMI standard through adapter
RS232 Interface		
Connector Type	D-sub 9-pin female	Tx,Rx,RTS,CTS
GPIB Interface (Optional)		
Connector Type	IEEE-488 bus connector	
AC Power Input		
Power Source	AC 100 V to 240 V, 50 / 60 Hz	Auto range selection
Battery Pack (Optional)		
Battery pack	6 cells, Li-Ion rechargeable, 3S2P	With UN38.3 Certification
Voltage	DC 10.8 V	
Capacity	5200 mAh / 56Wh	

General

Internal Data storage	16 MB nominal	
Power Consumption	<65 W	
Warm-up Time	< 30 minutes	
Temperature Range	+5 °C to +45 °C	Operating
	-20 °C to + 70 °C	Storage
Weight	4.5 kg (9.9 lb)	Inc. all options (Basic+TG+GPIB+Battery)
Dimensions	210 x 350 x 100 (mm)	
	8.3 x 13.8 x 3.9 (in)	

Tracking Generator (Optional)


Frequency Range	100 kHz to 3 GHz	
Output Power	-50 dBm to 0 dBm in 0.5 dB steps	
Absolute Accuracy	± 0.5 dB	@160 MHz, -10 dBm, Source attenuation 10 dB, 20 to 30°C
Output Flatness	Referenced to 160 MHz, -10 dBm	
	100 kHz to 2 GHz	± 1.5 dB
	2 GHz to 3 GHz	± 2 dB
Output Level	± 0.8 dB	Referenced to -10 dBm
Switching Uncertainty		
Harmonics	< -30 dBc	Typical, output level = -10 dBm
Reverse Power	+30 dBm max.	
Connector type	N-type female	
Impedance	50 ohm	Nominal
Output VSWR	< 1.6:1	300 kHz to 3 GHz, source attenuation ≥ 12 dB

USB Power Sensor (Optional)


Type	Average power sensor Model: PWS-06	
Interface to Meter	USB cable to GSP930 Front-Panel USB Host	
Connector Type	N-type male, 50 ohm nominal	
Input VSWR	1.1: 1	Typical
	1.3: 1	Max
Input Frequency	1 to 6200 MHz	
Sensing Level	-32 to +20 dBm	
Max. Input Damage Power	≥ 27 dBm	

Power Measurement Uncertainty @ 25 °C	-30 dBm to +5 dBm: 1 MHz to 3GHz: ± 0.10 dB typical 3 GHz to 6 GHz: ± 0.15 dB typical +5 dBm to +12 dBm: 1 MHz to 3GHz: ± 0.15 dB typical 3 GHz to 6 GHz: ± 0.15 dB typical +12 dBm to +20 dBm: 1 MHz to 3GHz: ± 0.20 dB typical 3 GHz to 6 GHz: ± 0.20 dB typical	± 0.30 dB max. ± 0.30 dB max. ± 0.30 dB max. ± 0.30 dB max. ± 0.40 dB max. ± 0.40 dB max.
Power Measurement Uncertainty @ 0 to 25 °C	-30 dBm to +5 dBm: 1 MHz to 3GHz: ± 0.25 dB typical 3 GHz to 6 GHz: ± 0.25 dB typical +5 dBm to +12 dBm: 1 MHz to 3GHz: ± 0.20 dB typical 3 GHz to 6 GHz: ± 0.20 dB typical +12 dBm to +20 dBm: 1 MHz to 3GHz: ± 0.35 dB typical 3 GHz to 6 GHz: ± 0.30 dB typical	
Linearity @ 25 °C	± 3 %	
Measurement Speed	100 ms for Low Noise Mode 30 ms for Fast Mode	

GSP-930 Dimensions



Unit: mm



Declaration of Conformity

We

GOOD WILL INSTRUMENT CO., LTD.

No. 7-1, Jhongsing Rd, Tucheng Dist., New Taipei City 236, Taiwan

GOOD WILL INSTRUMENT (SUZHOU) CO., LTD.

No. 69 Lushan Road, Suzhou New District Jiangsu, China.

declare that the below mentioned product

Type of Product: Spectrum Analyzer

Model Number: GSP-930

is herewith confirmed to comply with the requirements set out in the Council Directive on the Approximation of the Laws of the Member States relating to the Low Voltage Directive (2006/95/EC) and Electromagnetic Compatibility (2004/108/EC).

For the evaluation regarding the Electromagnetic Compatibility and Low Voltage Directive, the following standards were applied:

© EMC

EN 61326-1 : EN 61326-2-1: EN 61326-2-2:	Electrical equipment for measurement, control and laboratory use -- EMC requirements (2006)	
Conducted and Radiated Emissions EN 55011: 2009+A1: 2010		Electrostatic Discharge EN 61000-4-2: 2009
Current Harmonic EN 61000-3-2: 2006+A1: 2009+A2: 2009		Radiated Immunity EN 61000-4-3: 2006+A1: 2008+A2 :2010
Voltage Fluctuation EN 61000-3-3: 2008		Electrical Fast Transients EN 61000-4-4: 2004+A1: 2010
-----		Surge Immunity EN 61000-4-5: 2006
-----		Conducted Susceptibility EN 61000-4-6: 2009
-----		Power Frequency Magnetic Field EN 61000-4-8: 2010
-----		Voltage Dips/ Interrupts EN 61000-4-11: 2004

Low Voltage Equipment Directive 2006/95/EC	
Safety Requirements	EN 61010-1: 2010 EN 61010-2-030: 2010

INDEX

Accessories	11	CTB	156
ACPR.....	114	Date, Time, Wake-up clock.....	28
Adjacent channel power	114	Declaration of conformity	250
Alarm output.....	108	Default settings	209
AM Analysis.....	119	Display	
AM/FM demodulation sound		Backlight	98
out	127	Brightness	98
Amplitude		Display mode	
Amplitude correction.....	51	Setting.....	100
Attenuation	47	Spectrogram.....	101
Correction.....	52	Topographic.....	102
Input impedance.....	56	Reference level line	99
Pre-amplifier	57	Spit spectrum view	103
Reference level	46	Video out.....	99
Reference level offset	50	Display diagram.....	20
Scale.....	48	Disposal instructions	6
Scale/div	48	Disposal symbol.....	3
Vertical scale unit	50	EMI Filter	66
View scale.....	49	EN61010	
Autoset.....	59	Measurement category	4
Horizontal settings	60	Pollution degree	5
Vertical settings	60	Environment	
Average		Safety instruction	5
Trace.....	63	FAQ.....	205
Type	65	File	
Bandwidth		Copy files	183
RBW	61	Correction data.....	181
VBW	62	Delete files.....	184
VBW/RBW ratio.....	62	File explorer.....	181
Battery		File types	180
Safety instruction.....	5	Limit line data	180
Battery insertion.....	25	Move files.....	183
Carrier to noise ratio	152	Overview.....	178
Caution symbol.....	3	Power meter data.....	181
Cleaning the instrument	5	Quick save.....	192
CNR.....	152	Recall files	190
Composite second order	155	Rename files.....	185
Composite triple beat.....	156	Save files.....	187
Conventions	32	Screen files	180
CSO.....	155	Sequence data.....	181
		State data.....	180
		Trace data.....	180

Firmware update.....	30	OCBW	117
First time use instructions	24	Overview	112
FM Analysis	123	Phase Jitter.....	129
Frequency		SEM	144
Center frequency.....	39	3GPP	147
Center frequency step.....	41	802.XX.....	149
Frequency offset.....	42	Overview	132
Start frequency.....	40	User.....	145
Stop frequency.....	40	TOI.....	150
Front panel diagram	13	Menu tree	
Glossary	207	Amplitude	211
Ground		Autoset.....	213
Symbol.....	3	BW Avg.....	213
Language.....	106	Display.....	216
Limit lines		File	222
Creation.....	159	Frequency	213
Deletion	163	Limit line.....	214
Overview.....	159	Marker.....	217
Pass/fail testing.....	163	Marker->	218
List of features	9	Measure.....	229
Marker		Mode	222
Delta markers	87	Peak search.....	218
Functions		Recall.....	227
Frequency counter	90	Save	224
Noise.....	89	Sequence.....	215
Move to trace	91	Span.....	213
Moving delta markers	88	Sweep.....	213
Moving markers manually.....	86	System.....	219
Moving markers to preset		Trace.....	216
positions	86	Trigger.....	215
Moving reference markers	88	NdB bandwidth	128
Normal marker.....	85	OCBW	117
Peak configuration	95	Occupied bandwidth.....	117
Peak search.....	93	Package contents.....	12
Peak table	96	Peak search	93
Table	92	Peak table.....	96
Marketing		Phase Jitter.....	129
Contact.....	205	Power meter	
Measurement		Activation	173
ACPR	114	Data logging.....	175
AM Analysis	119	Power on/off	
AM/FM demodulation sound		Safety instruction	4
out	127	Power up.....	26, 27
CNR	152	Pre-amplifier	57
CSO	155	Preset	109
CTB	156	Power on settings.....	110
FM Analysis.....	123	Settings.....	109, 110
NdB bandwidth.....	128	Quick save	192

RBW.....	61	Sweep	
Rear panel diagram	18	Continous sweep.....	68
Remote control	194	Gated sweep	68
GPIO configuration.....	195	Single sweep	67
LAN configuration	196	Sweep time.....	66
RS232C configuration	199	System	
USB configuration	195	Alarm output.....	108
Remote control function check	199	Date & time.....	106
Replace the clock battery	206	Set language.....	106
Restore default settings.....	31, 109	System information.....	105
SEM		View error messages.....	105
3GPP.....	147	Wake-up clock.....	107
802.XX	149	Third order intermodulation	
Overview	132	distortion	150
User	145	Tilting stand.....	24
Sequance		TOI	150
Editing	165	Trace	
Overview	165	Detection modes.....	75
Running.....	169	Icons.....	73
Service operation		Math.....	74
About disassembly	4	Selecting trace.....	72
Contact.....	205	Type.....	72
Span		Tracking generator	
Full span	44	Activation.....	170
Last span.....	45	Normalization	171
Setting	43	Trigger	
Zero span.....	44	Delay.....	83
Specifications.....	240	External trigger.....	81
Amplitude	241	Free run	79
Dimensions.....	249	Mode.....	82
Frequency	240	Video trigger.....	79
General.....	246	UK power cord.....	7
Input/output.....	244	VBW.....	62
Power sensor.....	247	VBW/RBW ratio	62
RF amplifier.....	244	Video out port	99
Sweep.....	244	Warning symbol.....	3
Tracking generator	247	Web server function check	201, 204
Spectrum emission mask testing	144		
Status icons	22		